Quoizel, Inc. 6 Corporate Parkway Goose Creek, SC 29445

Customer Service Phone 631.273.2700 Fax 631.231.7102 www.quoizel.com

Assembly Instruction Sheet #IS-UPPS2813WT For Style UPPS2813WT

Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.

Bulb Recommended: (3)T8 Candelabra Filament Bulb, 60W Maximum (Supplied) **Estimated Assembly Time:** 20-30 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.



Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.


These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

Do not touch the bulb with bare hands use a cloth or glove.

Package Contents

Part	Description	Quantity
Α	Crossbar	1 pc.
В	Nipple	1 pc.
С	Lock Washer	2 pcs.
D	Hex Nut	2 pcs.
E	Ceiling Canopy	1 pc.
F	Canopy Chain Loop	1 pc.
G	Canopy Lock Ring	1 pc.
Н	Fixture Chain	1 pc.
I	Fixture Loop	1 pc.
J	6" Rod	2 pcs.
K	12" Rod	2 pcs.
L	Lock Ball	3 pcs.
М	Shade	1 pc.
N	Lock Screw	3 pcs.
0	Bulb	3 pcs.
Р	Side Arm	3 pcs.
Q	Socket Assembly	1 pc.
R	Candle Cover	3 pcs.
S	Shade Holder	1 pc.




Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com

September 2013

1of7




2of7

Assembly Instruction Sheet #IS-UPPS2813WT For Style UPPS2813WT


STEP 1 – Assemble Side Arm to Socket Assembly

A. Line up the Mounting Hole on the Socket Assembly (Q) and the Hole on the Side Arm (P). Secure by threading the Lock Ball (L) into the Mounting Hole on the Socket Assembly (Q). Hand tighten until sung.



STEP 2 - Assemble Rods

- A. Determine the Rods (J/K) to be assembled to the Socket Assembly (Q) according to your hanging height.
- B. Pass Supply Wires and Ground Wire through the chosen Rods (J/K) and then thread the chosen Rods (J/K) and the Socket Assembly (Q) together. Hand tighten until snug.



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com


September 2013



Assembly Instruction Sheet #IS-UPPS2813WT For Style UPPS2813WT

STEP 3 - Assemble Fixture Loop to Upper Rod

A. Pass Supply Wires and Ground Wire through the Fixture Loop (I) then thread the Fixture Loop (I) and the Upper Rod together. Hand tighten until snug.



STEP 4 - Attach Crossbar to Outlet Box

A. Secure the Crossbar (A) to the outlet box with outlet box screws (not supplied). Tighten until snug.





Figure 4

STEP 5 - Attach Nipple to Crossbar

- A. Thread one Hex Nut (D) onto the top end of the Nipple (B).
- B. Place one Lock Washer (C) over the top end of the Nipple (B) and then thread the Nipple (B) into the center lock hole of the Crossbar (A).
- C. Using pliers, thread the Hex Nut (D) against the Crossbar (A) and hand tighten until snug.



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700 or visit us on-line at www.quoizel.com


Ser

4of7

Assembly Instruction Sheet #IS-UPPS2813WT For Style UPPS2813WT


STEP 6 - Attach Canopy Chain Loop to Nipple

- A. Thread another Hex Nut (D) onto the end of the Nipple (B).
- B. Place the Lock Washer (C) over the end of the Nipple (B) and then thread the Canopy Chain Loop (F) onto the end of the Nipple (B).
- C. Using pliers, thread the Hex Nut (D) against the Canopy Chain Loop and hand tighten until snug.




STEP 7 - Assemble Ceiling Canopy

A. Push the Ceiling Canopy (E) upward over the Outlet Box. Thread the Canopy Lock Ring (G) onto the Canopy Chain Loop and tighten until snug to secure the Ceiling Canopy (E).



STEP 8 - Attach Fixture Chain to Canopy Chain Loop and Fixture Loop

- A. You may need to use plier to open the chain links. If so, put a cloth over the chain to protect the finish from the pliers.
- B. Attach one end of the Fixture Chain (H) onto the Canopy Chain Loop (F) and then attach the other end of the Fixture Chain (H) onto the Fixture Loop (I) on the top of the fixture.



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com


© 2013 Quoizel Inc.

September 2013

Assembly Instruction Sheet #IS-UPPS2813WT For Style UPPS2813WT

STEP 9 - Pass Supply Wires through Fixture Chain

A. Pull the Supply Wires and Ground Wire up through the Fixture Chain (H) alternating links. Push the wires up through the Canopy Chain Loop (F) into the outlet box.



STEP 10 - Make Wire Connections

- A. Un-thread the Canopy Lock Ring (G) and slide Canopy Lock Ring (G) and Ceiling Canopy (E) down the Fixture Chain.
- B. Push all slack fixture wire through Canopy Chain Loop into Outlet Box. Trim excess fixture wire leaving a minimum of 6 inch. Hanging out of the Outlet Box.
- C. Use standard wire connectors to make all wire connections. (Connectors are not included with fixture.) Strip and prepare wire ends according to instructions supplied with connectors.
- D. Connect White Supply Wire from the Outlet Box to Ribbed side Wire from fixture.
- E. Connect Black (or Red) Supply Wire from the Outlet Box to Smooth side Wire from fixture.
- F. Connect Ground Wire from the Outlet Box to Ground Wire from fixture.
- G. Twist connectors until wires are tightly joined together.
- H. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box.

Figure 10


G. Re-attach the Ceiling Canopy (E) as shown in Step 7.

White wire from supply

Black wire from supply

(or Red)

Ground wire from supply



Thank you for purchasing a Quoizel product.

Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700

or visit us on-line at www.quoizel.com


September 2013

QUOIZEL 6 CORPORATE PARKWAY GOOSE CREEK, SC. 29445

Assembly Instruction Sheet #IS-UPPS2813WT For Style UPPS2813WT


STEP 11 - Install Candle Cover

A. Place the Candle Cover (R) over the Socket as shown.



STEP 12 - Attach Shade to Fixture


A. Place the Shade (M) into the Shade Holder (S). Line up the Mounting Hole on the Shade Holder (S) and Hole on the bottom end of the Side Arms (P). Secure by threading the Lock Screw (N) into the Stud on the Shade Holder (S). Hand tighten until sung.



STEP 13 - Install Bulb and Bulb Shield

- A. This fixture uses T8 Candelabra Filament Bulbs, Maximum 60 watts.
- B. Insert bulb and seat properly into place.

Your lamp wall fixture is now assembled and ready to use. Enjoy!



Thank you for purchasing a Quoizel product. Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700 or visit us on-line at www.quoizel.com September 2013

© 2013 Quoizel Inc.