(4) (\$)
PROJECT

Project Source® is a registered trademark of LF, LLC. All rights reserved.


ITEM #0586865

MINI PENDANT

MODEL #ROC91216-18-1

Français p. 8

Español p. 15



ATTACH YOUR RECEIPT HERE

Serial Number _____ Purchase Date _



Intertek




Questions, problems, missing parts? Before returning to your retailer, call our customer service department at 1-866-389-8827, 8 a.m. - 6 p.m., EST, Monday - Thursday, 8 a.m. -5 p.m., EST, Friday.

PROJECT SOURCE.


AB14458

Lowes.com



PART	DESCRIPTION	QUANTITY
Α	Ceiling plate	1
В	Stem	3
С	Lamp holder	1
D	Glass shade	1
E	Check ring (preassembled to Lamp holder (C))	1
F	Short stem	2
G	Bottom stem	1

HARDWARE CONTENTS (shown actual size)





SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.



WARNING

- TURN OFF ELECTRICITY at main fuse box (or circuit breaker box) before beginning installation by removing fuse (or switching off circuit breaker).
- MINIMUM 90°C SUPPLY CONDUCTORS.

CAUTION

- CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR.
- If in doubt about electrical installation, consult a licensed electrician.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 15 minutes

Tools Required for Assembly (not included): Flathead screwdriver, Phillips screwdriver, Pliers, Electrical tape, Wire cutters, Safety glasses.

Helpful Tools (not included): Wire strippers, Step ladder.


Lowes.com

Lowes.com


ASSEMBLY INSTRUCTIONS

1. Remove cap nuts (AA) from the preassembled mounting screws on crossbar (DD). Attach crossbar (DD) to the outlet box (not included) with machine screws (CC). Note: The mounting screws should protrude away from the outlet box.


Hardware Used





2. Attach bottom stem (G) to lamp holder (C). Then, install stems (B) and short stems (F) based on the desired length of the item, adding ceiling plate (A) once finished.



3. Strip 3/4 in. of insulation from wire ends. Twist stripped ends together with pliers, black to the wire with smooth surface (power) and white to the wire with longitudinal ridges (neutral). Attach copper wire to ground wire. Helpful hint: If necessary, attach copper ground wire to grounded junction box.







PROJECT SOURCE.

ASSEMBLY INSTRUCTIONS

4. Attach wire nuts (BB). Tape wire nuts (BB) and wires together.

Hardware Used







5

-DD


5. Place ceiling plate (A) onto mounting screws on the crossbar (DD). Secure with cap nuts (AA).

Hardware Used





6. Remove check ring (E). Place glass shade (D) over lamp holder (C), securing with check ring (E).




Lowes.com

PROJECT SOURCE.

ASSEMBLY INSTRUCTIONS

7. Install light bulbs (not included). Use only 60-watt or less standard-base bulbs or 13-watt standard-base CFL bulbs.



CARE AND MAINTENANCE

• Shut off main power supply before wiping product with damp cloth or window cleaner. Do not use abrasives.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Bulb won't light.	 Bulb is burned out. Power is off. Faulty wire connection. Faulty switch. 	 Replace light bulb. Make sure power supply is on. Check wiring. Test or replace switch.
Fuse blows or circuit breaker trips when light is turned on.	Crossed wires or power wire is grounding out.	Check wire connections.

6


WARRANTY

The manufacturer warrants all of its lighting fixtures against defects in materials and workmanship for one (1) year from the date of purchase. If within this period the product is found to be defective in material or workmanship, the product must be returned, with a copy of the original sales receipt as proof of purchase in the original carton, to the place of purchase. The manufacturer will, at its option, repair, replace or refund the original purchase price to the consumer. This warranty does not cover fixtures becoming defective due to misuse, accidental damage, improper handling and/or installation and specifically excludes liability for direct, incidental or consequential damages. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state.

REPLACEMENT PARTS LIST

For replacement parts, call our customer service department at 1-866-389-8827, 8 a.m. - 6 p.m., EST, Monday - Thursday, 8 a.m. - 5 p.m., EST, Friday.

PART	DESCRIPTION	PART#
AA	Cap nut	110-121001
BB	Wire nut	375-022000
CC	Machine screw	109-042600
DD	Crossbar	152-103004



Printed in China

Project Source® is a registered trademark of LF, LLC. All rights reserved.