


132x192mm

REFRIGERATOR
FREEZER



4.0 CU FT
133 L

USER MANUAL

BR401/SR401

IMPORTANT SAFETY INSTRUCTIONS

WARNING	To reduce the risk of fire, electrical shock, or injury when using your refrigerator, follow these basic precautions:
<ul style="list-style-type: none">Read all instructions before using the refrigerator.DANGER or WARNING: Risk of child entrapment.<ul style="list-style-type: none">To avoid the possibility of child entrapment, please take the following precautions before throwing out the refrigerator.<ul style="list-style-type: none">Remove all doors from the unit.Leave the shelves in place so that children may not easily climb inside.Never allow children to operate, play with, or crawl inside the refrigerator.Refrigerants: All refrigeration products contain refrigerants, which under the guidelines of federal law must be removed before disposal of product. It is the consumer's responsibility to comply with federal and local regulations when disposing of this product.Never clean refrigerator parts with flammable fluids. The fumes can create a fire hazard or explosion.Do not store or use gasoline or any other flammable vapors and liquids in the vicinity of this or any other refrigerator. The fumes can create a fire hazard or an explosion.Save these instructions.	

INSTALLATION INSTRUCTIONS

- Before Using Your Refrigerator**
- Remove the exterior and interior packing.
 - Remove connecting the refrigerator to the power source, let it stand upright for approximately 4 hours. This will reduce the possibility of a malfunction in the cooling system from improper handling during transportation.
 - Clean the interior surface with lukewarm water using a soft cloth. (Cleaning instruction on page 9)
- Installing Your Refrigerator**
- This appliance is designed to be free standing only, and should not be recessed or built-in.
 - Place your refrigerator on a floor that is strong enough to support the refrigerator when it is fully loaded.
 - Allow 4 inches of space between the back and sides of the refrigerator, which allows the proper air ventilation. Adjust the feet to keep the refrigerator level.
 - Locate the refrigerator away from direct sunlight and sources of heat (stove, heater, radiator, etc.). Direct sunlight may affect the acrylic coating and heat sources may increase electrical consumption. Ambient temperature below 80°F (15°C) or above 85°F (24°C) will hinder the performance of this appliance. This unit is not designed for use in a garage or any other outside installation.
 - Avoid locating the refrigerator in moist areas.
 - Plug the refrigerator into dedicated, properly installed grounded wall outlet. Do not under any circumstances cut or remove the third ground prong from the power cord. Any questions concerning power and/or grounding should be directed toward a certified electrician or an authorized service center. This unit is not designed to be installed in an RV or used with an inverter.
 - After plugging the appliance into a wall outlet, turn the unit on and allow the unit to cool down for 2-3 hours under before placing food in the refrigerator or freezer compartment.

CARE AND MAINTENANCE

- Cleaning Your Refrigerator**
- Upon installation of your new appliance, it is recommended that it be cleaned thoroughly.
 - Turn off the refrigerator first and then unplug the unit from the wall outlet.
 - Remove all food contents.
 - Wash the inside with a damp warm cloth soaked in lukewarm water and baking soda solution. The solution should be about 2 tablespoons of baking soda to a quart of water.
 - Be sure to keep the door gasket (seal) clean to keep the unit running efficiently.
 - The outside of the refrigerator should be cleaned with mild detergent and warm water.
 - Dry the interior and exterior with a soft cloth.
- Vacuum Time**
- Turn off the refrigerator first and then unplug the unit from the wall outlet.
 - Remove all the food.
 - Clean the refrigerator.
 - Leave the door open slightly to avoid possible formation of condensation, mold, or odor.
 - Use extreme caution in the case of children. The unit should not be accessible to child's play.
 - Short vacations:** Leave the refrigerator operating during vacations of less than three weeks.
 - Long vacations:** If the appliance will not be used for several months, remove all food and unplug the power cord. Clean and dry the interior thoroughly. To prevent odor and mold growth, leave the door open slightly, blocking it open if necessary or have the door removed.
- Moving Your Refrigerator**
- Turn off the refrigerator first and then unplug the unit from the wall outlet.
 - Remove all the food.
 - Securely tape all loose items inside your refrigerator.
 - Lean the doors shut.
 - Be sure the refrigerator stays in the upright position during transportation.
- Energy Saving Tips**
- The refrigerator should be located in the coolest area of the room, away from heat producing appliances or heating ducts, and out of the direct sunlight.
 - Let hot foods cool to room temperature before placing in the refrigerator. Overloading the refrigerator forces the compressor to run longer. Foods that freeze too slowly may lose quality or spoil.
 - Be sure to wrap foods properly, and wipe containers dry before placing them in the refrigerator. This cuts down on frost build-up inside the refrigerator.
 - Organize and label food to reduce door openings and extended searches. Remove as many items as needed at one time, and close the door as soon as possible.

TABLE OF CONTENTS

NAMES OF THE PARTS.....	2
IMPORTANT SAFETY INSTRUCTIONS.....	3
INSTALLATION INSTRUCTION.....	4
BEFORE USING YOUR REFRIGERATOR.....	4
INSTALLING YOUR REFRIGERATOR.....	4
ELECTRICAL CONNECTION.....	5
OPERATING YOUR REFRIGERATOR.....	5
TEMPERATURE CONTROL.....	5
ICE TRAY.....	5
THE FREEZER COMPARTMENT.....	6
WHEN TO DEFROST.....	6
HOW TO DEFROST.....	6
HOW TO CHANGE THE INTERIOR LIGHT.....	6
CHANGING THE REVERSIBLE DOOR.....	7
CARE AND MAINTENANCE.....	8
CLEANING YOUR REFRIGERATOR.....	8
VACATION TIME.....	8
MOVING YOUR REFRIGERATOR.....	8
ENERGY SAVING TIPS.....	8
TROUBLESHOOTING GUIDE.....	9

Electrical Connection

WARNING

Improper use of the grounded plug can result in the risk of electrical shock. If the power cord is damaged, have it replaced by an authorized service center.

This refrigerator should be properly grounded for your safety. The power cord of this refrigerator is equipped with a three-prong plug which makes with standard three-prong wall outlets to minimize the possibility of electrical shock.

Do not, under any circumstances, cut or remove the third ground prong from the power cord supplied.

This refrigerator requires a standard 115/120 Volt A.C. 60Hz electrical outlet with three-prong ground.

This refrigerator is not designed to be used with an inverter.

The cord should be secured behind the refrigerator and not left exposed or dangling to prevent accidental injury.

Never unplug the refrigerator by pulling the power cord. Always grip the plug firmly and pull straight out from the receptacle.

Do not use an extension cord with this appliance. If the power cord is too short, have a qualified electrician or service technician install an outlet near the appliance. Use of an extension cord can negatively affect the performance of the unit.

OPERATING YOUR REFRIGERATOR


- Temperature Control**
- Your refrigerator has one control for regulating the temperature. The temperature control is located on the top center of the refrigerator compartment.
 - The first time you turn the unit on, adjust the temperature control knob to "5". Sand run for at least 2 hours before putting foods inside. This will ensure the cabinet is thoroughly chilled before food is put in.
 - The range of the refrigerator temperature control is from position "1" to "5". The cabinet. Adjust the temperature control to the setting that best suits your needs. The setting of "3" should be appropriate for home or office refrigeration use.
 - Turning the temperature control knob to "0" position stops the cooling cycle but does not shut off the power to the unit.
 - NOTE:**
 - If the unit is unplugged, loses power, you must wait 3 to 5 minutes before restarting the unit. If you attempt to restart before this time delay, the refrigerator will not start.
 - Large amounts of food will lower the cooling efficiency of the appliance.
 - Do not place the foods on the air outlet, and leave spaces for airflow.
 - If you choose to change the thermostat setting, adjust thermostat control by one increment at a time. Allow several hours for temperature to stabilize between adjustments.

TROUBLESHOOTING GUIDE

You can solve many common refrigerator problems easily, saving you the cost of a possible service call. Try the suggestions below to see if you can solve the problem before calling for service.		
PROBLEM	POSSIBLE CAUSE	
Refrigerator does not operate.	Not plugged in. The circuit breaker tripped or a blown fuse.	
Compressor turns on and off frequently.	The room temperature is hotter than normal. A large amount of food has been added to the refrigerator. The door is opened too often. The door is not closed completely. The temperature control is not set correctly. The door gasket does not seal properly. The refrigerator does not have the correct clearance.	
Temperature inside the refrigerator is too warm.	The door gasket does not seal properly. The door is kept open too long or is opened too frequently. Warm air enters the refrigerator every time the door is opened. Open the door less often. The door is not closed completely. The door gasket does not seal properly. A large amount of warm or hot food might have been stored recently. Wait until the refrigerator has had a chance to reach its selected temperature. The refrigerator has recently been disconnected for a period of time. 4 hours are required for the refrigerator to cool down completely. Temperature control is set too warm. Turn the control to a cooler setting and allow several hours for the temperature to stabilize.	
Temperature inside the refrigerator is too cold.	The exterior refrigerator walls can be as much as 30°F warmer than room temperature. This is normal while the compressor works to transfer heat from inside the refrigerator cabinet. Metal parts undergo expansion and contraction, as in hot water pipes. This is normal. Sound will level off or disappear as refrigerator continues to cool.	
Temperature of external refrigerator surface is warm.	The exterior refrigerator walls can be as much as 30°F warmer than room temperature. This is normal while the compressor works to transfer heat from inside the refrigerator cabinet. Metal parts undergo expansion and contraction, as in hot water pipes. This is normal. Sound will level off or disappear as refrigerator continues to cool.	
Popping or cracking sound when compressor comes on.	Refrigerant (used to cool refrigerator) is circulating throughout the system. This is normal. Check to assure that the refrigerator is on a level surface.	
Bubbling or gurgling sound, like water boiling.	Floor is uneven or weak. Refrigerator rocks on the floor when it is moved slightly. Be sure floor can adequately support refrigerator. Level the	
Vibrations.		

NAMES OF THE PARTS

MODEL NO. BR401/SR401



WARNING

Never touch the interior of the Freezer Chamber or frozen foods in the compartment with wet hands as this could result in frost bite.

Ice Tray

- Recommended temperature control setting for ice making is "5".
- Fill the ice cube tray (23 capacity) with cold water and place the tray on the bottom of the crisper compartment to freeze properly.
- To select the ice cubes from the tray, place over the ice bucket and twist slightly.
- Re-set the temperature control to setting "5".

The Freezer Compartment

- This compartment is designed for the long-term storage of frozen food.
- The storage life of frozen foods varies and the recommended storage time should not be exceeded.
- Place frozen food into the freezer as quickly as possible after purchase. If there are instructions on the packet, carefully follow these instructions regarding storage times.

When To Defrost

This unit is not designed to defrost automatically. In order to prevent damage to the interior liner of the unit from excessive frost build-up, please manually defrost the unit every 3 months or when ice/ frost is approximately 1/4" thick inside the freezer compartment.

How To Defrost

Defrost the freezer compartment when the ice / frost are approximately 1/4" thick or every 3 months, whichever comes first. Set the thermostat dial to "0" to defrost. Remove all contents from the freezer compartment. Leave the freezer door open to allow accumulated ice / frost to melt. Remove large pieces of ice as needed. Do not use hot water or other electric heating devices to melt the accumulated ice. After defrosting, remove accumulated ice / water and wipe the freezer compartment dry with a soft cloth. In the event that the ice is not visibly present in the freezer compartment, please allow the evaporator located behind the freezer wall to completely defrost for approximately 2 hours before restarting the unit. Restart the unit per starting instructions.

How To Change the interior light

NOTE: All parts removed must be saved to do the reinstallation of the light bulb. Before removing the light bulb, unplug the appliance from the power supply. Failure to do so could result in electrical shock or personal injury.

- Remove the lamp cover by unscrewing.
- Unscrew the bulb from the base hole at the thermostat control box.
- Replace the new bulb of the same voltage and screw size.
- Re-install the lamp cover by screwing.

Moisture forms on inside refrigerator walls.	refrigerator by pulling wood or metal stems under part of the refrigerator. The refrigerator is touching the wall. Re-level the refrigerator and move it from the wall. See "Installation Instructions" Weather is hot and humid, which increases internal rate of frost build-up. This is normal. Door is slightly open. Door is kept open too long or is opened too frequently. Open the door less often. The door is not sealed properly. Door is slightly open, allowing cold air from inside the refrigerator to meet warm moist air from outside. The refrigerator is not on a level surface. The gasket is dirty.
Moisture forms on outside of refrigerator.	
The door will not close properly.	

IMPORTANT SAFETY INSTRUCTIONS


WARNING To reduce the risk of fire, electrical shock, or injury follow these basic precautions when using your refrigerator.

- WARNING**—Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- WARNING**—Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- WARNING**—Do not damage the refrigerant tubing to increase the risk of a leak when handle, move and use of refrigerator.
- WARNING**—Do not use electrical appliances inside the food storage compartments of the appliances, unless they are of the type recommended by the manufacturer.
- WARNING—DANGER:** Never allow children to play with, operate, or crawl inside the refrigerator. Risk of child entrapment. Before you throw away your old refrigerator or freezer:
 - Take off the doors.
 - Leave the shelves in place so that children may not easily climb inside.
- The appliance has to be unplugged before carrying out user maintenance on the appliance.
- This appliance can be used by children age 8 years and above and persons with reduced physical sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children should not play with the appliance. Cleaning and maintenance should not be made by children without supervision.
- If the component part is damaged, it must be replaced by the manufacturer, its service agent or similar qualified persons in order to avoid a hazard.
- Phase abandon the refrigerator according to local regulations as the unit contains flammable blowing gas and refrigerant.
- Follow local regulations regarding disposal of the appliance due to flammable refrigerant and blowing gas. All refrigeration products contain refrigerants, which under the guidelines of federal law must be removed before disposal. It is the consumer's responsibility to comply with federal and local regulations when disposing of this product.
- This appliance is intended to be used in household and similar environments, such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses and by clubs in hotels, motels and other residential type environments;
 - bed and breakfast type environments;
 - catering and non-retail applications.
- Do not store or use gasoline or any inflammable liquors and liquids inside or in the vicinity of refrigerator.
- Do not use an extension cord with this appliance. If the power cord is too short, have a qualified electrician install an outlet near the appliance. Use of an extension can negatively affect the unit's performance.



CHANGING THE REVERSIBLE DOOR

CAUTION: To avoid personal injury to yourself and/or property, we recommend someone assist you during the door reversal process.



Your refrigerator is built with a reversible door. You have the choice of either opening it from the left or the right side. In order to reserve the opening direction of your door, please follow these simple instructions:

- Disassemble all the reversible components in the sequence as shown below (also refer to left diagram above). Be sure to keep them well for later use in the process of reassembling:
 - leveling leg II
 - bottom hinge
 - leveling leg I
 - top hinge
 - bottom door buffer block
 - 2 screws to hold top hinge
 - Door hinge cover
 - Plug
 - 2 screws to hold mid hinge
 - upper door right stopper
 - 100 door hinge section
 - 111 top hinge
 - 122 2 screws to hold top hinge
 - 133 door hinge cover
 - 144 Plug
 - 155 upper door left stopper
- To access the bottom hinge assembly, you may fit back the refrigerator cabinet or lay the refrigerator on its back.
- Remove the upper door right stopper (9), install the upper door left stopper (15) on the opposite side, take down the bottom door buffer block (4), and install it on the opposite side.
- Reassemble the unit with the door hinges on the opposite side (see the right diagram above). The sequence for reassembling is just in reverse order of disassembling.
- With the mid hinge not being fastened too tight, adjust the door hinges and the cabinet and then fasten the mid hinge. If necessary, loosen the bottom hinge and the top hinge when aligning and then fasten them tight.

Made in China

