


INSTALLATION



Product Manual

Version: 200213-00-24A-SY




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.





AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer—could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !


It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.




Please prepare the following tools




When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 57



Ø 6 x 35 mm

B x 65



Ø 15 x 10 mm

C x 48




Ø 8 x 30 mm

D x 16




Ø 3 x 12 mm

E x 10




Ø 4 x 30 mm

F x 7




Ø 4 x 40 mm

G x 2




Ø 4 x 12 mm

H x 2




Ø 6 x 40 mm

I x 8




Ø 6 x 30 mm

J x 4



Ø 6 x 70 mm


K x 1



L x 2




M x 4




Ø 4 x 20 mm

N x 4



O x 4





Ø 6 x 64 mm

P x 3



Ø 8 x 40 mm




⚠ WARNING




Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.
Do not remove!*






1




Fix board 17, 19 and 18 to board 16 with screw(E) as shown.








2

Insert bottom board 20 along grooves as shown.



x2

3



x2





Insert quickfit screw(A) into board 15 with a screwdriver as shown.
Fix handle(L) with screw(M) as shown.

4

B x 10



Ø 15 x 10 mm



Attach board 15 to the component,
add cam lock(B) into board 17,19,18
and turn clockwise to tighten as shown.

x2


5

D x 8




Ø 3 x 12 mm

N x 4





Separate glide into two parts at first.(Page 5)
Fix runner(N) to board 17 and 18 with screw(D)
as shown.




x2

6




Fix slide rail(N) to board 4 with screw(D) as shown.

Flip the board 180°, and fix another slide rail(N) as well.




7





Fix board 4 with board 12 using screw(F) as shown.

Fix board 13 with board 4 using screw(F) as shown.







8




Fix slide rail(N) to board 10 with screw(D) as shown.

Insert quickfit screw(A) into board 10 with a screwdriver as shown.






9




Insert wooden dowel(C) into board 13 at first.

Connect board 12 and 13 with board 10 together, add cam lock(B) into board 12,13 and turn clockwise to tighten as shown.







10

A x 2



Ø6 x 35 mm



Insert quickfit screw(A) into board 14 with a screwdriver as shown.

11

B x 2



Ø15 x 10 mm

C x 2





Ø8 x 30 mm





Insert wooden dowel(C) into board 3 at first.


Connect board 3 with board 14, add cam lock(B) into board 3 and turn clockwise to tighten as shown.




12




Insert wooden dowel(C) into board 14 at first.
Connect board 14 with board 10, add cam lock(B) into board 14 and turn clockwise to tighten as shown.



13




Insert wooden dowel(C) into board 3 and 10 at first.
Fix board 2 with board 3 and 10 using screw(F) as shown.




14




Insert back board 21 along grooves as shown.



15




Insert quickfit screw(A) into board 11 at first. Flip the board 180°, insert quickfit screw(A) and fix slide rail(N) with screw(D) as shown.








16

B x 7




C x 5





Insert wooden dowel(C) into board 13, 14 and 2 at first.
Attach board 11 to the component,
add cam lock(B) into board 12,13,14,
2 and turn clockwise to tighten as shown.

17

A x 12




Insert quickfit screw(A) into board 5 and 6 with a
screwdriver as shown.






18

A x 6



Ø6 x 35 mm



Insert quickfit screw(A) into board 9 with a screwdriver as shown.

x3

19

B x 6




Ø15 x 10 mm

C x 6







Ø8 x 30 mm




Insert wooden dowel(C) into board 9 at first. Attach board 8 to board 9, add cam lock(B) into board 8 and turn clockwise to tighten as shown.

Attach board 7 to board 9, add cam lock(B) into board 7 and turn clockwise to tighten as shown.



14/18



x2

20

B x 12




Ø15 x 10 mm

C x 18





Ø8 x 30 mm




Insert wooden dowel(C) into board 7, 8 and 9 at first.

Connect board 5 and 6 with board 7, 8 and 9, add cam lock(B) into board 7,8,9 and turn clockwise to tighten as shown.



21

B x 4



Ø15 x 10 mm



C x 4



Ø8 x 30 mm




Insert wooden dowel(C) into board 11 at first. Connect board 5 and 6 with board 11, add cam lock(B) into board 5,6 and turn clockwise to tighten as shown.



22




Fix part 22 and 23 to part 24 with screw(J) as shown.




23



Fix the steel component to the bottom with screw(I) as shown.
Fix the steel component to board 8 with screw(G) as shown.




24





Insert quickfit screw(O) and wooden dowel(P) into board 1 and 25 at first.

Connect board 1 with board 25, add cam lock(B) into board 1,25 and turn clockwise to tighten as shown.




Insert quickfit screw(A) into board 1 and 25 with a screwdriver as shown.

25




Insert wooden dowel(C) into board 5, 6, 12, 4 and 10 at first. Cover board 1 and 25 to the top, add cam lock(B) and turn clockwise to tighten as shown. Fix board 25 with steel part using screw(H) as shown.

26



Insert drawers.



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.

AFTER-SALES CONTACT



feedbackstation@163.com



(303)800-6387