


TV STAND

USER MANUAL



SAVE THESE INSTRUCTIONS FOR FUTURE USE

PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.







Before Installation


Important – Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions

	Diagram A Insert Cam Bolt into hole as shown in diagram A.
	Diagram B Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.
	Diagram C Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.
 Connect the panels together.	
 ARROW SIGN Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.	
 To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>	



Ax24



Bx24




Cx 28



M6x30

Dx 12



M4x40

Ex8




M4x30

Fx 16



M3x12

Gx 26



M4x12

Hx 12




M3x14

Ix 4




M4x16

Jx4



Kx 2



M4x35

Lx4



Mx4




Nx 1




Ox 2



Px1



Qx2




R x 4



M4x20

CRx2




300mm

CLx2




300mm

DRx2




300mm

DLx2




300mm







STEP 1






STEP 2




STEP 3




STEP 4



STEP 5




STEP 6







Dx12







Cx12







STEP 7






STEP 8




STEP 9




STEP 10




STEP 11




STEP 12




STEP 13



Ax8



Rx4




Jx2



Ex8






STEP 14




Bx8






STEP 15



STEP 16



STEP 17



STEP 18

