

# Contents

Safety information	4
What you need to know about the safety instructions	334
Important safety symbols	
Important safety precautions	5
Warnings	() 6- 8-
Cautions	-
Before installation	ç
Key installation requirements	9
Location considerations	9
Ducting requirements	12
Exhausting requirements	13
Electrical requirements	14
Installation	16
What's included	16
Step-by-step installation	18
Exhaust ducting guide	22
Changing the direction of the exhaust duct (optional)	23
Switching the door position	28
Before you start	33
Sort and load	33
Functional prerequisite	33
Operations	34
Feature panel	34
Simple steps to start	36
Cycle overview	37
Cycle guide	38
Special features	39

# Contents

Maintenance	41
Cleaning	41
Troubleshooting	42
Checkpoints	42
Information codes	.45
Specifications	46
Fabric care chart	46
Protecting the environment	47
Specification sheet	48
Cycle chart	49

# Safety information

Congratulations on your new Samsung dryer. This manual contains Important information on the installation, use and care of your appliance. Please take some time to read this manual to take full advantage of your dryer's many benefits and features.

### What you need to know about the safety instructions

Please read this manual thoroughly to ensure that you know how to safely and efficiently operate the extensive features and functions of your new appliance. Please store the manual in a safe location close to the appliance for future reference. Use this appliance only for its intended purpose as described in this instruction manual.

Warnings and Important Safety Instructions in this manual do not cover all possible conditions and situations that may occur. It is your responsibility to use common sense, caution and care when installing, maintaining and operating your dryer.

Because the following operating instructions cover various models, the characteristics of your dryer may differ slightly from those described in this manual and not all warning signs may be applicable. If you have any questions or concerns, contact your nearest service center or find help and information online at www.samsung.com.

### Important safety symbols

What the icons and signs in this user manual mean:



Hazards or unsafe practices that may result in severe personal injury, death and/or property damage.

### ! CAUTION

Hazards or unsafe practices that may result in personal injury and/or property damage.

# (B) NOTE

Indicates that a risk of personal injury or material damage exists.

These warning signs are here to prevent injury to yourself and others.

Please follow them explicitly.

After reading this manual, store it in a safe place for future reference.

Read all instructions before using the appliance.

As with any equipment that uses electricity and moving parts, potential hazards exist. To safely operate this appliance, familiarize yourself with its operation and exercise care when using it.

### **↑** WARNING

State of California Proposition 65 Warning (US only)
 This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

# **↑** WARNING - Risk of Fire

- · Clothes dryer installation must be performed by a qualified installer.
- Install the clothes dryer according to the manufacturer's instructions and local codes.
- Do not install a clothes dryer with flexible plastic venting materials. If flexible metal
  (foil type) duct is installed, it must be of a specific type identified by the appliance
  manufacturer as suitable for use with clothes dryers. Flexible venting materials are
  known to collapse, be easily crushed, and trap lint. These conditions will obstruct
  clothes dryer airflow and increase the risk of fire.
- To reduce the risk of severe injury or death, follow all installation instructions.
- Save these instructions.

### Important safety precautions

### / WARNING

To reduce the risk of fire, electric shock, or injury to persons when using your appliance, follow basic precautions, including the following:

- 1. Read all instructions before using this appliance.
- Do not dry articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances, as they give off vapors that could ignite or explode.
- 3. Do not use the dryer to dry clothes which have traces of any flammable substance, such as vegetable oil, cooking oil, machine oil, flammable chemicals, paint thinner, etc., or anything containing wax or chemicals, such as mops and cleaning cloths. Flammable substances may cause the fabric to catch fire by itself.
- Do not store or use gasoline or other flammable vapors and liquids near this or any other appliance.
- Do not allow children to play on or in the appliance. Close supervision of children is necessary when the appliance is used near children.

# Safety information

- Before the appliance is removed from service or discarded, remove the door to the drying compartment.
- 7. Do not reach into the appliance if the drum is moving.
- 8. Do not install or store this appliance where it will be exposed to the weather.
- 9. Do not tamper with internal controls.
- 10. Do not repair or replace any part of the appliance or attempt any service unless specifically recommended in the user-maintenance instructions or in published userrepair instructions that you understand and have the skills to carry out.
- Do not use fabric softeners or products to eliminate static unless recommended by the manufacturer of the fabric softener or product.
- 12. Clean the lint screen before or after each load.
- Do not use heat to dry articles containing foam rubber or similarly textured rubberlike materials.
- Keep area around the exhaust opening and adjacent surrounding areas free from the accumulation of lint, dust, and dirt.
- 15. The interior of the appliance and exhaust duct should be cleaned periodically by qualified service personnel.
- 16. Do not place items exposed to cooking oils in your dryer. Items contaminated with cooking oils may contribute to a chemical reaction that could cause a load to catch fire.
- This appliance must be grounded. See "Electrical requirements" and "Grounding" in "Installation" section.
- 18. Do not allow children to play on or in the appliance. Close supervision of children is necessary when the appliance is used near children.
- 19. Do not insert your hand under the dryer.
  - · This may result in injury.
- 20. Take care that children's fingers are not caught in the door when closing it.
  - This may result in injury.
- The Control board and inlet valve are intentionally not grounded and may present a risk of electric shock only during servicing.
  - Do not contact these parts while the appliance is energized.

# 

- Do not dry items that have been previously cleaned, washed, soaked, or spotted with gasoline, dry cleaning solvents, or other flammable or explosive substances. They emit vapors that could ignite or explode. Any material that has been in contact with a cleaning solvent or flammable liquids or solids should not be placed in the dryer until all traces of these flammable liquids or solids and their fumes have been removed. There are many highly flammable items used in homes, such as acetone, denatured alcohol, gasoline, kerosene, some liquid household cleaners, some spot removers, turpentine, waxes, and wax removers.
- Do not dry items containing foam rubber (may be labeled latex foam) or similarly textured rubber-like materials on a heat setting. Heated foam rubber materials can, under certain circumstances, ignite spontaneously.

### Warnings

# **⚠** WARNING

 Ensure pockets are free of small, irregularly shaped hard objects and foreign material, i.e. coins, knives, pins, etc. These objects could damage your dryer.

### Cautions

# **↑** CAUTION

- Do not allow children or pets to play on, in, or in front of the appliance. Close supervision is necessary when the appliance is used near children and pets.
- Before discarding or removing your dryer from service, remove the door to the drying compartment to prevent children or animals from becoming trapped inside.
- · Do not reach into the appliance when the drum is moving.
- · Do not install or store this appliance where it will be exposed to the weather.
- · Do not tamper with the controls.
- Do not repair, replace, or attempt to service any part of the appliance unless specifically instructed to in the user-repair instructions and you have the understanding and skills to carry out the procedure.

# Safety information

- · Do not use fabric softeners or products to eliminate static unless the softener or product is recommended for dryer use by the manufacturer of the fabric softener or
- Clean the lint screen before or after each load.
- Keep the area around the exhaust opening and surrounding areas free from lint, dust,
- . The interior of the dryer and exhaust duct should be cleaned periodically by qualified service personnel.
- This appliance must be properly grounded. Never plug the power cord into a receptacle. that is not grounded adequately or not in accordance with local and national codes. See the installation instructions for information about grounding this appliance.
- · Do not sit on top of the dryer.
- · Do not dry clothing with large buckles, buttons, or other heavy metal or solid objects.
- Install and use in accordance with the manufacturer's instructions.
- . Do not place items in your dryer that have been spotted or soaked with vegetable oil or cooking oil. Even after being washed, these items may contain significant amounts of these oils.
- Residual oil on clothing can ignite spontaneously. The potential for spontaneous combustion increases when items containing vegetable oil or cooking oil are exposed to heat. Heat sources such as your dryer can warm these items, allowing an oxidation reaction in the oil to occur. Oxidation creates heat. If this heat cannot escape, the items can become hot enough to catch fire. Piling, stacking, or storing these kinds of items may prevent heat from escaping and can create a fire hazard.
- All washed and unwashed fabrics that contain vegetable oil or cooking oil can be dangerous.
  - Washing these items in hot water with extra detergent will reduce, but not eliminate, the hazard. Always use the Cool Down cycle for these items to reduce their temperature. Never remove these items from the dryer hot or interrupt the drying cycle until the items have run through the Cool Down cycle. Never pile or stack these items when they are hot.

# Before installation

Read through the following instructions before installing the dryer, and keep this manual for future reference.

# **⚠** WARNING

The control board and inlet valve are intentionally not grounded and may present a risk of electric shock only during servicing.

Service personnel - Do not contact these parts while the appliance is energized.

### Key installation requirements

- A grounded electrical outlet.
- · A power cord for electric dryers (except in Canada).
- · An exhaust system made of rigid metal or flexible stiff-walled metal exhaust ducting.

### / WARNING

Remove the door from all discarded appliances to prevent a child from suffocating.

### Location considerations

- · Adequate clearances between the dryer and adjacent walls or other surfaces.
- Adequate air circulation for ventilation.
- · Away from water and weather.

### / WARNING


- · Make sure to exhaust the dryer outdoors to reduce the risk of fire.
- · Keep the dryer area clear of combustible materials, gasoline, and other flammable vapors and liquids.
- · Do not install other fuel-burning appliances around or in the same place as the dryer.

#### Alcove or closet installation

Minimum clearances between the dryer and adjacent walls or other surfaces are: 3" (76mm) in front, 17" (432 mm) on top, 0"(0mm) on either side, and 3" (76mm) in the back.

The closet front must have two unobstructed air openings for a combined minimum total area of 72 in2 (465 cm2) with 3" (7.6 cm) minimum clearance on the top and bottom. A louvered door with equivalent space clearance is acceptable.


# Before installation



### NOTE

When the exhaust duct is installed at the rear of the dryer, the rear must have at least 5.5 inch (140 mm) clearance.


Side by side installation



A <sup>+</sup>	1 in. (25 mm)	D	25.8 in. (655 mm)
В	23.6 in. (600 mm)	E	3 in. (76mm)
С	17 in. (432 mm)	F	3 in. (76mm)

<sup>\*</sup>Disregard this minimum clearance if the dryer is installed alone.

### Stacked installation (Model: SK-DH)



Α	3 in. (76 mm)	G	1 in. (25 mm)
В	48 in². (310 mm²)	Н	23.6 in. (600 mm)
С	24 in². (155 mm²)	I.	5.5 in. (140 mm)
D	3 in. (76 mm)	J	3 in.(76 mm)
Е	6 in. (152 mm)	К	26.6 in. (676 mm)
F	67 in. (1702 mm)	L	4.75 in. (120 mm)

# **⚠** WARNING

Samsung's washers and dryers can be stacked to maximize usable space.

You can purchase an optional stacking kit from your Samsung retailer.

# Before installation

### **Ducting requirements**

	Recommended  A" (10.2 cm)		Use only for short-run installation		
Weather hood type			2.5" (6.4 cm)		
No. of 90° elbows	Rigid	Metallic flexible*	Rigid	Metallic flexible*	
0	80 ft. (24.2 m)	40 ft. (12.2 m)	60 ft. (28.3 m)	30 ft. (9.1 m)	
1	60 ft. (28.3 m)	35 ft. (10.7 m)	45 ft. (13.7 m)	22 ft. (6.7 m)	
2	45 ft. (13.7 m)	25 ft. (7.6 m)	35 ft. (10.7 m)	17 ft. (5.2 m)	
3	35 ft. (10.7 m)	20 ft. (6.1 m)	25 ft. (7.6 m)	12 ft. (3.7 m)	



<sup>\*</sup> Use a 4-inch (10.2 cm) diameter rigid aluminum or galvanized steel duct.

### If you integrate the dryer's vent system with an existing exhaust system:

- · Make sure the exhaust system meets all applicable local, state, and national regulations.
- · Verify you are not using flexible plastic duct.
- · Make sure to check for and remove all lint buildup from inside the existing ducts.
- · Confirm the duct is not kinked or crushed.
- · Make sure the exhaust hood damper opens and closes freely.

#### Manometer measurements

The static pressure in any exhaust system must not exceed 0.83 inches of water column or be less than 0. Note that these values are measured with the dryer running with a manometer presented to the exhaust duct that connects to the dryer. The dryer tumbler must be empty and lint filter clean.

### **Exhausting requirements**

The dryer must not be exhausted into a chimney, a wall, a ceiling, an attic, a crawl space, or a concealed space of a building. Exhausting the dryer to the outside will prevent large amounts of lint and moisture from being blown into the room.

### In the United States and Canada

- All dryers must be exhausted to the outside.
- The required exhaust duct is 4 inches (10.2 cm) in diameter.
- See "Ducting requirements" in the "Installation" section for the maximum duct length and number of bends that can be used.
- The total length of flexible metal duct must not exceed 7' 10½" (2.4 m).
- Do not assemble the duct with screws or other fasteners that extend into the duct and can catch lint.
- For the United States only: Use only those foil-type flexible ducts, if any, specifically identified for use with the appliance by the manufacturer and that comply with the Outline for Clothes Dryer Transition Duct. Use Subject 2158A.
- For Canada only: Use only those foiltype flexible ducts, if any, specifically identified for use with the appliance by the manufacturer.

#### Outside the United States and Canada

· Refer to the local codes.

### **⚠** WARNING

- You must exhaust the dryer to the outside to reduce the risk of fire when you install the dryer in an alcove or closet.
- Do not use a plastic or non-metal flexible duct.
- If your existing ductwork is plastic, nonmetal, or combustible, replace it with metal.
- Use only a metal exhaust duct that is non-flammable to ensure containment of exhaust air, heat, and lint.

# Before installation

### **Electrical requirements**

The wiring diagram is located on the plate under the control panel or rear frame.

### / WARNING

- · Improperly connecting the equipment grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether your dryer is properly grounded. Do not modify the plug provided with your dryer - if it doesn't fit the outlet, have a proper outlet installed by a qualified electrician.
- To prevent unnecessary risk of fire. electrical shock, or personal injury, all wiring and grounding must be done in accordance with local codes, or in the absence of local codes, in accordance with the National Electrical Code, ANSI/ NFPA No. 70-Latest Revision (for the U.S.) or the Canadian Electrical Code CSA C22.1 - Latest Revisions and local codes and ordinances. It is your responsibility to provide adequate electrical service for your dryer.

#### Grounding

This dryer must be grounded. In the event of a malfunction or breakdown, the ground will reduce the risk of electrical shock by providing a path of least resistance for the electrical current.

### WARNING

· Your dryer has an optional cord with an equipment-grounding conductor and a grounding plug. This cord is sold separately.

- · The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.
- · Do not modify the plug provided with your dryer - if it doesn't fit the outlet, have a proper outlet installed by a qualified electrician.
- · If a power cord is not used and the electric dryer is to be permanently wired, the dryer must be connected to a permanently grounded metal wiring system, or an equipment grounding conductor must be run with the circuit conductors and connected to the equipment grounding terminal or lead on the dryer.

### **Electrical connections**

Before operating or testing, follow all grounding instructions in the "Grounding" section. An individual branch (or separate) circuit serving only your dryer is recommended.

Do not use an extension cord.

### U.S. only

Most U.S. dryers require a 120 / 240 volt, 60 Hz AC approved electrical service. Some require 120 / 208 volt, 60 Hz approved electrical service. The electric service requirements can be found on the data label located behind the door. A 30-ampere fuse or circuit breaker on both sides of the line is required.

- If a power cord is used, the cord should be plugged into a 30-ampere receptacle.
- The power cord is not provided with U.S. electric model dryers. This cord is sold separately.



### Risk of Electric Shock

When local codes allow, you can connect the dryer's electrical supply with a new power supply cord kit, marked for use with a dryer, that is U.L. listed and rated at a minimum of 120/240 volts, 30-amperes with three No. 10 copper wire conductors terminated with closed loop terminals, open-end spade lugs with turned up ends, or with tinned leads.

- Do not reuse a power supply cord from an old dryer. The power cord electric supply wiring must be supported at the dryer cabinet by a suitable UL-listed strain relief.
- Grounding through the neutral conductor is prohibited for (1) new branch-circuit installations, (2) mobile homes, (3) recreational vehicles, and (4) areas where local codes prohibit grounding through the neutral conductor. (Use a 4-prong plug for a 4 wire receptacle, NEMA type 14-30R.)

#### Canada Only

- A 120 / 240 volt, 60 Hz AC approved electrical service fused through a 30-ampere fuse or circuit breaker on both sides of the line is required.
- All Canadian models are shipped with the power cord attached. The power cord should be plugged into a 30-ampere receptacle.




In Canada, you may not convert a dryer to 208 volts.

This dryer must be installed by a qualified technician. The installer is responsible for connecting the dryer to the main power while observing the relevant safety regulations of your area.

### What's included

Make sure all the parts are included in the product package. If you have a problem with the dryer or the accessories, contact a local Samsung service center or the retailer.




### Dryer at a glance

9.5			
01 Top cover	02 Feature panel	03 Door	
04 Filter	05 Exhaust duct		

### Accessories & tools

### Provided accessories



# **⚠** WARNING

Packing materials can be dangerous to children. Keep all packing materials (plastic bags, polystyrene, etc.) out of children's reach.

### Step-by-step installation

Make sure you have a qualified technician install the dryer. Step by step installation instructions start below.

### STEP 1 Install the exhaust system


- 1. Select a location and move the dryer to the site. For easy access, we recommend you install the dryer in the same location as your washer.
- 2. To change the door direction, see "Switching the door position".
- 3. Install the exhaust system as instructed in the "Exhaust ducting guide" section.

- . To move the dryer easily, lay two of the carton cushions from the packaging on the floor. Tip the dryer on its side so it lies across both cushion-tops. Push the dryer so that it is near its final location, and then set the dryer upright.
- · Secure room around the dryer to facilitate ducting and wiring.

### STEP 2 Connect the electrical wiring

First, read through the "Electrical requirements" section, and then follow the instructions on this page or the next page. Instructions for a 3-wire system are on this page. Instructions for a 4-wire system are on the next page.

### For a 3-wire system




- A. Center silver-colored terminal block screw
- B. Neutral wire (white or center wire)
- C. Neutral grounding wire (white or green/ yellow)
- D. ¾" (1.9 cm) UL-listed strain relief
- E. External ground connector

- Loosen or remove the screws from the center terminal block.
- Connect the neutral wire (white or center wire) of the power cable to the center, silver-colored terminal screw of the terminal block. Tighten the screws.
- Connect the other wires to outer terminal block screws. Tighten the screws.
- Tighten the strain relief screws.
- Insert the terminal block cover into the rear panel of the dryer. Then, secure the cover with a hold-down screw.

# **⚠** CAUTION

- To convert from the 4-wire system to 3-wire system, connect the ground strap to the terminal block support to ground the dryer frame to the neutral conductor.
- Ring-type terminals are recommended.
   If using strap terminals, make sure they are tightened.

### For a 4-wire system



- A. Center silver-colored terminal block
- B. Neutral grounding wire (white or green/ yellow)
- C. ¾" (1.9 cm) UL-listed strain relief
- D. Neutral wire (white or center wire)
- E. External ground connector
- F. Green or bare copper wire of power cord

1. Remove the external ground connector's screw, and connect the ground wire (green or unwrapped) of the power cable to the screw.

### / CAUTION

- · To connect the ground wire to the neutral position without through contact A (cabinet ground), contact a technician. This is not user serviceable.
- · Ring-type terminals are recommended. If using strap terminals, make sure they are tightened.
- 2. Loosen or remove the screws from the center terminal block.
- 3. Connect the neutral wire (white or center wire) and ground wire (white) to the center, silver-colored terminal screw of the terminal block. Tighten the screw.
- 4. Connect the other wires to the outer terminal block screws. Tighten the screws.
- 5. Tighten the strain relief screws.
- Insert the tab of the terminal block cover into the rear panel of the dryer. Then, secure the cover with a holddown screw.

### / WARNING

- · All U.S. models are designed for a 3-wire system connection. The dryer frame is grounded to the neutral conductor at the terminal block. A 4-wire system connection is required for new or remodeled construction, mobile homes, or if local codes do not permit grounding through neutral. If you use the 4-wire system, you cannot ground the dryer frame to the neutral conductor at the terminal block.
- · Remove the terminal block cover plate.


- Insert the power cord with a UL-listed strain relief through the hole provided in the cabinet near the terminal block.
- · A strain relief must be used.
- · Do not loosen the nuts aiready installed on the terminal block. Be sure they are tight.
- Use a 3/8" (1 cm) deep well socket.

### STEP 3 Level the dryer

To ensure optimal performance, the dryer must be level.



 Using a level (A), check if the dryer is level side to side and then front to back. If the dryer is not level, adjust the leveling feet (B) at the bottom of the dryer. Then, check if the dryer is level again.



### ♠ NOTE

- To set the dryer to the same height as your washer, fully retract (A) the leveling feet by turning them counterclockwise, then loosen (B) the feet by turning them clockwise. Once the dryer is the same height as the washer, follow the directions above to level the dryer.
- Adjust the leveling feet only as much as necessary to level the dryer.
   Extending the leveling feet more than necessary can cause the dryer to vibrate.

### STEP 4 Final Check

When installation is complete, confirm that:

- · The dryer is plugged into an electrical outlet and grounded properly.
- · The exhaust ductwork is connected and the joints are taped.
- You have used rigid or stiff-walled flexible metal duct material, not plastic flexible duct.
- · The dryer is level and is sitting firmly on the floor.
- · The dryer starts, runs, heats, and shuts off properly.

### Exhaust ducting guide

#### Ducting

- 1. Make sure the dryer is installed properly so the air exhausts freely.
- Use 4-inch rigid metal ducts. Tape all joints including the dryer connection. Never use lint-trapping screws.
- 3. To facilitate the exhaust, keep the ducts as straight as possible.

#### Cleaning

Clean all old ducts before installing the dryer, and make sure the vent flap opens and closes freely. We recommend that you to clean the exhaust system annually or on a regular basis.

### **⚠** WARNING


- · To prevent fire, do not use plastic, thin-foil, or non-metal flexible ducts of any kind.
- · Do not use a poor exhaust system because it slows down the dryer's performance.
- · Do not use excessively long ducts that have multiple elbows.
- · Do not use crushed or clogged venting or ducts.

# Changing the direction of the exhaust duct (optional)


# **⚠** WARNING

Before performing this exhaust installation, disconnect the dryer from its electrical supply. Wear gloves to protect your hands and arms from sharp edges when working inside the cabinet.


### Side venting




 Detach the right (A) or left (B) side knockout as desired.




 Pull the duct out of the dryer, and then remove the screw (C) from the duct.
 Set screw (C) aside. You will need it in a later step.




Cut the duct as shown and keep the cut portion of the duct (D).



 Reconnect the cut portion of the duct (D), and then fasten it to the ramp on the appliance base with the screw (C) which you set aside in Step 2.




Connect a duct to an elbow, and then tape the duct and the elbow together with duct tape.



 Insert the duct with elbow (E) through the rear opening, and then connect it to the internal duct.

### **↑** CAUTION


Wire components in the dryer may interfere slightly with the duct. Do not pull or damage the electrical wires inside the dryer when inserting the duct.



Apply duct tape (F) on all joints as shown.

### **↑** CAUTION

All joints must be secured with duct tape, otherwise, they may separate and cause a safety hazard.




Cover the back opening with a cover plate (G).


### **⚠** WARNING

Never leave the back opening uncovered. It must be covered with a cover plate.


### **Bottom venting**




1. Detach the bottom knockout (A).




Pull the duct out of the dryer, and then remove the screw (B) from the duct. Set screw (B) aside. You will need it in a later step.



Cut the duct as shown and keep the cut portion of the duct (C).




 Reconnect the cut portion of the duct (C), and then fasten it to the ramp on the appliance base with the screw (B) which you set aside in Step 2.



- Insert the elbow (D) through the rear hole and connect it to the duct (C).
- **6.** Rotate the **elbow (D)** through the bottom opening.

# **⚠** CAUTION


Do not to pull or damage the electrical wires inside the dryer when inserting the duct.



Apply duct tape (E) on the joint as shown.

# **⚠** CAUTION

All joints must be secured with duct tape, otherwise, they may separate and cause a safety hazard.




**8.** Cover the back opening with a **cover** plate (F).

# **⚠** WARNING


Never leave the back opening uncovered. It must be covered with a cover plate.

# Switching the door position





To reverse the direction of the door, we recommend that you contact a qualified technician.

- 1. Unplug the power cord of the dryer.
- 2. Remove the two hinge screws from the door, and then remove the door by lifting it up slightly.




3. Remove the two screws on the opposite side of the door hinge.







Locate and remove the 9 screws from the door as shown.




5. Remove the door lever.




6. Remove the door frame.




7. Rotate the door glass 180°.



8. Reassemble the door frame and the door lever.




Move the location of the screws, used to fix the door hinge, as shown.




**10.** Remove the lever cover by pressing the hook on it.



Put the lever holder on the other side as shown.



12. Insert and tighten the two hinge screws.



**13.** Insert and tighten the two screws on the opposite side of the door hinge.

# Before you start


Here are a few things you should know before starting your dryer.

### Sort and load

- Put one wash load in the dryer at a time.
- Do not mix heavy and lightweight items together.
- To improve drying efficiency for one or two items, add a dry towel to the load.
- For best results, untangle items before inserting them into the dryer.
- Overloading reduces the tumbling action, resulting in uneven drying and wrinkling.
- Unless recommended on the care label, do not dry woolens or fiberglass items.
- · Avoid drying unwashed items.
- Do not dry items soiled with oil, alcohol, gasoline, etc.

### Functional prerequisite

### Lint filter



To prevent a risk of fire, make sure to clean the lint filter before or after every load.

- 1. Turn off the dryer.
- Open the door, and pull out the lint filter (A) from inside the tumbler.
- Remove the lint that has accumulated, and then clean the lint filter.
- Reinsert the lint filter, and then close the door.

### **↑** CAUTION


- Do not operate the dryer without the lint filter in place.
- Do not use a damaged or broken lint filter. This may reduce performance and/or cause fire.

# Operations

### **⚠** WARNING

To reduce the risk of fire, electric shock, or injury to persons, read the "Safety information" before operating this appliance.

### Feature panel



01 Cycle selector	orn the cycle selector to select a desired cycle. When a cycle is elected, the cycle indicator lights up.			
02 Digital graphic display	Displays all cycle information, including the cycle time, information code, operating status, and indicators.			
03 Dry Level	Press to adjust the dryness in the Sensor Dry cycles. The corresponding indicator turns on.  Larger or bulkier loads may require Very Dry or More Dry for complete dryness.  Less Dry is best suited for lightweight fabrics or for leaving some moisture in the clothing at the end of the cycle.  Damp Dry is designed to partially dry items. Use for items that lay flat or hang to dry.  NOTE  This option is not available with SANITIZE, WOOL, and ACTIVE			

	Tumble Dry Warm.     Extra Low: Provides the lowest heated drying temperature possible.  Press to adjust the drying time for the Manual Dry cycles. This		
05 Time	is not available with the Sensor Dry cycles because the dryer determines the drying time by sensing the current moisture level of the load.		
06 Wrinkle Prevent	Wrinkle Prevent provides approximately 180 minutes of intermittent tumbling in unheated air at the end of the cycle to reduce wrinkling. Press Wrinkle Prevent to activate this feature. The load is dry and can be removed at any time during the Wrinkle Prevent cycle.		
The Mixed Load Bell notifies you when the average dry I a load is damp dry (80% dried). This lets you take items t don't want fully dried or that dry quickly out of the drye while letting others continue to dry.  You can select this option in all Sensor Dry cycles except SANITIZE, WOOL, and ACTIVE WEAR. Available dry levels Normal Dry, More Dry, and Very Dry.			
08 My Cycle	Choose your favorite cycle including the cycle time, temperature and dry level. See "My Cycle Q" for details.		
09 Adjust Time	You can change the set time in the Manual Dry cycles. To change the cycle time, press <b>Adjust Time</b> until the desired time is displayed.		
10 Power	Press to turn on/turn off the dryer.		
11 Start/Pause	Press to start or stop operation.		

# ⑥ NOTE

Extremely tangled items finished by the washer may degrade the drying efficiency or cause the door to open. We recommend that you untangle the items before drying.

# **Operations**

### Indicators

땁	Drying in progress	. <u></u> Д.	Drum Light
23	Cooling in progress	M	Sound Off
T	Wrinkle Prevent in progress	٥	Child Lock
K	Cycle is complete	6	My Cycle
<b>=</b>	Filter Check	73	Mixed Load Bell

# Simple steps to start

- 1. Press Power to turn on the dryer.
- 2. Turn the Cycle Selector to select a cycle.
- Change the cycle settings (Dry Level, Temp., and Time) as necessary.
- Optionally, you can activate options available by pressing the relevant button (Adjust Time, Wrinkle Prevent and/or Mixed Load Bell).
- Press Start/Pause. The dryer indicator turns on with an estimated cycle time on the display.

### To change the cycle during operation

- 1. Press Start/Pause to stop operation.
- 2. Select a different cycle.
- Press Start/Pause again to start the new cycle.

#### Cycle overview

#### Sensor Dry

Sensor Dry cycles sense moisture in the load and stop the dryer when the load reaches the dryness level you have selected with Dry Level.

Cycle	Description
NORMAL	For most fabrics including cottons and linens.
HEAVY DUTY	For drying items made out of heavy fabrics, such as jeans, corduroys, or work clothes, with high temperature heat.
SANITIZE	Use to sanitize items by applying high-temperature heat to the fabric. This cycle can make items soft and reduce smells.
WOOL	For machine washable and tumble dryable wool only.
DELICATES	For heat-sensitive items at a low drying temperature.
ACTIVE WEAR	For exercise wear and outdoor wear such as sports jerseys, training pants, water-repellent jackets, and other performance clothing.  Thick fabrics like a zipper or velcro closure of a jacket, or training socks may not be completely dried.
PERM PRESS	Dry wrinkle-free cottons, synthetic fabrics, knits, and permanent press fabrics automatically.
TOWELS	For bath towels and similar items

#### Manual Dry

You can change the drying settings manually to your preference.

Cycle	Description
QUICK DRY	A quick drying cycle running for 30 minutes
TIME DRY	You can specify a cycle time in minutes.
AIR FLUFF	Tumbles the load in room temperature air.
WRINKLE RELEASE	The Wrinkle Release cycle will release wrinkles from items that are clean, dry, and only slightly wrinkled, such as clothes from a crowded closet, suitcase or items that have been in the dryer too long after the cycle has ended. Wrinkle Release can be used with any temperature selection.

## **Operations**

#### Cycle guide

The best way to dry items is to follow the instructions on the care label. If no drying instructions are provided, see the following table for reference.

Cycle	Description	
Bedspreads & Comforters	Follow the care label instructions or dry using NORMAL.  Make sure the item is thoroughly dry before using or storing.  May require repositioning in the drum to ensure even drying.	
Blankets	Use NORMAL and dry only one blanket at a time for best tumbling action.  Make sure blankets are is thoroughly dry before using or storing.	
Curtains & Draperies	Use PERM PRESS and the Medium temperature setting to help minimize wrinkling.  • Dry curtains and draperies in small loads for best results and remove as soon as possible after the cycle is complete.	
Cloth Diapers	Use NORMAL and the High temperature setting for soft, fluffy diapers.	
Down-filled Items (jackets, sleeping bags, comforters, etc.)	Use NORMAL and the Medium temperature setting.  Add a couple of dry towels to absorb moisture and shorten drying time.	
Foam Rubber (rug backs, stuffed toys, shoulder pads, etc.)	Do not dry on a heat setting. Use AIR FLUFF.  MARNING  Drying a rubber item with heat may damage it or cause a fire.	
Pillows	Use NORMAL.  Add a couple of dry towels and a pair of clean sneakers to help the tumbling action and to fluff the pillows.  Do not dry kapok or foam pillows using a heated drying cycle. You can dry these items in the dryer only if you use AIR FLUFF.	
Plastics (shower curtains, outdoor furniture covers, etc.)	Use AIR FLUFF or TIME DRY and the Low or Extra Low temperature settings depending on the care label instructions.	

#### **⚠** WARNING

Do not dry:

- · Fiberglass items (curtains, draperies, etc.)
- · Woolens, unless recommended on the label
- · Items spotted or soaked with vegetable or cooking oils

#### Special features

#### Child Lock

Child Lock prevents children from playing with the dryer. When Child Lock is activated, all buttons except for the **Power** button are disabled.

To activate/deactivate Child Lock, simultaneously press and hold **Time** and **Wrinkle Prevent** for 3 seconds.



Once Child Lock is activated, it will remain active even after you restart the dryer. If other buttons, except for the **Power** button, do not respond, check the Child Lock indicator. If the indicator is on, follow the instructions above to turn Child Lock off.

#### Drum Light 🖧

To turn on the drum light while the dryer is running, press and hold **Dry Level** for 3 seconds.

#### NOTE

After 2 minutes of inactivity, the drum light automatically turns off.

#### Sound On/Off ⋈

To turn off the dryer's notification beeps and melodies, press and hold **Temp.** for 3 seconds.

To unmute the dryer, press and hold **Temp**. again for 3 seconds.

#### ♠ NOTE

This function remains active even after you restart the dryer.

#### My Cycle 🕝

You can create your own cycle that contains your preferred settings and use it at your convenience.

- Turn the Cycle Selector to select a cycle. The cycle indicator turns on.
- Set or change the settings (Dry Level, Temp., Time, etc) and/or options as necessary. Each corresponding indicator blinks.
- Press and hold My Cycle for 3 seconds. The dryer stores the selected cycle with its settings.

To use My Cycle, press My Cycle.

#### ♠ NOTE

Wrinkle Prevent is not available with My Cycle.

#### Smart Care

If the dryer displays an information code, you can use Smart Care to check the status of the dryer on a smartphone. To use Smart Care, you must have the Samsung Smart Care app installed on your smartphone.

#### NOTE

Smart Care is optimized for Samsung Galaxy and Apple iPhones. (Not compatible with some models).

Download the Samsung Smart Washer app from the Google Play Store or Apple App store (Search term: "Samsung Smart Washer/Dryer"), and install it on your smartphone.

## **Operations**

If an information code appears on the dryer, follow these steps:

- 1. Press and hold Mixed Load Bell for 3 seconds to activate Smart Care.
- 2. Open the Smart Care app on your smartphone.
- 3. Put the smartphone's camera close to the display of the dryer. The app automatically recognizes the information code, and displays suggestions on your smartphone.
- 4. If the smartphone fails to recognize the information code more than twice, type the information code manually into the Smart Care app.

#### **↑** CAUTION

- · If light is reflected on the display of the dryer, the smartphone may not recognize the information code.
- · If you hold the smartphone at an angle to the dryer's display, the smartphone may not recognize the information code. For best results, hold the smartphone so that the front of the panel and the smartphone are parallel or nearly parallel.
- · After you use this function, the dryer will delete the record of the information code from its code log.

## Maintenance

#### Maintenance

Keep the dryer clean to prevent decreased performance and to lengthen its life.

#### **↑** WARNING

The control board and inlet valve are intentionally not grounded and may present a risk of electric shock only during servicing.

Service personnel - Do not contact these parts while the dryer is energized.

#### Cleaning

#### Feature panel

- Clean with a soft, damp cloth. Do not use abrasive substances.
- Do not spray liquid cleaning agents directly on the display of the dryer.
- Some laundry pre-treatment soil and stain removers may damage the feature panel.
- When using liquid cleaning agents, apply them to the cleaning cloth. Do not apply them directly to the dryer. Wipe up any spills or overspray immediately.

#### Tumbler

- Remove any stains from the tumbler with an all-purpose cleaner.
- Tumble old towels or rags to remove any remaining stains or cleaning substances. Stains may still be visible, but will not affect subsequent loads.

#### Stainless steel tumbler

To clean the stainless steel tumbler, use a damp cloth with a mild, non-abrasive cleaner suitable for easily marred surfaces. Remove cleaner residue and dry with a clean cloth.

#### Dryer exterior

- Clean with a soft, damp cloth. Do not use abrasive substances.
- Protect the surface from sharp objects.

- Do not place any heavy or sharp objects or a detergent container on the dryer. They can scratch or damage the top cover of the dryer.
- The dryer has a high-gloss finish on the entire surface. Be careful not to scratch or damage the surface.

#### Exhaust system

- Check and clean the exhaust system on a yearly or regular basis to maintain optimum performance.
- The external exhaust hood must be cleaned more frequently to ensure proper air flow.

## Troubleshooting

#### Checkpoints

If the dryer operates abnormally, first check the list of problems in the table below and try the suggested actions.

Problem	Action
Does not run.	Make sure the door is latched shut.     Make sure the power cord is plugged into a live electrical outlet.     Check your home's circuit breakers or fuses.     Press or tap Start/Pause again if the door is opened during a cycle.     Clean the lint filter.
Does not heat.	Check your home's circuit breakers or fuses. Some cycles do not require heating. Check the selected cycle again. Clean the lint filter and exhaust duct. The dryer may have moved into the cool-down phase of the cycle.
Does not dry.	<ul> <li>Check all of the above, plus</li> <li>Make sure the exhaust hood outside your home can open and close freely.</li> <li>Check the exhaust system for lint buildup. Ducting should be inspected and cleaned annually.</li> <li>Use a 4" rigid metal exhaust duct.</li> <li>Do not overload. 1 wash load = 1 dryer load.</li> <li>Dry heavy items and light weight items separately.</li> <li>Large, bulky items, such as blankets or comforters, may require repositioning to ensure even drying.</li> <li>Make sure that your washer is draining properly and extracting adequate water from the load.</li> <li>The load may be too small to tumble properly. Add a few towels and restart the dryer.</li> <li>The load may be too large to tumble properly. Remove some items and restart the dryer.</li> <li>Clean the lint filter.</li> </ul>

4	
7	
3	
Ŧ.	
=	
ž	
÷	
5	
5	
•	
5	
2	

Problem	Action
Is noisy.	<ul> <li>Check the load for objects such as coins, loose buttons, nails, etc. Remove promptly.</li> <li>Make sure the dryer is leveled properly as outlined in the installation instructions.</li> <li>It is normal for the dryer to hum due to the high velocity of air moving through the dryer drum, fan, or exhaust system.</li> </ul>
Dries unevenly.	Seams, pockets, and other similarly heavy areas may not be completely dry when the rest of the load has reached the selected dryness level. This is normal. You can choose a higher dryness level or a cycle that involves a higher dryness level.  If one heavy item is dried with a light weight load, such as one towel with sheets, it is possible that the heavy item will not be completely dry when the rest of the load has reached the selected dryness level.  For the best drying results, dry heavy items and light weight items separately.
Has odors.	<ul> <li>Household odors from paint, varnish, strong cleaners, etc. may enter the dryer with the surrounding room air. This is normal as the dryer draws the air from the room, heats it, pulls it through the tumbler, and exhausts it outside.</li> <li>When these odors linger in the air, completely ventilate the room before using the dryer.</li> <li>If odors persist, wash and dry the items again.</li> </ul>
Lint on clothes.	Make sure the lint filter is cleaned before every load. For clothes that naturally build up lint, clean the filter during the cycle.     Some fabrics are lint producers (for example, a fuzzy white cotton towel) and they must be dried separately from clothes that are lint trappers (for example, a pair of black linen pants).     Divide larger loads into smaller loads for drying.     Check pockets thoroughly before drying, then dry clothes.     Remove lint inside the drum before drying.
Items still wrinkled after WRINKLE RELEASE.	Small loads of 1 to 4 items work best.     Load fewer items. Load similar-type items.

## Troubleshooting

Problem	Action	
Extended time.	Sensor Dry automatically senses the moisture in the load and shuts the dryer off when the selected dryness level is reached.  The drying time can change according to the type and amount of laundry. See the cycle chart for reference.	

If a problem persists, contact a local Samsung service center.

# Troubleshooting

#### Information codes

If the dryer fails to operate, you may see an information code on the display panel. To determine what you should do, check the list of codes in the table below, and then try the suggested actions.

Code	Action
dC	Operating the dryer with the door open.  Make sure the door is properly closed.  Make sure laundry is not caught in the door.
FC	Invalid power source frequency Try restarting the cycle. If this information code remains, contact a Samsung service center.
AC	Electronic control problem (Invalid Communication).  Contact a Samsung service center.
нс	Invalid heating temperature when dryer is running.  • Contact a Samsung service center.
9C1	The electronic control needs to be checked.  Check if power is supplied properly.  If the information code remains, contact a Samsung service center.
tC	The thermistor resistance is very low or high.  Check for a clogged lint screen  Check if the vent system is restricted.  If this information code remains, contact a Samsung service center.
bC2	Invalid state of a button.  Check if a button is stuck.  If this information code remains, contact a Samsung service center.
dF	Incorrect door switch.  • Contact a Samsung service center.

If any information code keeps appearing on the screen, contact a Samsung service center.

## **Specifications**

#### Fabric care chart

The following symbols provide garment care direction. The clothing care labels include symbols for drying, bleaching, ironing, and dry cleaning. The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow care label directions to optimize garment life and reduce laundering problems.

#### Wash cycle

	Normal
	Permanent press/Wrinkle resistant/Wrinkle control
	Gentle/Delicates
3	Hand wash

#### Water temperature

	Hot	
	Warm	
1741	Cold	

#### NOTE

The Water Temperature table lists appropriate wash water temperatures for various items. The temperature range is 106 - 126 °F (41 - 52 °C) for Hot, 84 - 106 °F (29 - 41 °C) for Warm, and 61 - 84 °F (16 - 29 °C) for Cold. (Wash water temperature must be a minimum of 61 °F (16 °C) for detergent activation and effective cleaning.)

#### Bleach

0	Any bleach (when needed)
	Only non-chlorine (color-safe) bleach (when needed)
	Tumble dry

#### Normal

Permanent press/Wrinkle resistant/Wrinkle control
Gentle/Delicates

#### Special instructions

	Line dry/Hang to dry
III	Drip dry
	Dry flat

#### Heat setting

0	Hìgh	
0	Medium	
0	Low	
0	Any heat	
•	No heat / Air	

#### Iron dry or steam temperatures

<b>a</b>	High		
<b>a</b>	Medium		
<u>a</u>	Low		

#### Warning symbols for laundering

容	Do not wash	
<b>)</b> 86	Do not wring	
*	Do not bleach	
**	Do not tumble dry	
<b></b>	No steam (added to iron)	
2	Do not iron	

#### Dry-clean


0	Dry-clean
**	Do not dry-clean
	Line dry / Hang to dry
III	Drip dry
<b>=</b>	Dry flat

#### Protecting the environment

This appliance is manufactured from recyclable materials. If you decide to dispose of this appliance, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance.

## Specifications

#### Specification sheet



Туре		Front loading dryer
	A. Height	33.5" (850 mm)
	B. Width	23.6" (600 mm)
Dimensions	C. Depth	25.8" (655 mm)
	D. Depth with door open 90°	44.2" (1123 mm)
Net Weight		89.1 lb (40.4 kg)
Heater rating		2200 W (elec.)

#### NOTE

For best results, follow the load size recommendations for each dry cycle.

- Large load: Fill the drum to about ¾ full. Do not add items over this level as they
  need to tumble freely.
- Medium load: Fill the drum to about ½ full.
- Small load : Fill the drum with 3-5 items, not more than ¼ full.

Cycle		Recommended items	Load size	Dry Level
	NORMAL	Cottons, Work clothes, Linea, Mixed loads	•	Normal Dry (Adjustable
	HEAVY DUTY	Heavy fabrics such as jean, Corduroys, Heavy work clothes		Normal Dry (Adjustable
	SANITIZE	Bedding, Curtains, Children's clothing	-	Very Dry (No Change
Sensor Dry	WOOL	For machine washable and tumble dryable wool only (Maximum amount : 3lb)	0	Normal Dry (No change
	DELICATES	Underwear, Blouses, Lingerie	0	Normal Dry (Adjustable
	ACTIVE WEAR	Water-repellent wear, performance clothes, Sports wear	-	Normal Dry (No change
	TOWELS	Bath towels and similar items		Normal Dry (Adjustable
	PERM PRESS	Shirts, Synthetic fabrics, Knits, Wrinkle-free cottons, Permanent	-	Normal Dry (Adjustable
Manual Dry	QUICK DRY	Small loads	0	, Ed
	TIME DRY	Any load		£9
	AIR FLUFF	Foam, rubber, plastic	0	20
	WRINKLE RELEASE	Shirts, Trouser, Blouses	0	į ±1

Specifications

## Specifications

#### ■ NOTE

• e: factory setting, e: can be selected

			Temperature setting				**
Cycle		High	Medium	Med Low	Low	Extra Low	Time setting
	NORMAL	3	•	2 9	*	12	
	HEAVY DUTY	•	9		121	1 12	1/53
	SANITIZE	•	3		*	1 12	100
Sensor Dry	WOOL	=	3	# # 17	•	T is	1/53
	DELICATES	2	3	# # 6		•	1/63
	ACTIVE WEAR	*	3	== 1	•	12	1,5
	TOWELS	•	3	== 1	*	12	1/6
	PERM PRESS	=	•	# # 1	121	12	1/63
Manual Dry	QUICK DRY		8	== **	*	1 12	
	TIME DRY		0		0	0	.0
	AIR FLUFF	*	3	#1 7	181	1 34	.0
	WRINKLE RELEASE	121	3		0		0

Cycle		Mixed Load Bell	Wrinkle Prevent	Adjust Time	
	NORMAL	0	0		
	HEAVY DUTY	0	0	8	
	SANITIZE	50	0	- 8	
Sensor Dry	WOOL	56	0	8	
sensor bry	DELICATES	0	0	3	
	ACTIVE WEAR	- 50	0	8	
	TOWELS	0	0	8	
	PERM PRESS	0	0	8	
Manual Dry	QUICK DRY		0	0	
	TIME DRY	50	0	0	
	AIR FLUFF	50	0	0	
	WRINKLE RELEASE	50	0	0	

## Warranty (U.S.A)

#### SAMSUNG DRYER

#### LIMITED WARRANTY TO ORIGINAL PURCHASER

This SAMSUNG brand product, as supplied and distributed by SAMSUNG ELECTRONICS AMERICA, INC. (SAMSUNG) and delivered new, in the original carton to the original consumer purchaser, is warranted by SAMSUNG against manufacturing defects in materials and workmanship for a limited warranty period of:

· One (1) Year All Parts and Labor

This limited warranty begins on the original date of purchase, and is valid only on products purchased and used in the United States.

To receive warranty service, the purchaser must contact SAMSUNG for problem determination and service procedures.

Warranty service can only be performed by a SAMSUNG authorized service center.

The original dated bill of sale must be presented upon request as proof of purchase to SAMSUNG or SAMSUNG's authorized service center.

SAMSUNG will provide in-home service during the warranty period at no charge, subject to availability within the contiguous United States.

In-home service is not available in all areas.

To receive in-home service, product must be unobstructed and accessible to the service agent.

If service is not available, SAMSUNG may elect to provide transportation of the product to and from an authorized service center.

SAMSUNG will repair, replace, or refund this product at our option and at no charge as stipulated herein, with new or reconditioned parts or products if found to be defective during the limited warranty period specified above.

All replaced parts and products become the property of SAMSUNG and must be returned to SAMSUNG.

Replacement parts and products assume the remaining original warranty, or ninety (90) days, whichever is longer.

## Warranty (U.S.A)

This limited warranty covers manufacturing defects in materials and workmanship encountered in normal, noncommercial use of this product and shall not apply to the following: damage that occurs in shipment; delivery and installation; applications and uses for which this product was not intended; altered product or serial numbers; cosmetic damage or exterior finish; accidents, abuse, neglect, fire, water, lightning, or other acts of nature or God; use of products, equipment, systems, utilities, services, parts, supplies, accessories, applications, installations, repairs, external wiring or connectors not supplied or authorized by SAMSUNG that damage this product or result in service problems; incorrect electrical line voltage, fluctuations and surges; customer adjustments and failure to follow operating instructions, maintenance and environmental instructions that are covered and prescribed in the instruction book; product removal and reinstallation; problems caused by pest infestations.

This limited warranty does not cover problems resulting from incorrect electric current, voltage or supply, light bulbs, house fuses, house wiring, cost of a service call for instructions, or fixing installation errors.

SAMSUNG does not warrant uninterrupted or error-free operation of the product.

EXCEPT AS SET FORTH HEREIN, THERE ARE NO WARRANTIES ON THIS PRODUCT EITHER EXPRESS OR IMPLIED, AND SAMSUNG DISCLAIMS ALL WARRANTIES INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE.

NO WARRANTY OR GUARANTEE GIVEN BY ANY PERSON, FIRM, OR CORPORATION WITH RESPECT TO THIS PRODUCT SHALL BE BINDING ON SAMSUNG.

SAMSUNG SHALL NOT BE LIABLE FOR LOSS OF REVENUE OR PROFITS, FAILURE TO REALIZE SAVINGS OR OTHER BENEFITS, OR ANY OTHER SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY THE USE, MISUSE, OR INABILITY TO USE THIS PRODUCT, REGARDLESS OF THE LEGAL THEORY ON WHICH THE CLAIM IS BASED, AND EVEN IF SAMSUNG HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. NOR SHALL RECOVERY OF ANY KIND AGAINST SAMSUNG BE GREATER IN AMOUNT THAN THE PURCHASE PRICE OF THE PRODUCT SOLD BY SAMSUNG AND CAUSING THE ALLEGED DAMAGE.

WITHOUT LIMITING THE FOREGOING, PURCHASER ASSUMES ALL RISK AND LIABILITY FOR LOSS, DAMAGE, OR INJURY TO PURCHASER AND PURCHASER'S PROPERTY AND TO OTHERS AND THEIR PROPERTY ARISING OUT OF THE USE, MISUSE, OR INABILITY TO USE THIS PRODUCT.

THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THIS PRODUCT, IS NONTRANSFERABLE AND STATES YOUR EXCLUSIVE REMEDY.

Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.

To obtain warranty service, please contact SAMSUNG at: Samsung Electronics America, Inc. 85 Challenger Road Ridgefield Park, NJ 07660 1-800-SAMSUNG (726-7864) www.samsung.com/us/support

Visits by a Service Engineer to explain functions, maintenance or installation is not covered by warranty.

Please contact your Samsung call agent for help with any of these issues.

## Warranty (CANADA)

#### SAMSUNG DRYER

#### LIMITED WARRANTY TO ORIGINAL PURCHASER

This SAMSUNG brand product, as supplied and distributed by SAMSUNG ELECTRONICS CANADA, INC. (SAMSUNG) and delivered new, in the original carton to the original consumer purchaser, is warranted by SAMSUNG against manufacturing defects in materials and workmanship for a limited warranty period of:

· One (1) year part and labor

This limited warranty begins on the original date of purchase, and is valid only on products purchased and used in the Canada.

To receive warranty service, the purchaser must contact SAMSUNG for problem determination and service procedures.

Warranty service can only be performed by a SAMSUNG authorized service center.

The original dated bill of sale must be presented upon request as proof of purchase to SAMSUNG or SAMSUNG's authorized service center.

SAMSUNG will provide in-home service during the warranty period at no charge, subject to availability within the Canada.

In-home service is not available in all areas.

To receive in-home service, product must be unobstructed and accessible to the service

If service is not available, SAMSUNG may elect to provide transportation of the product to and from an authorized service center.

SAMSUNG will repair, replace, or refund this product at our option and at no charge as stipulated herein, with new or reconditioned parts or products if found to be defective during the limited warranty period specified above.

All replaced parts and products become the property of SAMSUNG and must be returned to SAMSUNG.

Replacement parts and products assume the remaining original warranty, or ninety (90) days, whichever is longer.

This limited warranty covers manufacturing defects in materials and workmanship encountered in normal, noncommercial use of this product and shall not apply to the following: damage that occurs in shipment; delivery and installation; applications and uses for which this product was not intended; altered product or serial numbers; cosmetic damage or exterior finish; accidents, abuse, neglect, fire, water, lightning, or other acts of nature or God; use of products, equipment, systems, utilities, services, parts, supplies, accessories, applications, installations, repairs, external wiring or connectors not supplied or authorized by SAMSUNG that damage this product or result in service problems; incorrect electrical line voltage, fluctuations and surges; customer adjustments and failure to follow operating instructions, maintenance and environmental instructions that are covered and prescribed in the instruction book; product removal and reinstallation; problems caused by pest infestations.

This limited warranty does not cover problems resulting from incorrect electric current, voltage or supply, light bulbs, house fuses, house wiring, cost of a service call for instructions, or fixing installation errors.

SAMSUNG does not warrant uninterrupted or error-free operation of the product.

EXCEPT AS SET FORTH HEREIN, THERE ARE NO WARRANTIES ON THIS PRODUCT EITHER EXPRESS OR IMPLIED, AND SAMSUNG DISCLAIMS ALL WARRANTIES INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE.

NO WARRANTY OR GUARANTEE GIVEN BY ANY PERSON, FIRM, OR CORPORATION WITH RESPECT TO THIS PRODUCT SHALL BE BINDING ON SAMSUNG.

SAMSUNG SHALL NOT BE LIABLE FOR LOSS OF REVENUE OR PROFITS, FAILURE TO REALIZE SAVINGS OR OTHER BENEFITS, OR ANY OTHER SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY THE USE, MISUSE, OR INABILITY TO USE THIS PRODUCT, REGARDLESS OF THE LEGAL THEORY ON WHICH THE CLAIM IS BASED, AND EVEN IF SAMSUNG HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. NOR SHALL RECOVERY OF ANY KIND AGAINST SAMSUNG BE GREATER IN AMOUNT THAN THE PURCHASE PRICE OF THE PRODUCT SOLD BY SAMSUNG AND CAUSING THE ALLEGED DAMAGE.

WITHOUT LIMITING THE FOREGOING, PURCHASER ASSUMES ALL RISK AND LIABILITY FOR LOSS, DAMAGE, OR INJURY TO PURCHASER AND PURCHASER'S PROPERTY AND TO OTHERS AND THEIR PROPERTY ARISING OUT OF THE USE, MISUSE, OR INABILITY TO USE THIS PRODUCT.

THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THIS PRODUCT, IS NONTRANSFERABLE AND STATES YOUR EXCLUSIVE REMEDY.

## Warranty (CANADA)

Some provinces do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

This warranty gives you specific rights, and you may also have other rights, which vary from province to province.

To obtain warranty service, please contact SAMSUNG at:

Samsung Electronics Canada Inc.

2050 Derry Road West,

Mississauga, Ontario L5N 0B9 Canada

1-800-SAMSUNG (726-7864)

www.samsung.com/ca/support (English)

www.samsung.com/ca\_fr/support (French)

Visits by a Service Engineer to explain functions, maintenance or installation is not covered by warranty.

Please contact your Samsung call agent for help with any of these issues.

## Memo

## Memo

## Memo

#### SAMSUNG



Scan the QR code\* or visit www.samsung.com/spsn to view our helpful How-to Videos and Live Shows

Requires reader to be installed on your smartphone

an this with your smartphone

#### QUESTIONS OR COMMENTS?

COUNTRY	CALL	OR VISIT US ONLINE AT
U.S.A	1-800-SAMSUNG (726-7864) 1-844-SAM-PAYS (726-7297)	www.samsung.com/us/support
CANADA	1-800-SAMSUNG(726-7864)	www.samsung.com/ca/support (English) www.samsung.com/ca_fr/support (French)



DC68-03650A-01