

# **AC200P Portable Power Station**User Manual

## Contents

Saf	ety instructions	01
1.	Packing list	02
2.	Function introduction	.03
3.	Startup and shutdown operation	04
4.	How to use the user-friendly touch screen display	04
5.	The operation steps of user-friendly touch screen display	04
6.	Charging the product	07
7.	Discharging	.09
8.	Application scenario	.09
9.	Examples of loads	10
10.	Estimation of charging time	10
11.	Specification	11
12.	Storage and maintenance instructions	13
13.	Declaration	13
14.	Common faults and troubleshooting	13
15.	FAQ(Frequently Asked Questions)	14

## **Safety instructions**


Please observe the following instructions to ensure safe usage:

- 1. Do not alter or disassemble this product.
- 2. Do not move during charging or using it, because the vibration and impact during
- 3. moving will lead to poor contact of output interface.
- 4. In case of fire, use dry powder fire extinguishers for this product. Do not use water fire extinguisher, which may cause electric shock.
- 5. Close supervision is required when using this product near children.
- 6. Please confirm the rated specification of your load, and do not use it beyond the specification.
- 7. Do not place the product near heat sources, such as electric furnace and heaters.
- 8. Not permitted on aricrafts because the battery capacity exceeds 100Wh.
- 9. Do not touch the product or the plug-in points if your hands are wet.
- 10. Check the product and accessories prior to every use. Do not use if it is damaged or broken.
- 11. Please unplug the AC adapter from the wall outlet immediately in case of lightning stroke, which may cause heating, fire and other accidents.
- 12. Use original charger and cables.


## 1. Packing list

No.	Product	Quantity(pcs)	standard	option
1	Power Station	1	√	
2	AC adapter (including AC charging cable)	1	√	
3	MC4 Solar charging cable (MC4 to XT90)	1	√	
4	Car charging cable (car to XT90)	1	√	
5	XT90 to aviation plug (input)	1	√	
6	User manual	1	√	
7	Warranty card	1	√	
8	Certificate	1	√	
9	12V / 25A aviation plug to XT60 (output)			<b>√</b>
10	12V / 25A XT60 to spc45 (output)			√
11	12V / 24V lead acid battery charging cable			<b>√</b>
	XT90 to Red Black clamp (input)			
12	Connector for dual AC adapter (Female 7909			√
	to XT90)			

#### (1) Standard( accessories included)




## (2) Options( not included, buy separately from seller)



The picture is for reference only, take the object for standard.

#### 2. Function introduction



- 1. Power button
- 2. 12V / 10A cigarette lighter port
- 3. Type-C charging port
- 4. Touchable interaction LCD display
- 5. USB output x 4pcs
- US AC output x 6pcs
   (EU/UK AC output x 2 pcs)

- 7. 12V / 25A output
- 8. 12V / 3A output
- 9. PV / car input port
- 10. AC adapter input port
- 11. Wireless charging x 2pcs
- 12.

#### Note:

AC stands for alternating current.

DC stands for direct current.

PV stands for photovoltaic(solar charging).

Car stands for automobile electric energy.

#### 3. Startup and shutdown operation

- (1) Start up: short press the power button, the indicator light is on, and the machine is in standby mode.
- (2) Shutdown: press and hold the power button for more than 2 seconds, and the indicator light will be off and the machine shut off.

The LED indicator lamp status warning		
BMS Over current or short circuit	Turn off after the indicator light flashes	
protection		
BMS Startup timeout	The indicator light flashes and not shut down	
Normal startup	The indicator light on	
Normal shutdown	The indicator light off	

(3) DC power switch and AC power switch are integrated in the interaction LCD screen(Figure 1),press"DC ON/OFF"button and "AC ON/OFF"button on the screen to turn on/off the DC /AC output.

#### 4. How to use the touch screen


#### Interaction LCD screen(Information Vision) supports below functions:

- (1) Real time display of voltage, current, power, temperature and state of charge and discharge.
- (2) The user can adjust the output voltage, frequency, charging mode, power consumption mode and time information according to the setting column.
- (3) Support energy-saving, and enable Super ECO mode to save more than 30% of useless energy loss.
- (4) Support users to view fault information, historical fault information, software version independently.

## 5. The operation steps of touch screen

Warm tip: ●The touchable LCD screen is a resistance screen. we recommend to press the touch button by fingernail lightly until it "beeps".

- •In order to maximize the lifespan of the LCD screen, please avoid direct sunlight on it.
- (1) When press the power button, it will enter the main interface of the LCD display screen:



- a. Homepage button
- b. Settings button
- c. Data button
- d. Faults button
- e. PV/Car charging display button
- f. BMS information display button

- g. Date/Time
- h. DC load information display button
- i. DC ON/OFF button
- j. AC ON/OFF button
- k. Adapter charging display button
- I. AC load information display button
- (2) Click the settings button in the main interface (Figure 2) to enter the setting interface as follows (Figure 3):

**Warm tip:** Please enter the setting interface to set the date and time according to the local time zone, and check the output voltage, frequency and other parameters for the first time.

#### The default:

JP output: 100V/50Hz
US output: 120V/60Hz
EU output: 230V/50Hz
UK output: 230V/50Hz

DC Input Source: PV (solar)

ECO Mode: NO


Press "Next" button to enter language and date setting as below (Figure 3):

Language: Japanese, English

Date and time: 2000-00-00 \ 00: 00: 00

Please set the "Date and time" at least once every 2 weeks.

Press to configure it.



(Figure 2)




(Figure3)

- (3) Return to the main interface (Figure 1), click the "Data" button to enter the page (Figure 4):
- •Click the "Product Info" button, you can view the product model, control software version, monitoring software version, BMS monitoring software version and display software version in turn;
- •Click the "Inverter & Charger Info" button, you can view the PV / Car operation and the adapter operation status ,DC out operation and AC out operation in turn, which can also

be accessed directly from the shortcut key on the main interface;

- •Click the "BMS Maintenance" button, you can view the operation information of BMS, and this part can also be accessed directly from the shortcut key in the main interface;
- •Click the "Fault History" button, you can view all the fault information generated by the machine. All the fault codes recorded here. According to the fault codes, return to the main interface and click the fault button to view the corresponding fault information. Fault History is retained up to 10 years if not manually cleared.



(Figure4)

(4) Return to the main interface and click the fault button (Figure 1) to view the current fault information: the fault button will display orange if there is a fault, click to enter the corresponding fault information, then the gray light will turn into orange.


## 6. Charging the product

#### There are five ways to charge:


- (1) Charging mode 1: From AC Wall outlet
- Press the main power button to start charging after connecting the product to the AC wall outlet, the charging will automatically stop when it reaches 100%.




- (2) Charging mode 2: From the solar panels
- Choose the solar panel with working voltage DC 35V-150V.
- •Connect the solar panel to the product via solar charging cable included.
- •Plug and play charging: it will start charging automatically after connecting the solar panel to the product even it is off status.
- Max. current of the solar is 12A.




- (3) Charging mode 3: From the car lighter port
- •Press the power button and connect it to the cigarette lighter port through the car charging cable.
- •Enter the setting interface as shown in (Figure 2) through the display screen to set DC input source to car mode; The product can be charged with 8.2A maximum current.



- (4) Charging Mode 4: From a generator (gasoline, propane or diesel)
- •Connect the AC adapter input to the generator and the output port to the AC charging port of the machine.
- •Press the power button, the product will be charged, the charging will automatically stop when it reaches 100%.



- (5) Charging mode 5: from lead acid battery
- •Connect to the positive and negative poles of the battery through the provided solar charging cable(pay attention to distinguish the positive and negative poles of the battery, the red head is the positive pole, and the black head is the negative pole).
- •Enter the setting interface as shown in (Figure 2) through the display screen to set DC input source to "car mode". The product can be used for car charging mode, with the maximum current of 8.2A. The product has the function of anti over discharge for lead-acid battery.



## 7. Discharging

- (1) Turn on 12V / 25A, 12V / 3A, cigarette lighter port, USB and type C output: first, press the power button, then enter the main interface through the touch screen, click the DC ON/ OFF button and confirm, Turn off these output, and also click the DC on / off button and confirm.
- (2) Turn on AC output: first, press the power button, then enter the main interface through the touch screen, click the AC ON/ OFF button and confirm. Turn off these AC output ports, and also click the AC ON/ OFF button and confirm.


## 8. Application scenario

- (1) **Outdoor:** Car equipment: car fridge, car vacuum cleaner and other car equipment; Camping equipment: garden electric tools (power tools such as blowers, lawn mowers, electric drills, electric saws), BBQ grills, LED lights, etc.
- (2) **Indoor:** Refrigerator, kitchen devices such as kettle, toaster, blender, coffee maker, rice cooker, laptops, phones, lighting, etc.

#### 9. Examples of loads

- (1) 12V / 25A, 12V / 3A, cigarette lighter port, USB and type C output port are suitable for most products in the market, but some products may trigger overcurrent protection if there is a large current impact at the moment of starting.
- (2) The power of electrical products used for AC output should be less than 2000W. According to the different electrical products, when the rated power is less than 2000W, some air conditioners, motors and other devices that need instantaneous high current when starting may trigger overcurrent when the ratio of peak value of rated current exceeds 3:1. At this time, we recommended that you select the electrical appliances with lower power rate.
- (3) When the output is overload, over-current or short circuit, the product will turn off the corresponding output, and then it will automatically start twice (at an interval of 20s). If there is still an overload, over-current or short circuit alarm, the output will be locked, and it needs to be manually troubleshooting and then restart. If the output stops repeatedly after restart, please stop using it immediately (only after troubleshooting) or contact the seller or maintenance agent for help.
- (4) When the battery power is discharged to 0%, the DC and AC output will automatically turn off. Only when the battery power is charged to more than 5%, the DC and AC output can be turned on, which is to protect the battery and enhance its cycle life.
- (5) This machine supports charging and discharging simultaneously.

## 10. Estimation of operating time



2000Wh × DOD ×  $\eta$  ÷ (load W) = charging time (unit: h)

Note: DOD is the battery discharge depth,  $\eta$  is the local inverter efficiency, DOD=90%,  $\eta\text{=}88\%_{\circ}$ 

## 11. Specification

Output		
	Rated output power	2000W
	Low rated voltage	100-120Vac
	High rated voltage	220-240Vac
	THD	< 5%
	Efficiency	> 88% (R load)
AC output	Overload capacity	2000W <load<2500w, 2min;<br="">2500W<load, immediately<="" td=""></load,></load<2500w,>
	Short circuit protection	yes
	Over temperature protection	yes
	Noise	load<1500W, Max.45dB; load>1500W, Max.54dB
	Rated voltage	12V
DC12V/25A	Rated current	25A
	Overload power	330W <load, 2s<="" td=""></load,>
	Short circuit protection	yes
	Rated voltage	12V
DC12V/10A	Rated current	10A
output	Overload power	>120W, 2s
	Short circuit protection	yes
	Rated voltage	12V
DC12V/3A	Rated current	3A
output	Overload power	>40W, 2S
	Short circuit protection	Yes
	Rated voltage	5V
USB output	Maximum current	3A
	Short circuit protection	Yes
	Fast charging type	PD2.0 (60W Max)
Type C	0 0 71	
Type-C	Rated output	5V/3A, 9V/3A, 12V/3A,15V/3A, 20V/3A
Type-C output		5V/3A, 9V/3A, 12V/3A,15V/3A, 20V/3A Yes
	Rated output	

Input		
	input voltage	100-240VAC
AC charging	Maximum charging voltage	58.8 VDC
	maximum charging power	500W
Car input	input voltage	11.5V-14.4V/23V-28.8V
Car input	Input current	8.2A
	input voltage	35V-150V
Solor nonel	Input current	12A (only 12A will be received When
Solar panel		the current exceeds 12A)
	Input maximum power	700W

#### Remarks:

- 1. PV charging has automatic activation charging function(plug and play): when PV is connected with the product, it will automatically activate the device for charging as long as the sun has energy; if you do not want this function, please unplug the PV charging head after full charge.
- 2. It supports charging while discharging, and does not support UPS function.

2. It supports charging while discharging, and does not support OPS function.		
Battery Pack		
Rated capacity 2000Wh,40Ah		
Voltage	41.5V-58.4V	
Short circuit protection	yes	
Output overcurrent protection	70A	
Discharge high temperature protection	<b>65℃/149</b> ℉	
Recovery of discharge high temperature protection	<b>55℃/131</b> ℉	
Charging high temperature protection	<b>55℃/131</b> ℉	
Charging high temperature protection recovery	<b>45℃/113</b> ℉	
Charging low temperature protection	<b>0℃/32</b> ℉	
product		
Product size	420*280*386mm(16.5*11*15.2inch)	

product		
Product size	420*280*386mm(16.5*11*15.2inch)	
Net weight	27.5Kg(60.6lbs)	
Working environment temperature	<b>0°</b> C <b>-40°</b> C <b>/32°</b> F−104°F	
Storage ambient temperature	<b>-10</b> ℃ <b>-45</b> ℃ <b>/14</b> ℉−113℉	
Working environment humidity	10-90%	

#### 12. Storage and maintenance instructions

- (1) Please fully charge the machine before storing it.
- (2) Turn off all power buttons.
- (3) To preserve the battery liftspan, please use and recharge at least once every 6 months.
- (4) Ensure proper ventilation while in use or store and keep away from any combustible materials or gases. Do not stack anything on top of the unit in storage or in use. Inadequate ventilation and/or improper storing may cause damage to the unit.
- (5) Avoid exposing the product to rain or using the product in humid environment.
- (6) Use and store the product in a clean and dry environment.
- (7) Keep this product away from children and pet.
- (8) Wring the cloth with water and wipe it clean In case of dirt.

#### 13. Declaration

- •Some changes may be made to the appearance and specifications without prior notice due to the improvement of the product.
- •Our company shall not be liable for any damage caused by force majeure such as fire, typhoon, flood, earthquake or the user's intentional negligence, misuse or other abnormal conditions.
- •No compensation shall be made for the failure of non standard connector/accessories.
- •Our company will not bear all responsibilities if the damage is caused by not operating the product according to the use method in the operation manual.
- •This product is not suitable for use on the relevant equipment or machines involving personal safety, such as atomic energy devices, aerospace devices, transportation devices, medical devices, etc., or the equipment or machines that must be highly reliable in electricity. If we use this product on the above-mentioned equipment or machine, we will not be responsible for personal accident, fire accident or wrong action of the machine and equipment caused by the failure of this product.

## 14. Common faults and troubleshooting

If this product is unable to charge or power other equipment, please check according to the following steps.

- (1) Ensure that the power button is on and the power button light is always on(green).
- (2) Make sure the DC ON / OFF button and AC ON / OFF button are on.
- (3) Check whether the left of battery capacity is more than 5%. If the left of battery

capacity is less than 5%, please charge as soon as possible.

(4) Ensure that the load equipment meets the power limit of the product, that is, the load power is within the maximum input range of each output interface;

If the above steps still do not solve the problem, please contact the seller for help.

#### 15. FAQ(Frequently Asked Questions)

#### What is the depth of discharge (DoD)?

To extend battery life, the portable power station has a DOD setting of 90%, which means that only 90% of the battery capacity can be discharged. Reserve 10% of the energy to avoid damage to the battery due to over discharge.

#### • Can it be charged and discharged at the same time?

Yes, it supports pass through charging for both AC and DC loads. We recommend if you do this that you make sure to fully charge the AC200P at least once per month to extend battery life.

#### • Can AC output charge refrigerator, air conditioner or electric drill?

Lower power for those devices can be charged. It is not recommended to use more than 1400W power. The starting power of refrigerator, air conditioner and electric drill is generally 5-7 times of the nominal power, which is easy to trigger AC overload.

• Can two products be used in parallel?

No.

#### Can I use third-party solar panels?

You can use any solar panels available as long as they have MC4 connectors and when wired together the voltage is between 35V to 150V and no more than 700W.

#### • How do I know if my appliance will work with the product?


When figuring what appliances can be powered with your portable power station, you will need to calculate how much the continuous loads are of each appliance you want to run simultaneously to determine if the total amount of watts is within the capacity of the generator. You can find the wattage of the appliance by looking at the manufacturer's information (this information is usually stamped or printed on most appliances and equipment) to measure it's wattage. Add all wattages of appliances to be run to determine if the total amount of watts is within the maximum continuous and surge watts.

Can I connect the product to my home circuit breaker box?
 Can not.



## **B300 Portable Power Station**

Please read this manual before use and follow its guidance. Keep this manual for future reference.



## **User Manual**

Please read this manual before use and follow its guidance. Keep this manual for future reference.

## **Contents**

01.	BRIEF INTRODUCTION	01
02.	ABBREVIATION	01
03.	SAFETY INSTRUCTION	01
04.	BLUETTI APP	02
05.	IN THE BOX	03
06.	LET`S GET STARTED	05
07.	FEATURES	05
08.	RECHARGE	06
09.	AC300+B300 EXTRA BATTERY CONNECTION	07
10.	AC200MAX+B300 EXTRA BATTERY CONNECTION	09
11.	TECHNICAL SPECIFICATIONS	10
12.	FAQ (Frequently Asked Questions)	11
13.	STORAGE AND MAINTENANCE	12
14.	DECLARATION	12

#### 1.BRIEF INTRODUCTION

#### Introduction

B300, the extension battery pack owns 3072Wh capacity to support BLUETTI AC200MAX and AC300 series, or AC200P. AC200MAX can support up to two B300 battery packs to reach 8192Wh capacity. When connecting to AC300, user can connect two AC300 to double the output power and capacity with Split Phase Box(P030A) at the same time! Boost up to 6,000W of continuous power, 24.6kWh capacity in total, and 10.4kW of groundbreaking solar input capability! This setup can be an emergency power center and run your home essentials for over a week, or with enough solar panels, you can even run your entire whole house, off-grid indefinitely.

#### 2.ABBREVIATION

BMS: Battery Management SystemMPPT: Maximum Power Point Tracking

• DC: Direct Current

PV: Solar Panel(s) Charging (Photovoltaic)
Grid: Home Power Supplied by Utility
T500: 500W Additional Adapter


• DOD: Depth of Discharge

#### 3.SAFETY INSTRUCTION

- DO NOT place the power station near heat sources. It is prohibited to place the equipment in an environment with flammable, explosive gas, or smoke. It is also prohibited to operate the equipment in this environment.
- DO NOT attempt to replace the internal battery or any other component of the equipment by anyone other than authorized personnel. There are no end User-serviceable components.
- DO NOT operate in wet conditions. If the equipment becomes wet, please let the unit dry completely before using.
- Please ensure proper ventilation while in use and do not obstruct fan openings. Inadequate ventilation may cause permanent damage to the equipment.

- DO NOT stack anything on top of the power station while in storage or while in use.
- DO NOT move the unit while operating as vibrations and sudden impacts may lead to poor connections to the hardware inside.
- Warning: DO NOT insert foreign objects into any ports of the B300. Please use it carefully and keep children away from it.
- In the case of fire, only a dry powder fire extinguisher is suitable for the product.
- For safety purposes, please use the original charger and cables designed for the equipment. We are not liable for damage caused by third-party equipment and may render your warranty invalid.

#### 4.BLUETTI APP



With BLUETTI App, the remaining capacity of B300 can be viewed remotely only when B300 has been connected to AC300/AC200Max already. Please turn to the AC300/AC200Max User Manual for detailed information.

## **5.IN THE BOX**


#### Standard Accessories

No.	Category	Quantity
1	B300 Battery Module	1
2	Battery Expansion Cable  Connect B300 to the battery port of AC300 or AC200Max to extend the capacity	1
3	PV Input Cable (MC4 - XT90) (10A, MAX 200W) Charging B300 via solar panels with MC4 ports.	1
4	User Manual Please read the manual before use and follow its guidance, keep this manual for future reference.	1
5	Warranty Card Please keep this Warranty Card properly.	1
6	Certificate of QC PASS	1

## Additional Purchase Accessories Sold on BLUETTIPOWER.COM


No. Category	
	Car Charging Cable(Cigarette Lighter Port - MC4) Charging B300 by vehicle, work with cable No.3.
Optional Input Cable	Lead-acid Battery Charging Cable Charging B300 via lead-acid battery, put the clamps on the corresponding positive&negative poles of lead-acid battery, work with cable No.3.
	D050S Charging Enhancer Kit (Including D050S,PV,Car,Lead-acid Charging Cable) D050S - for extra charging methods on 7909(original AC) port.
	Voltage limit: 12-60VDC Input: 500W Max
Optional	USB-C to USB-C Cable Support 20V/5A, 100W power of output, fits most appliances in the market with USB-C port.
Output Cable	Cigarette Lighter Port - 5521 Cable Suit for 12V devices with 5521 input port such as router, camera and etc.
Optional AC	
Adapter	AC Adapter Charging B300 via wall outlet at 500W Max.

## **6.LET`S GET STARTED**



- Power ON/OFF: Long press the power button to turn ON/OFF the unit, the led indicator will light up/off.
- The B300 will turn on automatically from Power Off state when either grid charging and/or PV charging voltage is applied to the charging port.

#### 7.FEATURES



#### **11** Battery Capacity LED

Show the remaining capacity of B300.

#### 12V/10A Cigarette Lighter Port

Output port for devices with corresponding plug such as vehicle-use vacuum.

#### IB USB-C (PD3.0, 100W) Output Port

Can be used via USB-C to USB-C cable to charge most devices in the market such as Pixel Phone, Macbook Pro at 100W Max.

#### **II** DC ON / OFF Button

To turn ON/OFF the output function of B300.

#### USB-A (QC3.0) Output Port

USB-A ports supports QC3.0 protocol.

#### M Power Button

To turn ON/OFF the B300, all the function will be closed.

#### **M** Battery Extension Port

The port to connect B300 with AC300/AC200MAX/B300.

#### **B** PV Input Port

To charge B300 via solar powers. And car charging, lead-acid battery charging.


#### Charger Input Port

To charge B300 via vehicle, extra solar power, lead-acid battery, AC adaptor. Suitable for D050S.


#### 8.RECHARGE

#### 8.1 Solar Charging

- Choose the solar panel with working voltage DC 12V-60V.
- Connect the solar panel to the B300 via solar charging cable(accessory3).
- Plug and play charging: it will start charging automatically after connecting the solar panel to the product even it is at off status.
- Max. current of the solar: 10A
- B300 should be turned off after 2mins when unplugging the solar charging cable from B300.




#### 8.2 AC Charging




The estimated fully charging time for adapter: 6.6-7.1Hrs.

#### 8.3 Car Charging



#### 8.4 Dual Recharge




The estimated fully charging time for Dual Recharge: 4.9-5.4 Hrs.

## 9.AC300 + B300 EXTRA BATTERY CONNECTION

AC300 can extend the capacity by 1-4 B300 battery pack to 3072-12288Wh. Supports up to 4 battery packs in parallel.

AC300+B300 system will be activated when AC300 has been charged.




AC300 + B300 \*1 = 3072Wh


Step1: Press Button01 and connect the battery port of AC300 with B300 through Battery Expansion Cable (accessory No.2)

Button 01

Step2: Push Button02 to LOCK the cable with either AC300 or B300.


Step3: Press the power button of both AC300 and B300.






AC300 + B300 \*4 = 12288Wh

# 10.AC200MAX + B300 EXTRA BATTERY CONNECTION



AC200MAX + B300 \*1 = 5120Wh



AC200MAX + B300 \*2 = 8192Wh

## 11.TECHNICAL SPECIFICATIONS

General Specs		
Model No.	B300	
Net Weight	36.1kg (79.6lbs)	
Dimensions	520*320*266mm (20.5*12.5*10.5in)	
Charge Temperature	0-40℃ (32-104 ℉ )	
Discharge Temperature	-20-40℃ (-4-104 ℉ )	
Storage Temperature	-20-40℃ (-4-104 ℉ )	
Working Environment Humidity	10-90%	
Capacity	3072-12288Wh (60-240Ah)	
Battery Type	LiFePO4	

Standard Battery Voltage	51.2VDC		
	DC Output		
Cigarette Lighter Port *1 12VDC,10A			
USB-A	*1 3.6-12VDC, 3A,18W		
USB-C PD3.0 supported	*1 5-15VDC,3A; 20VDC,5A,100W		
	AC Input		
AC(through 7909 via T500)	500W Max		
Specs	58.8VDC, 8A		
	PV Input		
MPPT(single) Voltage Limit	12-60VDC		
Max. Power of Input	200W		
Max Input Current	10A		
Car Charging			
Input Voltage	12/24VDC		
Current	8.2A		
Max Input Power	196.8W		
Battery Port *2			
Specs	58.8VDC, 80A		

## 12. FAQ (Frequently Asked Questions)

• How to claim the warranty?

Please refer to the warranty card you received from where you have ordered the product from.

• Can the unit be upgraded?

When B300 has been connected to AC300, the firmware including ARM, DSP, IOT and BMS can be upgraded online through OTA via BLUETTI APP.

• Can it be charged and discharged at the same time?

Yes, the unit supports pass-through charging function for DC outputs.

• Can I use third-party solar panels to charge the unit?

Yes, third-party solar panels can be used as long as they utilize MC4 connectors and the combined output voltage (in series or parallel) is between 12V to 60V,200W Max.

#### 13. STORAGE AND MAINTENANCE

- Please turn off the unit and charge it to 50-70% capacity every time before storing it.
- To preserve the battery health, please discharge and fully charge the unit at least once every 3-6 months.
- Ensure proper ventilation in use or store and keep away from any combustible materials or gases.
- Avoid exposing the unit to rain or wet environment, and direct sunlight (32-113  $^{\circ}$ F, 0-45 $^{\circ}$ C), a clean and dry environment is strongly recommended.
- Dry, non-abrasive cloths to clean the exterior from dust and debris every so often are highly recommended.
- Keep the unit away from children and pets.

#### 14. DECLARATION

- Some changes may occur without notice such as external appearance or specifications due to availability of material supplies or hardware improvements of the product over time.
- BLUETTI shall not be liable for any damage caused by force majeure such as fires, typhoons, floods, earthquakes or the user's intentional negligence, misuse or other abnormal conditions.
- No compensation for damages shall be made for utilizing non-standard adapters and accessories.
- BLUETTI is not liable for any damages caused by any operations of the product outside of the usage methods detailed in this manual.
- This unit is not suitable for use on the relevant equipment or machines involving:

Personal safety, atomic energy devices, aerospace devices, medical devices,

etc., or any equipment or machines that require highly reliable power sources. We are not responsible for accidents, fires, wrongful or negligent actions caused by such equipment or machines which results in damage.

#### EU REP

Company: POWEROAK GmbH Address: Lindwurmstr. 114, 80337

München Germany Mail: logi@bluetti.de

#### UK REP

Company: POWEROAK ENERGY UK CO.,LTD Address: Suite 108 Chase Business Center 39-41 Chase Side London United Kingdom N14 5BP

Mail:poweroak.eu@bluetti.com

P/N:17.0303.0401-00A0