

# IDEAL INDUSTRIES, INC. TECHNICAL MANUAL MODEL: 61-920

*The Service Information provides the following information:* 

- Precautions and safety information
- Specifications
- Performance test procedure
- Calibration and calibration adjustment procedure
- Basic maintenance (Disassembly, Troubleshooting, Spare Parts list)



Form number: TM61920 Revision: 4. Date: July 2008

## TABLE OF CONTENTS

Title	Page
Introduction	1
Precautions and Symbol Information	1
Safety Information	2
Specifications	3
General Specification	3
Ground Resistance Specifications	4
Ground & Leakage Current Specifications	4
Performance Verification	5
Calibration	6
Preparation	6
Procedure	7-9
Disassembly and Component Layout	9
Troubleshooting	10-12
Spare Parts List	12

#### Introduction

# **W**arning

To avoid shock or injury, do not perform the verification tests or calibration procedures described in this manual unless you are qualified to do so. The information provided in this document is for the use of qualified personnel only.

# **∆**Caution

The 61-920 Ground Clamp contains parts that can be damaged by static discharge. Follow the standard practices for handling static sensitive devices.

For additional information about IDEAL INDUSTRIES, INC. and its products, and services, visit IDEAL INDUSTRIES, INC. web site at: www.idealindustries.com

#### Precautions and Safety Information

Use the meter only as described in the *Users Manual*. If you do not do so; the protection provided by the meter may be impaired. Read the "Safety Information" page before servicing this product. In this manual, a **Warning** identifies conditions and actions that pose hazard(s) to the user; a **Caution** identifies conditions and actions that may damage the meter or the test instruments.

#### The Symbols

The symbols used on the meter and in this manual are explained in Table A.

1 able A Symbo	Table A Symbols		
Meter Safety	Description		
Symbol			
#ATT	Battery		
$\square$	Cautionary or important information in manual		
A	Danger - Risk of electrical shock		
	Double Insulation- Protection Class II		
CAT III	IEC Over-voltage Category III		

## Table A Symbols

# SAFETY

Review the following safety precautions to avoid injury and prevent damage to this product or any products connected to it. To avoid potential hazards, use the product only as specified.

# $\triangle$ CAUTION.

These statements identify conditions or practices that could result in damage to the equipment or other property.

# A WARNING.

These statements identify conditions or practices that could result in personal injury or loss of life.

#### **Specific precautions**

Use proper Fuse. To avoid fire hazard, use only the fuse type and rating specified for this product.

**Do not operate without covers.** To avoid personal injury, do not apply any voltage or current to the product without the covers in place.

**Electric overload.** Never apply a voltage to a connector on the product that is outside the range specified for that connector.

**Avoid electric shock.** To avoid injury or loss of life, do not connect or disconnect probes or test leads while they are connected to a voltage source.

**Do not operate in wet/damp conditions.** To avoid electric shock, do not operate this product in wet or damp conditions.

Use of rubber gloves: is a good safety practice even if the equipment is properly operated and grounded

**Use of Clamp jaws:** do not attempt to use the ground tester to twist or pry the ground electrode or ground wire away from equipment or other obstructions. Non-repairable damage may occur.

Characteristics	Description
Display	LCD with a maximum count of 2099
Conductor Size	Approximately 1.25" in diameter max.
Overrange Indication	"OL"
Sampling Rate	Approx once per second
Operating Environment:	14°F to 104°F
Relative Humidity	85% Relative Humidity
Storage Environment:	-4°F to 122°F at <75% relative humidity
Power source:	4 "AA" batteries
Measurement time:	Approx 24 hrs with alkaline batteries
Low Battery Indicator:	Symbol indicates low battery voltage
Auto power off	Turns power off after 10 minutes of non-use
Power Consumption	50mA
Operating system	Earth Resistance Function: Constant voltage injection,
	Current detection (Frequency appr. 2400Hz) dual integration
	AC current function: Successive approximation (TRMS)
Response Time	Earth Resistance function: Approx. 7 seconds
	Current Function: Approx. 2 Seconds
Location for use	Altitude 2000m or less indoor/outdoor use
IP protection degree	IP40
Electrostatic discharge immunity	Performance criteria B
Withstand Voltage	AC5320 Vrms/5 seconds
	Between the transformer jaws fitted parts and case enclosure
	(except for jaws)
Insulation Resistance	50Megohm or more at 1000v
	Between the transformer jaws fitted parts and case enclosure
	(except for jaws)
Applicable standards	IEC61010-1:2001(CAT IV 300V pollution degree2)
	IEC61010-2-032:2002
	IEC61326:2000 (EMC standard)
Dimensions	9.7" H x 4.7" W x 2.1" D
Weight:	Approximately 1.7 lbs. including battery

# RANGES and ACCURACY SPECIFICATION Measurement Characteristics

(All at  $75^{\circ}F \pm 5^{\circ}C$ , < 85% R.H.)

#### **Ground Resistance**

Range	Measuring Range	Resolution	Accuracy
20Ω	0.00Ω - 20.99Ω	0.01 Ω	$\pm 1.5\% \pm 0.05\Omega$
200Ω	16.0Ω - 99.9Ω	0.1Ω	$\pm 2\% \pm 0.5\Omega$
	100.0Ω - 209.9Ω	0.1Ω	$\pm 3\% \pm 2\Omega$
	160Ω - 399Ω	1Ω	$\pm 5.0\% \pm 5\Omega$
1200Ω	400Ω - 599Ω	1Ω	$\pm  10.0\% \pm 10\Omega$
	600Ω - 1260Ω	10Ω	Unspecified

**Continuity Measurement:** Beep if resistance  $< 10.00 \Omega$  (approximately)

#### **Ground/Leakage Current**

Range	Measuring Range	Resolution	Accuracy
100mA	0.0 - 104.9mA	.1mA	$\pm 2.0\% \pm 0.7$ mA
1000mA	80 - 1049mA	1mA	± 2.0%
10A	0.80 - 10.49A	.01A	± 2.0%
30A	8.0 - 31.5A	.1A	± 2.0%

\*Crest factor  $\leq 2.5$  accuracy at sine wave +1% (50Hz/60Hz, peak value shall not exceed 60A)

\*In the following case, ZERO will be displayed on the LCD

At 20  $\Omega$  range if Earth resistance measured is  $\leq 0.04 \Omega$ 

\*Auto ranging shifts to upper range when the input exceeds 105% of the selected range, and shifts to the lower range when the input falls under 80% of the lower range.

#### PERFORMANCE VERIFICATIONS

Perform the following analysis, if the meter conforms to the limits listed in Table 1 the meter is functioning correctly. If the meter does not conform to any of the listed limits the calibration procedure must be performed.

#### **Performance Verification Preparation**

- Turn on the calibrator, allow calibrator to warm up. Temperature stabilization should be reached after 30 minutes.
- Remove battery cover and use a calibrated meter to ensure the battery measures a minimum of 4.8V DC. If the battery measures under 4.8V DC, replace the battery before beginning the performance test.
- To test the performance of the 61-920 you will need to construct a loop using general resistors with an accuracy of 0.5% or better of fixed values 0.1Ω, 10Ω, 20Ω 200Ω 1000Ω)



Construct the loop using low resistive wire. Minimize connectivity resistance.

- Note: Error for the general resistors are not included in the test data of Table 1
- If the display reading falls outside of the range shown in the Table 1, steps 1 6, the meter does not meet specification.
- Clamp jaws in the center of the test loop.

e I. Resh	stunce I er	tormanee verme	ation	
Steps	Range	Input	Low Limit	High Limit
1	20	00.10Ω	00.05	00.15
2	20	10.00Ω	9.80	10.20
3	200	20.00Ω	19.1	20.9
4	200	100.0Ω	95.0	105.0
5	1200	200.0Ω	185	215
6	1200	500.0Ω	440	560

#### Table 1: Resistance Performance Verification

- Connect the meter to a single wire loop on the calibrator and place the clamp around the center of the wire.
- Apply the current listed in Table 2, steps 1 3.
- If the display reading falls outside of the range shown in the Table 2, steps 1 4, the meter does not meet specification.

Table 2: mA, A Performance Verification

Steps	Range	Input	Low Limit	High Limit
1	100mA	100mA @ 60Hz	97.3	102.7
2	1000mA	1000mA @ 60Hz	980	1020
3	10A	10.0A @ 60Hz	9.80	10.20
4	30A	30.0A @ 60HA	29.4	30.60

### CALIBRATION

#### (1) Calibration Preparation

(1.1) This procedure consists of the following sections.
(1) Calibration Preparation
(2-6) Adjustments
(7) Disassembly and Component Layout
(8) Trouble-shooting
(9) List of spare parts

(1.2) Adjustment procedure will require the following tools and fixed standards Prepare following items for adjustment. Oscilloscope, 20 MHz or better. *See Figure 1* General resistors @ .5% or better  $(0.1\Omega/10\Omega/20\Omega/200\Omega/1000\Omega)$ , Wire of fixture to form a loop circuit with each of the resistors as part of the loop. *See Figure 2* Calibrated current source .1mA to 30A, with an accuracy of 0.5% or better.

Figure 1: Oscilloscope to check waveforms



(1.3) Connect the probe and alligator clip of the oscilloscope as shown in figure one to form a circle (Short the input to common or ground of the scope).

(1.4) Connect a wire and each general resistor  $(0.1\Omega/10\Omega/20\Omega/200\Omega/1000\Omega)$  like a circle respectively.



Construct the loop using low resistive wire. Minimize connectivity resistance

Figure 2

(1.5) Open and close the jaws of 61-920 several times, and confirm that the jaws close by themselves.

(1.6) Use care in removing front panel decal. The adjustment locations shown in *Figure 3* are located underneath the decal. *Note:* plastic switch extensions will be loose with the decal removed.

#### (2) Calibration Procedure

It is recommended that all IDEAL meters undergo the following calibration procedure on an annual basis.

- (2.1) Press the POWER button, without clamping anything, while the CAL button is being pressed down. Then release the POWER button. Version information (3-digit) about this instrument is displayed in a short minute. Then the instrument goes into  $\Omega$  adjustment mode.
- (2.2) Adjust VR for Hi range Press the  $A/\Omega$  button until the mark is displayed at the upper position of the LCD for a moment and "Hi" is displayed at the left of the mark. Turn VR401 to adjust the flickering reading to be within 165.0 ~ 175.0.
- (2.3) Waveform check at Hi range (*Figure 4*)Clamp onto the ring formed by the probe of the oscilloscope The waveform should be a sine wave. Remove the jaws from the ring when the sine wave is observed.
- (2.4) VR adjustment at Lo range.

The message "Lo" is displayed at the upper of the LCD when MEM/MODE button is pressed. Turn VR402 to adjust the flickering reading to be 800 or close value. Then fine adjust the value using VR402 to fall within  $800 \sim 0$ .

#### (2.5) Waveform check in Lo range (*Figure 4*)

Clamp onto the ring formed by the probe of the oscilloscope. The waveform should be a sine wave. Remove the jaws from the ring when the sine wave is observed.

- (2.6) Resistance range Adjustment (2) (Adjustment for Hi range) Press the  $A/\Omega$  button twice. The mark "F.S" is displayed at the upper position of the LCD. (This status is same as when Hi range is selected.)
- (3) Full scale adjustment Wait for a while without clamping anything. Press the CAL button when MEM mark appears.

Later, "OL" or some value is displayed on the LCD.

#### **(3.1)** 1000Ω

Use  $1000\Omega$  resistor. Press the <u>MEM/WRITE</u> button when <u>MEM</u> mark appears on the LCD and the reading becomes stable.

#### **(3.2)** 200Ω

Press the  $\checkmark$  button once. Then 200 is displayed at the upper position on the LCD. Use 200 $\Omega$  resistor. Press the <u>MEM/WRITE</u> button when <u>MEM</u> mark appears on the LCD and the reading becomes stable.

#### **(3.4)** 20Ω

Press the  $\checkmark$  button once. Then 20 is displayed at the upper position on the LCD. Use 20 $\Omega$  resistor. Press the MEM/WRITE button when MEM mark appears

on the LCD and the reading becomes stable.



Fig. 3 Button lavout





Fig. 4 Check of waveform











#### Page 7

(3.5) Repeatability check with  $1000\Omega$  and re-adjustment Press the button twice. Then "F.S" is displayed at the upper position of the LCD. Use  $1000\Omega$  resistor. Open and close the jaws, and check the readings on the LCD. Repeat this kind of work five times. Each time the reading should be within  $900 \sim 1100$ . If the reading is within above range, proceed to the next process. If one of the readings is out of above range, repeat the adjustment from 2.-(4) Full scale adjustment (Hi range). (4) Resistance range Adjustment(3) (Adjustment for Lo range)  $(4.1) 20.0\Omega$ Press the MEM MODE button once. Then 20.0 is displayed at the upper position of the LCD. Use  $20\Omega$  resistor. Press the MEM/WRITE button when MEM mark appears on the LCD and the reading becomes stable. **(4.2)** 10.0Ω Press the  $\nabla$  button once. Then 10.0 is displayed at the upper position of the LCD. Use  $10 \Omega$  resistor. Press the MEM/WRITE button when MEM mark appears on the LCD and the reading becomes stable. **(4.3)** 0.1Ω Press the  $\blacksquare$  button once. Then 0.1 is displayed at the upper position of the LCD. Use  $0.1\Omega$  resistor. Press the MEM/WRITE button when MEM mark appears on the LCD and the reading becomes stable. (4.4) Disconnect the 61-920 from the test wires, and press the POWER button to power off the instrument. (5) Current range adjustment Prepare following items for adjustment. Current generator, coil for current adjustment (0.1A/1A/10A/30A/50Hz or 60Hz) Press the POWER button without clamping anything while the CAL button is being pressed down. Then release the POWER button. Version information about this instrument (3-digit) is displayed for a moment. Then the instrument goes into  $\Omega$  adjustment mode. (5.1) Press the  $A/\Omega$  button once and the instrument goes into "A mode". (5.2) Clamp the coil for current adjustment with 61-920. (5.3) Adjust the current range. (a). 0.1A adjustment Generation current: 0.1A@50Hz Press the MEM/WRITE button after the reading becomes stable. (saving the adjustment value) (b). 1.0A adjustment Press the MEM/MODE button once. Generation current: 1A@50Hz Press the MEM/WRITE button after the reading becomes stable. (saving the adjustment value) (c) 10.0A adjustment

Press the MEM/MODE button once. Generation current: 10A@50Hz Press the MEM/WRITE button after the reading becomes stable. (saving the adjustment value)







NHM	ПІ	,	
2	ñ	ir	1 a
_	Ų.	ίĽ	5







(5.3) Adjust the current range (cont'd.)

(d). 30.0A adjustment

Press the MEM/MODE button once. Generation current: 30A@50Hz Press the MEM/WRITE button after the reading becomes stable. (saving the adjustment value)



(6) Press the **POWER** button to power off the unit and replace the front decal, making sure the plastic switch extensions are in place.

(7) Disassembly Removal of battery cover Loosen one battery cover-fixing screw, and remove the battery cover.

(7.1) Removal of Front panel Loosen three front panel-fixing screws. Remove the front panel from the bottom case. *Note: Care should be taken not to lose the snap band and button spacer.* 

(7.2) Removal of PCBLoosen three PCB-fixing screws.Remove the wires for jaw and battery contact.Remove the finished PCB from the bottom case.

(7.3) Removal of jawLoosen two jaw-fixing screws.Remove the finished jaw from the bottom case.

(7.4) Component Layout (Figure 5)



**Figure 5 - Component layout** 

# (8). Trouble shooting

(8). Trouble shooting	Descible Courses	Downadias
Symptoms The instrument cannot be	Possible Causes	Remedies
buttoned on.	No batteries.	Set the batteries.
	Faulty battery polarity	Install batteries in correct polarity.
	Insufficient capacity of battery	Replace the batteries.
	Poor contact of battery contacts	Replace the battery contacts.
	A break in a battery harness	Make a continuity test of test lead. If there is no continuity, replace the battery harness.
	Defect of circuit component	Defect of PCB; when current consumption is about 100mA or more at 6V of battery voltage. Replace the PCB.
Indication error (chip of segment,	Insufficient capacity of battery	Replace the battery if the indication is faint or "BATT" mark is displayed on the LCD.
arithmetic point, unit and so on)	Poor contact of rubber contactor.	Clean the tracks on PCB and LCD where rubber contactor contacts with.
	Defect of circuit component	Check above points first. If there is no problem, replace the PCB and do re-adjustment.
Incapable measurement of resistance	Insufficient capacity of battery	Replace the battery when "BATT" mark is displayed on the LCD.
	Data hold function is being run.	Data hold function is being activated if "H" mark is displayed on the LCD. Press the "DATA HOLD" button and release it.
	F.SW is in the wrong position.	In case that " $\Omega$ " isn't displayed on the LCD as a unit, press A/ $\Omega$ button several times and select the Ohm measurement function.
	A break in jaw wiring	Make a continuity test of jaw wiring. If there is no continuity, replace the jaw and do re-adjustment.
	Defect of circuit component	Check above points first. If there is no problem, replace the PCB, and do re-adjustment.
Incapable measurement of current	Insufficient capacity of battery	Replace the battery if "BATT" mark is displayed on the LCD.
	Data hold function is being run.	Data hold function is being activated if "H" mark is displayed on the LCD. Press the "DATA HOLD" button and release it.
	Wrong function is selected.	In case that "mA A" isn't displayed on the LCD as a unit, press $A/\Omega$ button several times and select the ACA measurement function.
	A break in jaw wiring	Make a continuity test of jaw wiring. If there is no continuity, replace the jaw and do re-adjustment.
	Defect of circuit component	Check above points first. If there is no problem, replace the PCB, and do re-adjustment.

# (8). Trouble shooting (cont'd.)

(8). Trouble shooting (con Symptoms	Possible Causes	Remedies
When measuring	Insufficient capacity of battery	Replace the battery if "BATT" mark is
resistance,		displayed on the LCD.
error of measurement is	Bad fit of Jaw.	Make sure that the Jaw is completely closed.
notable.		Replace the jaw if it cannot be completely
		closed and do re-adjustment.
	Re-adjustment of PCB	Check above points first. If there is no
	-	problem, PCB needs to be re-adjusted.
	Defect of circuit component	Check above points first. If there is no
	1	problem, replace the PCB, and do
		re-adjustment.
When measuring	Insufficient capacity of battery	Replace the battery if "BATT" mark is
AC current, error of	1 5 5	displayed on the LCD.
measurement is notable.	Bad fit of jaw.	Make sure that the jaw is completely closed.
		Replace the jaw if it cannot be completely
		closed and do re-adjustment.
	Re-adjustment of PCB	Check above points first. If there is no
		problem, PCB needs to be re-adjusted.
	Defect of circuit component	Check above points first. If there is no
		problem, replace the PCB, and do
		re-adjustment.
Any button doesn't work.	Button spacer is missing.	Put the button spacer at the specific
	Daniel opwer is incomg.	location.
	Defect of circuit component	Check above points first. If there is no
	Derect of chean component	problem, replace the PCB, and do
		re-adjustment.
Buzzer doesn't sound.	Poor contact of buzzer	Soldered point at buzzer should be checked.
(when a button is operated	Defect of circuit component	Check above points first. If there is no
or in Buzzer mode)	Derect of circuit component	problem, replace the PCB, and do
		re-adjustment.
		-
"OPEN" mark doesn't	Wrong function is selected.	In case that " $\Omega$ " isn't displayed on the LCD
appear while jaws are		as a unit, press A/ $\Omega$ button several times and
opend.		select the resistance measurement function.
	Defect of circuit component	Check above points first. If there is no
		problem, replace the PCB, and do
		re-adjustment.
"OPEN" mark doesn't go	A break in jaw wiring	Make a continuity test of jaw wiring. If there
off after closing the jaws.		is no continuity, replace the jaw and do
		re-adjustment.
	Defect of circuit component	Check above points first. If there is no
		problem, replace the PCB, and do
		re-adjustment.
"NOISE" mark doesn't	Measuring the current flowing	Turn off the device, which is generating the
go off	line.	current, to minimize the current.
	Two or more 61-920 are clamping	Use only one 61-920 per line.
	onto one same line	
	Defect of circuit component	Check above points first. If there is no
		problem, replace the PCB, and do
		re-adjustment.

Incapable of saving data.	Switch spacer for MEM WRITE button is missing.	Put the Button spacer at the specific location.
	Defect of circuit component	Check above points first. If there is no problem, replace the PCB, and do re-adjustment.
	Switch spacer for backlight is missing.	Put the button spacer at the specific location.
Backlight doesn't light up.	Poor contact of backlight	Soldered point at backlight should be checked.
	Defect of circuit component	Check above points first. If there is no problem, replace the PCB, and do re-adjustment.

# (8). Trouble shooting (cont'd.)

# (9). List of Spare parts

No.	Description	Parts No.	Qty.	Note
10	4200 Finished jaw	142000100A	1	
4	4200 Finished PCB	142000200A	1	
1	Nameplate 4200	9000012900	1	
2	Panel 4200	9000012947	1	
6	4200 Finished Case	142000401A	1	
9	4200 Finished Battery cover	142000402A	1	
3	TAP +N2.3 x 8 (P-TITE)	900009425	3	
7	P-TITE +N 3x 14 (black)	9000010949	5	
8	Battery SUM-3	9000001934	4	
5	Snap band 2412	9000006138	1	
Others				
	Finished Hard case	1912800000	1	
	8304	083040000A	1	
	Instruction manual 4200 (English)	9000013434	1	



Fig. 3 Button layout