

Swing Set USER MANUAL

OWNER'S MANUAL, ASSEMBLY INSTRUCTIONS,
CARE, MAINTENANCE AND USER'S GUIDE

PLEASE DO NOT RETURN TO STORE



Please do not return this product to the retailer!

We are able to assist you in ANY way.

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.



Important Instructions & Warnings!

Please read this entire instruction and assembly manual completely before proceeding. You must follow all safety instructions while using this equipment. The surface area where this swing set is set up must be level and free of all debris. This set is designed to be anchored into the ground and is not to be set up on any hard surfaces such as concrete, hardened soil, or asphalt.

Proper surfacing under and surrounding the set adds to the safety level such as sand or mulch. Read all cautionary statements on the following pages before using this equipment and save this instruction manual. **DO NOT ALLOW CHILDREN TO PLAY ON THIS GYM SET UNSUPERVISED! CONSTANT ADULT SUPERVISION IS REQUIRED.** Do not use when raining or during any inclement weather (i.e. rain, sleet, snow, ice, high winds, thunderstorms, or lightening). **DO NOT ALLOW CHILDREN TO JUMP ON OR CLIMB UP ON THIS SET'S TOP BAR.**

FOLLOW ALL ASSEMBLY INSTRUCTIONS AS WRITTEN IN THIS MANUAL.

IMPORTANT INSTRUCTIONS AND WARNINGS

BEFORE YOU BEGIN

- Carefully read all instructions in this manual before assembling and using this product.
- The unit must be assembled by adults. Heavy duty working gloves must be worn to avoid injuries during assembly.
- Children must not use the equipment until it is properly assembled and anchored.
- Adult supervision is required during the use of this equipment at all times.
- Unpack all parts. Take a complete inventory of all parts and hardware using the parts and hardware lists in the following pages. If any parts are missing, do not return to the store. Please call customer service toll-free number listed on the cover page for assistance. Store the product back in the original box and do not begin to install until all parts are obtained.

LOCATION OF PLAY SET

- The equipment must be placed more than six (6) feet (1.8 meters) from any structures or obstructions, including but not limited to buildings, fence, garage, trees, laundry lines, electrical wires. Children can be seriously injured running or swinging into obstacles.
- The play set must be installed on level ground. Uneven ground must be leveled prior to installation. Installation on sloping or uneven ground will put stress on the joints, causing the unit to become loose and unstable which may result in serious injuries.
- Remove any tripping hazards from the safe play area, such as roots, tree stumps, rocks, landscaping, sprinkler heads, railroad ties, plumbing and electrical connections.
- In windy conditions it is possible for the product to be blown about by a high wind. If you anticipate high winds, the frame should be secured to the ground with the use of an Anchor kit. If you anticipate severe winds, the product should be moved to a sheltered location or completely disassembled.
- Do not install your play set over hard surface, e.g. asphalt, concrete, packed earth, tile or brick floor. A fall onto a hard surface can result in serious injury or death to the user.

The Consumer Product Safety Commission's Outdoor Home Playground Safety Handbook recommends to install and maintain the playground equipment over at least 9 inches of wood chips, mulch or shredded rubber (for equipment up to 8 feet high) or sand or pea gravel (for equipment no more than 5 feet high) as shock absorbing material. Dirt and grass, which are the most prevalent surfaces under home playground equipment, do not adequately protect children from serious head injuries. Install protective surfacing at least six feet in all directions from play equipment. For swings, the surface should extend, in back and front, twice the height of the suspending bar. You should consult a local contractor about ways to secure the product in your location. Do not install your play set over hard surface, e.g. asphalt, concrete, packed earth, tile or brick floor. Please refer to the CONSUMER PRODUCT SAFETY COMMISSION'S OUTDOOR HOME PLAYGROUND SAFETY HANDBOOK for detailed guidelines to prevent injuries from falls and other hazards on public and home playgrounds.



WARNINGS ON ANCHORING

This product must be anchored into the ground to prevent movement and to make the swing set more stable during use.

Some consumers want an anchoring system that allows the product to be moved to different locations. Other

consumers want to keep their swing set in a permanent location.

It is highly recommended that you seek the opinion from a local licensed contractor on the best way to secure the

swing set in your location. The best way to anchor a product is to create a concrete footing and use that as a base for an anchor. Whatever method you prefer for your location, an anchoring system for this product should be used at all times.

WEATHER CONDITIONS

- DO NOT use this equipment if the swing seat, slide, glide ride, rocky-rider, stand n swing, see-saw, trapeze or any parts are wet. Use the play set only when the parts are clean and dry. If the equipment is wet, the user could slip and suffer injuries.
- Please be aware of weather conditions when using the equipment. If it is too windy, users could lose control and suffer injuries. The playground equipment must be properly anchored, stored away or restricted from use during inclement weather such as heavy winds or severe weather storms. You should consult a local contractor about ways to anchor the product in your location.

PLAY SUPERVISION

- DO NOT allow more than one child to play on the individual swing, stand R swing, or slide component at any one time.
- DO NOT allow children to stand on the slide, swing seats, see-saw, rocky-rider, stand n swing, or glide ride.
- DO NOT allow children to walk too close to moving parts. ALWAYS keep a safe distance to avoid being struck by other children while playing on swings, slides, trapeze, glide ride, etc.
- DO NOT allow children to hang upside down on the trapeze!
- DO NOT allow children to twist the swing chains or loop them over the top support bar as this may reduce the strength of the chain.
- DO NOT swing empty seats as this may cause injuries.
- ALWAYS guide children to sit in the center of swinging parts, with their full weight placed in the seat center and holding on to the swing chains.
- DO NOT allow children to jump off the equipment while it is in motion. ALWAYS come to a full stop before dismounting.

- ALWAYS dress children appropriately for proper play, e.g. wear well-fitted rubber sole shoes, and remove loose or sharp items such as jewelry, hair accessories, scarves which may become entangled in the equipment or cause injuries.
- ALWAYS make sure children remove their bike or other sports helmets before playing on the playground.
- DO NOT allow children to slide down the slide head first.
- DO NOT allow children to climb onto swing or jump to/from different play areas of the equipment.
- ALWAYS return safely to the ground before approaching another play area.
- DO NOT allow children to climb on structural parts (e.g. legs, top bar). These are structural components and are not designed for play.
- ALWAYS check the slide or other parts exposed to the body for extreme heat from the sun before allowing children to use the equipment.
- ALWAYS prevent access and secure from any unauthorized use when there is no adult supervision.
- DO NOT allow pets or other animals near the equipment to prevent damage or injuries.
- Adequate overhead clearance is essential. A minimum of 24 ft (7.3 meters) from ground level is recommended. Provide clearance for wires, tree limbs, and other possible hazards.
- Use the swing set in a well-lit area. Artificial illumination may be required for shady areas.

INSPECTION PRIOR TO EACH USE OR DAILY INSPECTION

- DO NOT use the equipment if any bolts or nuts are missing or loose. ALWAYS check to ensure the equipment and all parts are well secured and stable before each use.
- ALWAYS clear the play area of any rocks, sharp objects, or any materials that could be potentially hazardous to users.
- DO NOT attach items to the equipment that are not specifically designed for use with the equipment, including, but not limited to, jump ropes, clothesline, pet leashes, cables and chains as they may cause choke hazards.
- The steel and plastic parts used in your product are subject to normal wear. Gradual deterioration of the material will occur, the speed of which will depend on the level of exposure to UV rays, airborne pollution, outdoor weather conditions such as rain and wind and the amount of use. You must inspect the equipment prior to every use. This includes, but is not limited to inspecting the set for cracks, excess wear, missing parts, loose connections, and for overall integrity. When the set shows any signs of weakness, you must stop using the play set immediately, properly store the set or restrict access by users until the condition is resolved.
- Verify that the chains are secured at both ends and tightened, so that there is no loose chain hanging that can result in choking hazard.

When conducting inspections, it is recommended that you use the Suggested General Maintenance

Checklist and Routine Inspection and Maintenance Issues checklists provided by the US Consumer.

CARE & MAINTENANCE INSTRUCTIONS

- Inspect all nuts and bolts twice monthly during the usage season for tightness and tighten as required. It is particularly important that this procedure is followed at the beginning of each season.
- Oil all metallic moving parts monthly during the usage period.
- Sand rusted areas on metal tubing and repaint using a nonlead-based paint meeting the requirements of Title 16 CFR Part 1303.
- Check swing seats, trapeze, stand n swing and chains monthly during usage season for deterioration. Replacements should be made in accordance with the manufacturer's instructions.
- Check all coverings for bolts and sharp edges twice monthly during usage season to be certain that they are in place and replace when necessary. It is especially important to do this at the beginning of each new season.
- Do not use when the temperature drops below 32 degrees F (0 degrees C); remove and store the plastic swing seats, stand n swing, trapeze, rocky-rider, and slide indoors.

READ THROUGH THE ENTIRE ASSEMBLY PAGES FIRST BEFORE STARTING.

Note: The maximum fall height for this product is 4 feet. The minimum ground clearance between the bottom of the suspended plays and the playing or ground surface must be 8 inches. You must maintain a minimum of 8 inches of ground clearance.



WARNING

Please properly anchor the swing set to minimize the risk of injury or death.


If the swing set is used without proper anchoring, it may be dangerous and may tilt over.

Assembly Instruction
















- Place the playground equipment on level ground, not less than 6ft from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.
- Do not install the playground equipment over concrete, asphalt, packed earth, or any other hard surface. A fall onto a hard surface can result in serious injury to the User.














Tightening Bolts&Nuts

- Do not over-tighten the nuts and bolts when you are assembling your playground equipment. This will allow for some possible adjustments and ease of installation.
- Once you have finished the assembly of the playground assembly, go back over all of the nuts and bolts and properly tighten all of them before using the playground equipment.



Part List


<p>(A)</p>  <p>x 2</p>	<p>(B)</p>  <p>x 1</p>	<p>(C)</p>  <p>x 2</p>
<p>(D)</p>  <p>x 2</p>	<p>(E)</p>  <p>x 8</p>	<p>(F)</p>  <p>x 4</p>
<p>(G)</p>  <p>x 4</p>	<p>(H)</p>  <p>x 2</p>	<p>(J)</p>  <p>x 4</p>
<p>(K)</p>  <p>x 2</p>	<p>(L)</p>  <p>x 2</p>	<p>(M)</p>  <p>x 4</p>
<p>(N)</p>  <p>x 4</p>	<p>(P)</p>  <p>x 1</p>	<p>(Q)</p>  <p>x 1</p>

<p>①</p>  <p>x 7</p>	<p>②</p>  <p>M8 x 60mm x 16</p>	<p>③</p>  <p>M8 x 70mm x 16</p>
<p>④</p>  <p>x 16</p>	<p>⑤</p>  <p>x 78</p>	<p>⑥</p>  <p>x 47</p>
<p>⑦</p>  <p>x 7</p>	<p>⑧</p>  <p>x 4</p>	<p>⑨</p>  <p>x 1</p>
<p>⑩</p>  <p>x 1</p>	<p>⑪</p>  <p>x 1</p>	<p>⑫</p>  <p>x 1</p>
<p>⑬</p>  <p>x 1</p>		

STEP 1:


Connect reinforcement tube (D) into the beam tube (B) at both ends with the screws (3) spacers (5) protect iron piece (M) nut (6)

(Note: do not lock the screws tightly, fix them temporarily first. After most pieces are assembled, tighten them in sequence so that the stress of the overall structure is evenly distributed.)




STEP 2:

Connect the beam tube (A) to STEP 1, insert the beam tube (A) into the beam tube (B) connection, assemble and lock it with screws (3) spacers (5) and nuts (6).




STEP 3:

Assemble and connect the crossbeam end tube (C), insert the left crossbeam tube (C) into the crossbeam tube (A), assemble and lock it with the screws (2) spacers (5) nuts (6), Repeat the above step for the right side.



STEP 4:

Assemble the upper column tube (F), insert the left upper column tube (F) into the 2 sleeves of the crossbeam tube (A), assemble and lock it with screws (2) spacers (5) nuts (6). Assembled and locked. Repeat the above step for the right side.




STEP 5:

Assemble the beam support tube (E), connect the left crossbeam tube (A) with the support tube (E), assemble it with screws (3) spacers (4) nuts (6) and lock it, then connect the crossbeam tube (C) with the support tube (E) and assemble it with screws (3) spacers (4) nuts (6).


Repeat the above step for the right side.

(Note: do not lock the screws tightly, fix them temporarily first. After most pieces are assembled, tighten them in sequence so that the stress of the overall structure is evenly distributed.)



STEP 6:


The last step on the left side of the assembly of the four support tube (E) connected to the upper column tube (F), and then use the screws (3) spacer (5) nut (6) assembly and lock. Repeat the above step for the right side.



STEP 7:

Swing seat hanging anchor assembly: with carabiner (7) eye hook screws (1) spacers (5) nuts (6) assembled on the beam tube (C) and lock.

Repeat the above step for the beam tube (A) and beam tube (B).




STEP 8:

Connect the left cross tube (H) lower column tube (G) upper column tube (F), insert the lower column tube (G) into the upper column tube (F), and then assemble and lock it with the cross tube (H) screws (2) spacers (5) nuts (6).


Repeat the above step for the right side.

(Note: Tube H is assembled in the lower side screw hole)




STEP 9:

Assemble the rectangular swing saucer: put 2 U-shape tube (K) into the two ends of the seat cushion (P), then put 2 side bars (L) together (the ports of L and K are connected).




STEP 10:

The lanyard (N) is assembled to the rectangular swing saucer, assembled and locked with the screw and spacer (5) nut (6) on the front of the lanyard (N).




STEP 11:

Assemble the disc swing seat: put 4 curved surface tubes (J) into the Oxford cloth seat cushion (Q) so that their ports are connected.



STEP 12:

Assemble the lanyard (N) to the disc swing seat with the screws and spacers (5) and nuts (6) at the front of the lanyard (N) and lock it.



STEP 13:

Hang the ring hanging ring set (9) on the carabiner (7), repeat the above step for disc swing seat and monkey bar swing, rectangular swing saucer and triangular climbing pendant, Then put the ground nail (8) in the bottom of the lower column tube (G) holes, and then inserted into the lawn, all the assembly is complete!

