
Item Number: A05065

WARNING (To reduce the risk of fire, electric shock, or personal injury):

- 1. We suggest installation by a **licensed electrician**.
- 2. Please read the instruction carefully and save it as you may need it at a later time.
- 3. Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done.
 - » Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "OFF" position.
 - » Place the wall switch in the "OFF" position.
- 4. Mounting surface should be clean, dry, flat, strong enough and 1/4" larger than the canopy on all sides. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- 5. Make sure that the ceiling or wall can stand the weight of the lamp before installation.
- 6. Make sure the voltage you are using is **120V**. The maximum wattage is **LED**, **12W**.
- 7. Keep the lamp away from acidic and alkaline substances in case of damaging the surface of the lamp.
- 8. When replacing bulbs, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
- 9. The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.


IMAGE FOR FINISHED PRODUCT:



TOOLS REQUIRED (NOT INCLUDED):


Before starting assembly and installation please prepare the needed tools as below picture

				and and a second
Ladder	Philips Head or Flat Blade Screwdriver	Electrical Tape	Pliers	Wire Cutter/Stripper




ASSEMBLY & INSTALLATION INSTRUCTIONS:

- 1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration.
- 2. Turn off power Before you start the installation, NEVER attempt any work without shutting off the electricity until the work is done.
 - Go to the main fuse, or circuit breaker, box in your home.
 Place the main power switch in the "OFF" position.
 - » Place the wall switch in the "OFF" position.
- 3 » Unscrew screws (E) from canopy (F).
 - Remove mounting plate (A).




K

L



4 » Screw tube (J) onto connector (K) as shown in the illustration.




5 » Attach mounting plate (A) to the outlet box with mounting screws (D).

OUTLET BOX

6 » Make wire connections

Connect wires as shown in the charts below. *PLEASE NOTE THAT GROUND WIRE IS BARE COPPER WIRE, NEVER CONNECT OTHER WIRES TO GROUND WIRES.*




7 » Raise canopy (F) to the ceiling and secure canopy (F) in place by tightening screws (E) onto the pre-assembled screws in mounting plate (A).

Note: canopy (F) should be snug against the ceiling and screws (E).

If not, adjust the threaded length on mounting plate (A):

- Unscrew the pre-assembled hex nuts.
- Screw the pre-assembled screws in or out of mounting plate (A).
- When the secure length is achieved, tighten the hex nuts and back to step 7.
- CEILING

- 8 » To adjust the hanging height of the fixture:
 - Press down and hold lock nuts (G) by hand.
 - Pull or push steel wire (I) and cable (H) in and out of canopy (F) to increase or decrease the hanging height.
 - Please adjust steel wire (I) first.



9.Check that everything is installed properly, then you can turn on the light. We hope you enjoy your new lighting!

ORDERING PARTS

Keep this sheet for future reference in case you need to order replacement parts. All parts for this fixture can be ordered from the place of purchase. Be sure to use exact wording from illustration when ordering parts.

CLEANING

To clean, wipe the fixture with a soft cloth. Clean glass with a mild cleaner (such as mild and non-abrasive soap). Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.