

EN



Before You Start

- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

FR



Avant de Commencer

- ⚠ Veuillez lire attentivement toutes les instructions.
- ⚠ Conservez les instructions pour vous y référer ultérieurement.
- ⚠ Vérifiez toutes les pièces et les accessoires.
- ⚠ Lisez attentivement chaque étape et suivez l'ordre correct.
- ⚠ Nous recommandons que, dans la mesure du possible, tous les produits soient assemblés à proximité de la zone où ils seront utilisés, afin d'éviter tout déplacement inutile du produit une fois assemblé.
- ⚠ Placez toujours le produit sur une surface plane et stable.
- ⚠ Conservez toutes les petites pièces de ce produit et les matériaux d'emballage hors de portée des bébés et des enfants, car ils pourraient présenter un risque d'étouffement.

EN



CONSUMER SAFETY INFORMATION

- Read this manual before installing and operating this appliance.
- Failure to follow these instructions may result in electric shock, fire property, or personal injury.
- Do not store or use gasoline or other flammable liquids in vicinity of this appliance.



IMPORTANT SAFETY INFORMATION!



WARNING



- **ALWAYS** keep **electric cords, home furnishings, drapes, clothing, papers, or other combustibles** at least **3 feet (0.9m)** away from the front of this heater, and away from the bottom, sides, and rear of this heater.
- **DO NOT** place the heater near a bed because objects such as pillows or blankets can fall off the bed and be ignited by the heater.
- **DO NOT COVER** this heater or block the air vents at all. Doing so could cause a **fire**.
- **AVOID fire or electric shock! NEVER** insert or allow any foreign objects to enter the ventilation or exhaust openings of this heater.
- **Prevent Fire!** Keep all **flammable liquids**, like gasoline or paint, away from this heater. This heater produces **arcing sparks** that **could ignite** flammable liquids.
- **DO NOT cover** this heater in any manner. Doing so could block the air flow and cause the unit to **overheat**, or could **ignite** the material covering the heater.

- **NEVER** run the **power cord** under carpet, rugs, runners, or any other covering. Doing so could cause the cord or materials covering the cord to overheat.
- **AVOID FIRE!** Regularly inspect all air vents to make sure they are free from dust, lint, or other blockage. **Unplug the unit** and clean with a **vacuum ONLY**. **DO NOT** rinse or get wet.


WARNING

- **For residential use only! NOT for commercial use!** **NEVER** use this fireplace for other than its intended purpose.
- **Only use this insert with the mantel that came with the insert. NEVER** use a mantel from **another manufacturer**.
- **NEVER** use this electric fireplace insert **unless** it is **properly installed** in the correct mantel.
- Use **extreme caution** if using this heater **near children**, or where children may be present.
- **NEVER** leave this heater unattended. **ALWAYS** unplug this heater when not in use.
- This heater is **hot** when **in use**. **AVOID INJURY! DO NOT TOUCH** hot surfaces, or attempt to move this heater while it is hot.
- **ALWAYS** turn this heater off before unplugging it from the outlet.
- **AVOID INJURY!** Keep the cord from crossing traffic areas to avoid tripping.
- **NEVER modify this fireplace**. Doing so could result in personal injury or property damage.
- **Discontinue use** if this fireplace **malfunctions** or is **dropped or damaged in any manner**.

WARNING

- **Risk of electric shock! DO NOT OPEN!** No user-serviceable parts inside!
- **ALWAYS disconnect** this unit from the **power** supply **before** performing any assembly or cleaning, or before relocating the electric fireplace.
- **ALWAYS** store this heater in a dry location. **NEVER** use the fireplace if it has become wet.
- **NEVER** use this heater in **bathrooms, laundry rooms**, or any other location where the heater could fall into a **bathtub or pool, become damp** or **come in contact with water**.
- **NEVER** hang this unit on a wall **directly below an electrical outlet**.
- **NEVER** operate this heater if the **power cord** or **plug** has become **damaged**, or if the **grounding pin** is **damaged** or **missing**.
- Place the heater near a wall outlet so an extension cord is not needed. If an extension cord is needed, the **gauge** of the cord **must be at least 14AWG**, and the **rating must be at least 1875 Watts**. **NEVER** use a **smaller gauge** cord with a **lower rating**. Doing so may result in **fire** or **electric shock**.
- **ONLY** use this heater on a **110~120 Volt 15 Amp grounded circuit**. **NEVER overload the circuit**. If this heater trips the circuit breaker, unplug all other appliances on the same circuit before the next use. Avoid plugging other appliances into the same circuit as this heater.
- **NEVER** plug this heater into an outlet that is **old, cracked**, or has any **loose wires or connections**. Plugging this heater into a faulty outlet could result in **electric arcing** within the outlet that could cause the **outlet** to **overheat or catch fire**.
- **ALWAYS** check your heater cord and plug connections with **each use!**

- i) **MAKE SURE** the plug fits tight in the outlet! Faulty wall outlet connections or loose plugs can cause the outlet to overheat.
- ii) **Heaters draw more current** than small appliances. **Overheating** may occur even if it has not occurred with the use of other appliances.
- iii) During use **check frequently** to see if the **plug outlet or faceplate is HOT!**
- iv) If the outlet or faceplate is **HOT, discontinue use immediately** and have a qualified electrician inspect and/or replace the faulty outlets.
- The cord supplied with the heater has a plug with two blades (live and neutral) and one round pin (ground). If a 3-slot receptacle is not available, an adapter **MUST** be used. The adapter **MUST** be **properly grounded** to the outlet box (see figure at right).



PREPARATION



This insert has front panel made of **GLASS! ALWAYS** use **extreme caution** when handling **glass**. Failure to do so could result in **personal injury or property damage**.

Remove all parts and hardware from the carton and place them on a clean, soft, dry surface. Check the parts list to make sure nothing is missing. Dispose of packaging materials properly. Please recycle whenever possible.


Tools required for assembly:



Phillips screwdriver
(Not included)


PARTS & HARDWARE

Item	Description	Qty
1	Fireplace Insert	1
2	Screws	11
3	Rubber Mat	4
4	Trim Kit	1




Trim Kit

1. Four bracket are on either side of fireplace side.
2. Slide the trim kit onto the bracket. The flanges will fit the bracket.
3. Gently push the trim kit down until fully seated.
4. Lay the heater on the floor and install the rubber mat with 4pcs screws (screws are on the bottom of the fireplace) as provided.



REMOTE CONTROL



Warning: Remote control requires two AAA batteries (Not Included)



ALWAYS unplug this fireplace heater **before assembly or cleaning, or before relocating.**

Failure to do so could result in **electric shock, fire, or personal injury.**

OPERATION



Read and understand this entire owner's manual, including **all safety information**, before **plugging in** or **using** this product. Failure to do so could result in **electric shock, fire, serious injury, or death.**

Power

Make sure the ON/OFF switch, located on the control panel, is in the OFF position. Plug the power cord into a 110~120 Volt 15 Amp grounded outlet (see **IMPORTANT SAFETY INFORMATION**).


Make sure the outlet is in good condition and that the plug is not loose. **NEVER** exceed the maximum amperage for the circuit. **DO NOT** plug other appliances into the same circuit.

Methods of Operation

CONTROL PANEL: Controls **ON/OFF, DIMMER, COLOR, TEMPERATURE, TIMER** and **HEATER**.

REMOTE CONTROL: Controls **ON/OFF, DIMMER, COLOR, TEMPERATURE, TIMER** and **HEATER**.

Control Panel and Master Power Switch Locations



Control Panel

BUTTON	ACTION /FUNCTION	INDICATION /RESULT
 ON/OFF	1. Press once to turn on flame effect, fuel bed lights, and enable control panel & remote control. 2. Press again to turn off flame effect, and shut off power to remote control, and all functions.	1. Flame effect and fuel bed turn on. Indicator light turns on. Control panel & remote control are enabled. 2. Flame effect and indicator light turns off. The control panel and remote control will not function.
 FLAME Color	The FLMAE color controls the color of the flame effect. Press the button to set the flame color to the desired option.	The flame effect cycles through three kinds of color. Orange, Blue, O&B mix. Keep pressing this button for 3 seconds, it can adjust the flame brightness.
 HEAT	Flame effect must be ON for heater to function. 1. Press once for low heat (750W). 2. Press again for high heat (1500W). 3. Press again to turn off heater.	1. Heater & fan turn on low (750W). Indicator light turns on. Warm air blows. 2. Heater & fan turn on high (1500W). Indicator light turns on. Hot air blows. 3. Heater turns off. Fans may blow air after heater is turned off to cool down.

BUTTON	ACTION /FUNCTION	INDICATION /RESULT
 TEMP.	TEMPERATURE Button: Control temperature settings to choose temperature as desired. Setting range from 62°F to 82°F.	1. Press once. Indicator light turns on. Temperature is set to 62°F. 2. Press again until desired setting is reached. LED display shows setting.
 TIMER	TIMER Button: Control timer settings to turn off fireplace as selected time. Setting range from 0 hour to 8 hours.	1. Press once. Indicator light turns on. Timer is set to hours. 2. Press again until desired setting is reached. LED display shows setting.

Remote Control Operation

NOTE: Master Power switch on control panel must be ON to use remote control.

BUTTON	ACTION /FUNCTION	INDICATION /RESULT
 ON/OFF	1. Press once to turn on flame effect, fuel bed lights, and enable control panel & remote control. 2. Press again to turn off flame effect, and shut off power to remote control, and all functions.	1. Flame effect and fuel bed turn on. Indicator light turns on. Control panel & remote control are enabled. 2. Flame effect and indicator light turns off. The control panel and remote control will not function.

BUTTON	ACTION /FUNCTION	INDICATION /RESULT
 FLAME	FLAME button: Makes flame effect dimmer and brighter. NOTE: The flame effect stays on until the power button is turned off. The flame effect must be on for the heater to turn on.	1. Press once. The Flame brightness effect gets changing. 2. Press again. Until the desired setting is reached.
 COLOR	The FLMAE color controls the color of the flame effect. Press the button to set the flame color to the desired option.	The flame effect cycles through three kinds of color. Orange, Blue, O&B mix.
 HEAT	Flame effect must be ON for heater to function. 1. Press once for low heat (750W). 2. Press again for high heat (1500W).	1. Heater & fan turn on low (750W). Indicator light turns on. Warm air blows. 2. Heater & fan turn on high (1500W). Indicator light turns on. Hot air blows. 3. Heater turns off. Fans may blow air after heater is turned off to cool down.
 TEMP.	TEMPERATURE Button: Control temperature settings to choose temperature as desired. Setting range from 62°F to 82°F.	1. Press once. Indicator light turns on. Temperature is set to 62°F. 2. Press again until desired setting is reached. LED display shows setting.

BUTTON	ACTION /FUNCTION	INDICATION /RESULT
 TIMER	TIMER Button: Control timer settings to turn off fireplace as selected time. Setting range from 0 hour to 8 hours.	1. Press once. Indicator light turn on. Timer is set to hours. 2. Press again until desired setting is reached. LED display show setting.

NOTICE	To improve operation, DO NOT press the buttons too quickly. Give the unit time to respond to each command.
---------------	--

	NEVER leave heater unattended during operation! Failure to do so could result in personal injury or property damage.
---	--

NOTICE	When the heater is first turned on, a slight odor may be present. This is normal and should not occur again unless the heater is not used for a long period of time.
---------------	--

FCC STATEMENT

Remote Control FCC Information

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a
--


residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.



Warning: Remote control requires two AAA batteries (Not Included).

CARE AND MAINTENANCE



ALWAYS turn the heater **OFF** and **unplug the power cord from the outlet** before cleaning, performing maintenance, or moving this fireplace. Failure to do so could result in **electric shock, fire, or personal injury**.

Cleaning



NEVER immerse in water or spray with water. Doing so could result in electric shock, fire, or personal injury.

Metal:

- Buff using a soft cloth, slightly dampened with a citrus oil-based product.
- **DO NOT** use brass polish or household cleaners as these products will damage the metal trim.

Glass:

- Use a good quality glass cleaner and dry thoroughly with a paper towel or lint-free cloth.
- **NEVER** use abrasive cleansers, liquid sprays, or any cleaner that could scratch the surface.

Vents:

- Use a vacuum or duster to remove dust and dirt from the heater and vent areas.
- Clean the exterior of the fireplace with a slightly damp cloth or duster.

Maintenance



Risk of electric shock! DO NOT OPEN! No user-serviceable parts inside!



ALWAYS turn the heater **OFF** and **unplug the power cord from the outlet** before cleaning, performing maintenance, or moving this fireplace. Failure to do so could result in **electric shock, fire, or personal injury**.

Electrical and Moving Parts:

- The fan motors are lubricated at the factory and will not require lubrication.
- Electrical components are integrated in the fireplace and are not serviceable by the consumer.

Storage:

- Store heater in a clean dry place when not in use.



WARNING! No other servicing should be performed by the consumer. Do not attempt to service the unit yourself.

TROUBLESHOOTING



WARNING: Turn off the appliance, unplug and let cool for at least 10 minutes before attempting to service. Only a qualified professional should attempt to service or repair the appliance.

Problem	Possible Cause	Corrective Action
No flame	1. Dimmer control button set too Low. 2. LED bulb are burned out. 3. "Flame wand" has come loose from bracket. 4. "Flame wand" motor is not functioning.	1. Push Dimmer button to increase light. 2. Contact with the technical service. 3. Remove back panel. Secure end of " flame wand" back into the support Bracket 4. Ask qualified technician for help.
The appliance turns off and will not turn back on	1. The overheat protection device in the appliance has been triggered. 2. House circuit breaker has been tripped.	1. Turn all controls off, unplug the appliance, allow to cool for at least 10 minutes, then plug back in and restart. 2. Reset house circuit breaker.
The appliance does not turn on when the button is pushed to "ON"	1. The overheat protection device in the appliance has been triggered.	1. Turn all controls off, unplug the appliance. Allow to cool for at least 10 minutes, then plug back in and restart.

Problem	Possible Cause	Corrective Action
Remote control does not work	1. Low batteries. 2. Manual control on the appliance must be "ON" before operating the remote control.	1. Replace all batteries in the remote control. 2. Push the appliance "ON" using the manual control panel, then use remote control to operate. If using the remote control the appliance, you must also turn on the appliance "ON" using the remote control