

7FT KIDS TRAMPOLINE +TIC-TAC-TOE

MODEL# 9011TS
PRODUCT MANUAL VERSION 5.20.01

FOR AGES:

3-9

WEIGHT LIMIT:

120_{Lbs} 54 Kgs

TO BUILD:



TOOLS NEEDED:

Tools Provided





CUSTOMER SERVICE





CUSTOMER SERVICE INFORMATION

Thank you for purchasing: 7FT KIDS TRAMPOLINE + TIC-TAC-TOE

MODEL# 9011TS

If you have an issue with your item, do not return. Please report items that are damaged or missing parts to the manufacturer GQ Brands within three days of delivery. Contact customer service at customerservice@gqbrands.com to open a ticket.

At GQBrands®, we want all of our customers to be completely satisfied with their purchase. Take time to review the contents of the product you have just received to make sure that all of the parts are included. If you find that any parts are missing or damaged, we will provide replacement parts at no charge within 30 days of purchase.

Please keep in mind that for select damaged part replacement requests, we will require a photo for submission.

To register you product please visit: www.globalqualitybrands.com/product-registration or scan code:



To order these parts, or if you have any other questions or concerns about this GQBrands product, please contact us at

PureFun Net **GQBrands®**

Phone: 1-866-498-5269

Email: CustomerService@GQBrands.com 4401 Samuell Blvd, Ste 150, Mesquite, TX 75149

Please be sure to include the following information when you contact Customer Service:

YOUR NAME:	RETAILER WHERE PURCHASED:
YOUR MAILING ADDRESS:	DATE OF PURCHASE:
YOUR EMAIL ADDRESS:	ORDER NUMBER: (If Available)
PRODUCT NAME:	QUANTITY NEEDED:
PRODUCT MODEL#:	SERIAL NUMBER: (On Product Frame)
PART NUMBER	

LIMITED WARRANTY

Global Quality Brands® warrants this product to be free from defects in workmanship and materials under normal use and conditions for a period of 90 DAYS FROM THE DATE OF ORIGINAL PURCHASE. This Limited Warranty is not transferable and is available only for the original purchaser of the Product. The Company's obligation under this warranty is limited to replacing or repairing the Product, at the discretion of the company.

All warranty coverage extends only to the original retail purchaser from All warranty coverage extends only to the original retail purchaser from the date of purchase, GQBrands obligation under this warranty is limited to replacing or repairing, at Global Quality Brands® option. All products for which a warranty claim is made must be received by Global Quality Brands® and accompanied by sufficient proof of purchase (photocopy of the original store receipt, indicating the date of purchase). All freight and handling fees are the responsibility of the consumer to pay, both to and from Global Quality Brands®. All warranty claims must be pre-authorized by Global Quality Brands® pre-authorization can be obtained by calling 866-408-5269 866-498-5269.

This warranty does not cover ordinary wear and tear, weathering, failure to follow directions, improper installation, improper maintenance, or acts of nature, (such as damage caused by wind, lightning, snow, water, or ice) weather damage, damage caused by unauthorized repair work or damage caused by improper use of the products are not covered by the product warranty. No other warranty beyond that specifically set forth above is authorized by GQBrands®.

GLOBAL QUALITY BRANDS® IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES ACCORDINGLY. THE ABOVE LIMITATION MAY NOT APPLY TO DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO

THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND GLOBAL QUALITY BRANDS®, SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NO APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

WHILE EVERY ATTEMPT IS MADE TO ENSURE THE HIGHEST DEGREE OF PROTECTION IN ALL EQUIPMENT, WE CANNOT GUARANTEE FREEDOM OF INJURY. THE USER ASSUMES ALL RISK OF INJURY DUE TO USE. ALL MERCHANDISE IS SOLD ON THIS CONDITION, WHICH NO REPRESENTATIVE OF GQBRANDS® CAN WAIVE OR CHANGE.





ADULT ASSEMBLY REQUIRED

CHOKING HAZARD - Small Parts **NOT** for children under 3 years of age.

Please read these warnings and the information in this manual in its entirety.

Failure to comply with the following instructions may increase the risk of serious injury and/or death:

- DO NOT allow children under the age of 3 to handle or use chalk pieces. Broken chalk or chalk remnants present a choking hazard and serious injury or death may occur.
- This unit must be assembled and disassembled by ADULTS ONLY.
- This Trampoline is suitable for use by most children 3-9 YEARS OF AGE.
- DO NOT exceed the MAXIMUM WEIGHT limit of 120 lbs (54kgs) regardless of age.
- FOR HOME USE ONLY: This Trampoline is designed for family residential use. It is NOT intended for use in commercial applications and/or use in public areas such as schools, parks, nurseries, day schools, day cares, etc.
- ALWAYS locate this equipment on a stable, level surface AT LEAST 7 feet away from any structure, obstruction, or possible hazard(s) such as walls, pools, power lines, overhangs, other playground equipment, driveways, hard surfaces and/or roadways.
- Children must be supervised at all times when using this equipment. DO NOT leave children unattended at any time.
- DO NOT attach items to the trampoline not specifically designed for this purpose.
 Especially in the case of jump ropes, chains, clotheslines, pet leashes and cables. These may cause a strangulation or physical hazard.
- This Trampoline is NOT for adult or adolescent use.
- DO NOT allow more than one child to jump on the Trampoline at any time.


- DO NOT allow children to wear glasses or helmets when using the Trampoline.
- DO NOT allow the padding cover of this trampoline to become wet. If accidental spillage occurs, immediately blot this with a damp towel and allow to dry.
- DO NOT place objects on or under the trampoline, or allow people and pets to stand or sit on, near or under the unit.
- Remove all hard or sharp objects including jewelry, eyeglasses, sunglasses or hair clips before jumping.
- Do not attempt or allow somersaults.
 Landing on the head or neck can cause serious injury, paralysis, or death, even when landing in the middle of the mat.
- Do not use if in a cast or have previous leg, arm, head, neck or back injury.
- ALWAYS secure the Trampoline against unauthorized and unsupervised use.
- Inspect legs for proper attachment or cracks, netting for tears and sagging, loose or damaged springs, mat for tears or worn stitching, and frame for sagging or cracks before use
- The product must not be used in windy conditions as wind can cause unexpected movement of the product. Wind can cause the trampoline to be lifted off the ground and become airborne. This can present a danger to individuals and to property. Winds can be especially strong in open areas, foothills, mountains, locations subject to hurricanes and tornadoes, areas between homes that create wind tunnels and anywhere else where local weather conditions can create high winds.

- We recommend that you anchor the trampoline or otherwise secure the trampoline to prevent it from moving as a result of the wind.
- If the winds are anticipated to be very strong, the trampoline should be disassembled and stored away safely until the weather conditions improve.
- Only genuine replacement parts sold through our authorized dealer are recommended. Replacement parts from other sources may not have been designed, tested or manufactured to standards. Because of this, cannot guarantee the performance and safety of the product when non genuine replacement parts are used. The use of non-genuine r replacement parts may affect any warranty claim on the product, as allowed by the law in your jurisdiction.


MODEL# 9307TS 3

PARTS LIST

1 - Jump Mat and Frame Pad




2 - Top Rail



3 - Corner Top Rail with Socket




4 - Vertical Leg Extension




5 - Plastic Vertical Leg Extension




6 - Plastic Horizontal Leg Base



7 - Galvanized Spring




8 - Straight Frame Tube



8A - Straight Frame Tube Foam




Curve Frame Tube



9A - Curve Frame Tube Foam




10 - Horizontal Tube





10A - Horizontal Tube Foam





PARTS LIST







































Place the Jump Mat and Frame Pad (1) with the Logo and Tic-Tac-Toe facing upwards.

Each corner of the Jump Mat and Frame Pad will have an opening. Slide the Straight Frame Tubes through these openings. The loop is elastic giving you enough give to stretch and insert.

Dont push the Mat all the way down, make sure to leave yourself a little room to install the springs to the mat.




Locate the R-Hook side of the Galvanized Spring (Part 7).

At the bottom of the trampoline there will be V-rings assigned to an opening of the Top Rail based on the proximity of each one.

Attach the Spring to the V-Ring using the "R"-Hook. Make sure the ends of the Springs are facing downwards to avoid punctures to the mat or injury while jumping on the trampoline.

Using the Spring Loading Tool (Part 16) pull on the "C" Hook of the Galvanized Spring and hook to the closest Spring Opening of the Top Rail.




To ensure that Jump Mat and Frame Pad won't suffer from any excessive tension that will cause ripping or tearing on the Mat, the springs must be installed in a specific order.

Follow the Spring order shown for the best way to properly install and secure the Jump Mat and Frame Pad to the Top Rails.


Once the first 16 Springs have been installed on the Top Rail, install the remaining 20 Springs.


NOTE: Failure to install the springs to the correct V-Ring and Top Rail openings and/ or not follow the Spring Order Installation as shown, may result in tearing or injury while in use.


STEP 16



All ribbons must be attached and secured to the Top Rail to make sure no skipping, tearing, or loose jumping occurs








STEP 20

Place the Enclosure Netting (11) on top of the trampoline making sure all arcs are inside.

The zipper and safety buckle must be facing the outside of the trampoline.




STEP 21


Pull the Enclosure Netting all the way to the bottom of the trampoline mat.

Place all the hoods on top of the netting to each corresponding arc.

Push the Velcro between both section to make sure the hood stays on top of the arc of the enclosure.



STEP 22




Secure on the bottom the Enclosure Ribbons to the Top Rail from the Safety Net





When the Trampoline is not in use, make sure to close the Enclosure Netting door by using the zippers.

For extra security, close the clasps from the outside as shown until the click.



FREQUENTLY ASKED QUESTIONS

- Question: "The foam padding or mat is damaged, what should I do?"
- Answer: If you are still within your warranty period (90 Days from initial purchase) you should contact customer service. You can also purchase replacement padding and mats at: www.PureFun.net
- Question: "I had a part missing from my box" or "something was damaged in shipping, can you send it to me?"

Answer: If it has been 30 days or less from the date of your initial purchase, you can contact customer service for a replacement part to be issued.

CARE & MAINTENANCE

- IMPORTANT: While no regular maintenance is required, you must inspect the trampoline before each use and replace any worn, defective, or missing parts.
- The following conditions could represent potential hazards: Missing, improperly positioned, or insecurely attached frame padding; Punctures, frays, tears, or holes worn in the bed or frame padding; Deterioration in the stitching or fabric of the bed or frame padding; Broken or missing springs; A bent or broken frame; A sagging jump mat; or sharp protrusions on the frame or suspension system; Bent or broken enclosure poles; Missing or torn foam on the poles; Torn or ripped enclosure netting; Broken or fraying zipper in the enclosure opening. Cease using trampoline immediately and secure it against unauthorized use if any of these conditions are present.
- If any part of the trampoline frame requires cleaning, simply wipe with a damp cloth. (Do not jump on the trampoline after cleaning until completely dry).
- To clean chalk from mat, wipe down net with wet rag. Allow mat to fully dry before jumping.

Thank You Coupon!

As a way of saying thank you for purchasing one of our products, here is a 10% OFF coupon for your next purchase at

www.PureFun.net Use Code: GQBRANDS10 at Checkout



