
12'X14' Metal Patio Wood Gazebo ASSEMBLY MANUAL



Pre-assembly



1.Two or more people are required for assembly.



2.You will need one or more stepladders.



3. Wearing protective gloves is recommended.



4. You may need a safety hat.



5. Please use a Phillips screw driver.



6.For ease of construction, you may need a drill.



7. You may need a safety goggle.





8.Do not fully tighten screws prior to complete assembly.


Warning & Attention


- -Try to assemble this product on the flat ground, otherwise it is difficult to carry out;
- -It would be much easier to assemble the product with three or more people;
- -After assembly, please check whether all screws are tightened, to prevent parts from falling apart.


 \triangle Use bolts to secure the frame to the ground to against the strong wind.









































































































28


(3) Repeat the above procedures to assemble the opposite side.
























































WOOD CARE GUIDELINES

Wood requires some care and attention over its lifetime to ensure a long-lasting beautiful finish. Proper cleaning and maintenance will keep your wood products looking beautiful for a long time. Please follow these guidelines to maintain your wood surfaces.

- Fadingand weathering: Wood is a natural product and is expected to change over time. Long periods of sun exposure can naturally lead to color fading. Weather extremes, temperature fluctuations, and humidity highs/lows cause wood to expand and contract, possibly leading to warping and cracking. Knots and small surface cracks are naturally occurring and do not affect the strength of the product.
- **Keepingdry:** Prolonged moisture and high or low humidity can be harmful for wood. Cracking or splitting from extremes outside of the normal humidity range of 35-65% are not covered by our warranty. Preventing prolonged exposure to moisture is advisable.
- Cleaning: Frequent light cleaning is recommended. Dust regularly using a slightly damp soft cloth, and then wipe dry (following the direction of the wood grain). For more thorough cleaning, use a soft cloth and a gentle soap solution (dilute ¼ cup mild dishwashing liquid soap with 1 gallon of warm water). Rinse with water, and then immediately dry the surfaces using a soft cloth. Do not use bleach, acid, or other solvents on any metal parts or surfaces. Minor stains or scratches can be lightly buffed with No.0000 steel wool, followed by an application of good quality wood-care oil, wiping in the direction of the grain.
- Annualsealing: It is advisable to annually maintain the wooden parts with a sealant or outdoor wax/oil to protect and enhance the wood surfaces. Twice yearly, after cleaning, apply a good quality wood-care oil or water-based sealant to the surfaces. Recommended options are outdoor water-based sealant, linseed, teak, or tung oil. Refer to the manufacturer's specific instructions for application. It is best to try on a small section of wood, then if satisfied with the result, continue the application, taking care to avoid any metal surfaces.
- For further questions and concerns, please contact: contactus24service@gmail.com



Call us First! DO NOT RETURN TO STORE

For immediate help with assembly or product information call our number: (951)213-4742

Or E-mail:

contactus24service@gmail.com

Our staff is ready to provide assistance

M-F 9:00 AM to 5:00 PM EST