




Beverage Refrigerator

Built-In / Freestanding

Model - BR 476



OWNER'S MANUAL

Please read the instructions carefully and keep for future reference. Information may be updated from time to time so please refer to the website for the latest version of the manual.

Warranty

Equator Appliances undertakes to the consumer-owner to repair or, at our option, to replace any part of this product which proves to be defective in workmanship or materials under normal personal, family or household use, in the USA and Canada, for a period of one year from the date of original purchase. For commercial use, the product is warranted for a period of 90 days. During this period, we will provide all labor and parts necessary to correct such defect, free of charge, if the appliance has been installed and operated in accordance with the written instructions with the appliance. Ready access to the appliance, for service, is the responsibility of the consumer-owner. Service would be provided from Monday to Friday between normal business hours.

Exclusions

In no event shall Equator Appliances be liable for incidental or consequential damages or for damages resulting from external causes such as abuse, misuse, incorrect voltage or acts of God. This warranty does not cover service calls which do not involve defective workmanship or materials covered by this warranty. Accordingly, diagnosis and repair costs for a service call which does not involve defective workmanship or materials will be the responsibility of the consumer-owner.

Specifically, the following work is not covered under warranty and does not constitute warranty work:

Installation - e.g. Insufficient spacing around appliance

Maintenance - e.g. Cleaning the appliance using solvents

Mishandling - e.g. Breakage of door handle

Most work is covered. The defining factor is, has the machine malfunctioned (Equator Appliances is responsible) or has the customer omitted or done something to cause the appliance to malfunction (customer is responsible). Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you.

WARRANTY SERVICE

This warranty is given by:

Equator Appliances

10222 Georgibelle Drive, Suite 200,
Houston, Texas 77043-5249

For Customer Service:

Appliance Desk

Phone/Text: 1-800-776-3538

Email: Service@ApplianceDesk.com

Web: www.ApplianceDesk.com

Business hours: 9:00 am to 5:00 pm weekdays

You can register your warranty by either of the following methods:

1. Scan QR Code



1. Open Smart Phone
2. Open Camera
3. Scan QR Code
4. Click the Link

2. Register online at ApplianceDesk.com/Warranty

GENERAL

Since it is the responsibility of the consumer-owner to establish the warranty period by verifying the original purchase date, Equator Appliances recommends that a receipt, delivery slip or some other appropriate payment record be kept for that purpose.

This warranty gives you specific legal rights, and you may also have other rights which vary from State to State.

All rights reserved. Manual subject to change without notice

Safety

Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

Refrigerant and foaming material is flammable. Take precautions during handling, installation, and maintenance.

Ensure that the refrigerant circuit is not damaged.

Keep ventilation openings clear of obstructions.

When positioning the appliance, ensure the electrical cord is not trapped or damaged.

Do not place multiple portable socket-outlets at the rear of the appliance.

Never unplug the appliance by pulling on the power cord. Grip the plug firmly and pull straight out to remove from wall socket.

Do not use a damaged power cord.

Do not use an extension cord.

Children should be supervised to ensure that they do not climb on or play with the appliance.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.

Safe Disposal

Before discarding the appliance, remove the door in order to prevent risk of child entrapment.

Please dispose of this appliance in accordance with local regulations.


Installation Spacing Requirements

The appliance can be used as built-in or freestanding.

Place the appliance on a flat level surface. Whether installing under a cabinet as a built-in unit or freestanding, ensure to leave adequate space around the unit.

Leave at least:

- Half an inch on either side of the unit
- Half an inch between the back of the unit and the wall
- Half an inch above the unit



Installation and Preparation

Do not tilt the appliance at an angle of more than 45° when moving it.

Do not move the appliance while it is loaded with bottles.

Place the appliance away from sources of heat and high humidity, and also away from areas of moisture and exposure to cold temperatures.

The appliance should be placed in a room where the temperature is between 32°F-101°F (0 to 38°C).

After moving the appliance in place, let it stand upright for 10 minutes before turning it on.

Plug the appliance into a dedicated, properly installed-grounded wall outlet. Do not under any circumstances cut or remove the third (ground) prong from the power cord.

Check the plug and cable before you connect the power and ensure the correct voltage is 110V / 60Hz.

Ensure that the plug is accessible.

Place the appliance on a flat level surface. The feet of the appliance can be adjusted to make it level.


Ensure the bottom vent is not obstructed.

Before use, clean the outside and inside surfaces with a damp soft cloth.

When loading bottles and cans, ensure items are arranged evenly, so that weight is not concentrated in one area of the unit. Ensure items do not touch the back of the cabinet.

Installing Door Handle

Install the handle according to the following four steps:




- 1. Move door seal
- 2. Insert screws
- 3. Using screwdriver fasten door handle
- 4. Replace door seal to original position

Specifications Table

Model	BR 476
Capacity	4.76 cu. ft.
Storage	108 cans + 6 wine bottles
Electrical	110V / 60Hz
Refrigerant	R600a
Temperature Range - Upper Zone	34° - 65° F
Net Weight	117 lbs
Product Dimensions (HxWxD)	33.9" x 23.4" x 23.6"

Door Reversal

The direction of the door swing can be reversed by following the instructions below.




Use a screwdriver to remove the upper and lower hinges of the door and remove the door.

Remove the handle, hole cap and door stopper.
Install them on the other side of the cabinet.

Take out the upper and lower door hinges from the accessory bag and install the door in the corresponding position on the other side.


Ensure the hinge holes and screws are aligned and tighten the screws to complete the door reversal process.



Operation

This appliance is intended for household use and for the storage of beverages. Do not overload the cabinet and ensure that the door can be closed firmly.

The appliance has dual temperature zones, which allows for different temperature settings in the same appliance depending on the items that are being stored.



Press the Power ON/OFF button to turn the appliance on.
Press the Light ON/OFF button to turn on the LED light inside the appliance.

The temperature range of the appliance is:

- 33.8°F - 50°F in the upper zone
- 41°F - 71.6°F in the lower zone

The temperature of the upper zone must be set less than the temperature in the lower zone. Increase or decrease the temperature by pressing the Up and Down arrows.

Pressing the temperature Up and Down buttons for 5 seconds will display the temperature as °C or °F.



If the power goes off or if the appliance is unplugged, the temperatures in the appliance will be saved to memory and the same temperature settings will be activated when the appliance restarts.

Maintenance

Make sure the power cord is unplugged before moving or cleaning the back of the appliance.

Clean the outside and inside of the appliance regularly, using water and mild detergent.

Replace the activated charcoal filter every 6 months. The charcoal filter is located on the rear panel inside the unit. To order charcoal filter, contact Customer Service (see p.2)



Troubleshooting

Problem	Possible Cause and Solution
Not Working	<ul style="list-style-type: none">• Check the power source.• Check if it is plugged in correctly to the power source.
Not Cooling	<ul style="list-style-type: none">• Temperature is not set correctly. Adjust the temperature.• Move unit if it is near heat source or direct sunlight• Check for proper ventilation and that air inlet or outlet is not blocked.• Door opened frequently or not shut properly.• Door seal is damaged.• Too many bottles stored on the same shelf.
Too much noise	<ul style="list-style-type: none">• Appliance not placed on flat surface or not level.• Adjust the feet to level it.• Some parts are loose causing rattling.• The appliance is against a wall.
Door does not close properly	<ul style="list-style-type: none">• Check the seal.• Shelves are not positioned properly.• Adjust the shelves.• Check that bottles are stored correctly and fit in the cabinet.

The following are normal:

- Moisture on the glass door – wipe with dry cloth
- Sound of fluid is the compressor when it is starting or stopping
- Flowing sound of refrigerant in the refrigeration system
- Condensation forming inside the cabinet – wipe with dry cloth

California Proposition 65

WARNING: This product contains chemical known to the State of California to cause cancer and birth defects or other reproductive harm.

