

This is NOT a permanent structure. The canopy top should never be left on during periods of extended or heavy rain nor any inclement weather where high winds or wind gusts can occur. if left up, damage to the gazebo and surroundings can occur.

If you have questions or concerns. Please contact us via email at service@domioutdoorliving.com

10'×14' Gazebo ASSEMBLY MANUAL



MODEL#: LGCD1625

Missing part? Damaged? Contact us via email at service@domioutdoorliving.com

www.domioutdoorliving.com

Copyright 2023–2025 domi outdoor living LLC. All Rights Reserved.

Pre-assembly



1.Two or more people are required for assembly.



2.You will need one or more stepladders.



3. Wearing protective gloves is recommended.



4.You may need a safety hat.



5.Please use a Phillips screw driver.



6.For ease of construction, you may need a drill.



7.You may need a safety goggle.



8.Do not fully tighten screws prior to complete assembly.

Warning & Attention

-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;

-It would be much easier to assemble the product with three or more people;

-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

 \blacktriangle Use bolts to secure the frame to the ground to against the strong wind.





If the deck is hard wood and the depth of it is over 3 inch, you can use 5/16 in. ×4 in. Structural Wood Screw to mount the gazebo.



















































