


## BURLINGTON / PORTLAND / BERKSHIRE

---

### TALL TV MEDIA STAND

MODEL # AXCRBUR17-MAH





**Questions, problems, assembly help, missing parts?**

No need to return the product, we will gladly help and ship your replacement parts free of charge

Please call Customer Service at 1-866-518-0120 ext. 262

Monday to Friday between 9 am – 4 pm EST

or go to

[www.simpli-home.com/parts request](http://www.simpli-home.com/parts request)

In order to assist you in a timely manner, please have the following information ready:

Model # \_\_\_\_\_ Part Number or Letter \_\_\_\_\_

Purchased at \_\_\_\_\_ Date of Purchase \_\_\_\_\_

**If you wish to return the product, please contact the retailer where the product was purchased.**

**IMPORTANT :** Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

## SAFETY INFORMATION

**CAUTION:** Injuries and damage can occur from furniture tip over if product is not properly anchored to the wall. Use the Furniture Anti-Tipping Restraint provided with the product. Consult our assembly instructions for help.

If the Furniture Anti-Tipping Restraint kit is not in the box, please contact our customer service department in order to obtain another kit before using the furniture.

Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all of the parts and hardware required. Hardware package may have spare parts.

**WARNING:** This item contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets. We recommend that you assemble this unit on a carpeted floor to avoid scratches. If using power tools, set the tool to low torque to avoid damage.

**May require 2 people for ease of assembly.**

**IMPORTANT :** Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

## CARE and MAINTENANCE

Perhaps the greatest environmental damage to wood furniture comes from wide swings in relative humidity (RH) in our homes. Wood absorbs and desorbs water as relative humidity rises and falls, and in doing so it swells and shrinks. Making matters worse, it expands and contracts unequally along different grain directions. As humidity changes, the components of wooden objects are continually pushing and pulling against each other. This pressure often results in parts of furniture no longer fitting together closely or becoming distorted or breaking from their own internal stresses.

The response to relative humidity changes begins with determining the annual average RH for your particular space. Then try to keep the RH in the space where your furniture is as close to that average as possible, generally within about 10% up or down. De-humidify in the summer and humidify in the winter.

Be aware that raising the temperature lowers the humidity and vice versa. Thus, modern heating systems, which can drive down interior RH in the winter, almost invariably cause problems for furniture. To counteract their effect, you can either modify the RH by keeping furniture containing spaces cooler in the winter or most importantly, have a good working humidifier for your home. A humidistat automatically works to balance the humidity in your home so it is constant. Dry indoor air can suck enough moisture from its surroundings to do permanent damage to wood, causing it to crack or split.

Remember, that not all woods are created equal. Two factors that help determine how rapidly a wood will lose moisture are pore size and surface hardness. A piece made from a dense and hard wood will dry less rapidly than pieces made from softer woods.


Furniture that is sealed and lacquered will lose moisture more slowly than an unfinished piece while pieces with veneer finishes are not only stronger, but lose moisture more slowly than other finishes.

### **To help protect your wood furniture, take these steps:**

- Use a humidifier, preferably one with an automatic control system that can sense the humidity level and adjust itself accordingly. Don't over-humidify; that can damage wood by causing it to expand and contract.
- Keep furniture out of direct sunlight, which can cause it to dry out, crack and warp.
- If you can avoid it, don't put furniture near heating vents. If you must, keep the piece 3 to 4 inches away from the wall, giving the heat and air space to circulate.
- Dust with soft dry cloth.
- Do not use liquid or aerosol products.
- To avoid marking, do not place rubber on surface (foot pads, etc.)
- For soil build-up, wipe with damp cloth & dry.
- Do not use abrasive cleaners.


## PARTS DESCRIPTION

**A**




TOP  
QTY 1

**BL**




LEFT SIDE  
QTY 1

**BR**




RIGHT SIDE  
QTY 1

**C**




BOTTOM SHELF  
QTY 1

**DL**




LEFT DIVIDER  
QTY 1

**DR**




RIGHT DIVIDER  
QTY 1

**E**




CENTRE SHELF  
QTY 1

**F**




CABINET SHELF  
QTY 1

**G**




CABINET SHELF  
QTY 4

**H**



BACK PANEL  
QTY 1

**I**



BACK PANEL  
QTY 1

**JL**




LEFT BACK PANEL  
QTY 1

**NEED HELP?** For help with assembly or if you are missing a part,  
Please call customer service at 1-866-518-0120 ext. 262 (9 am to 4 pm EST)


## PARTS DESCRIPTION

JR




RIGHT BACK PANEL  
QTY 1

KL




LEFT DOOR  
QTY 1

KR




RIGHT DOOR  
QTY 1

L




DRAWER FRONT  
QTY 2

ML




LEFT DRAWER SIDE  
QTY 2

MR




RIGHT DRAWER SIDE  
QTY 2

N



DRAWER BACK  
QTY 2

O




DRAWER BOTTOM  
QTY 2

**NEED HELP?** For help with assembly or if you are missing a part,  
Please call customer service at 1-866-518-0120 ext. 262 (9 am to 4 pm EST)


## HARDWARE DESCRIPTION

1



ALLEN KEY SCREW  
M6 X 30 mm  
QTY 20

2




CAM LOCK PIN  
CAM LOCK  
QTY 26 SETS

3




WOOD DOWEL  
Ø8 X 30 mm  
QTY 8

4




ALLEN KEY  
QTY 1

5




PHILLIPS SCREW ROUND HEAD  
M4 X 15 mm  
QTY 27

6




SHELF SUPPORT  
QTY 30

7




PHILLIPS SCREW  
M3 X 12 mm  
QTY 12

8




PHILLIPS SCREW  
M3 X 15 mm  
QTY 8

9




MAGNET AND PLATE  
QTY 2 SETS

10




HANDLE  
M4 x 12 mm  
QTY 2 SETS

11






FURNITURE TIP OVER RESTRAINT  
QTY 1 SET



Required -  
Flathead screwdriver  
Phillips screwdriver  
Rubber mallet  
**Not Included**


**NEED HELP?** For help with assembly or if you are missing a part,  
Please call customer service at 1-866-518-0120 ext. 262 (9 am to 4 pm EST)



Warning Label




## STEP 1




1. Attach four Cam Lock Pins (2) to back of Drawer Front (L).
2. Align Cam Lock Pins with guide holes and attach Drawer Sides (ML, MR).
3. Insert two Cam Locks (2) into guide holes on each Drawer Side (ML, MR).
4. Use flathead screwdriver to secure Cam Locks.

## STEP 2





1. Slide Drawer Bottom (O) firmly into slots on Drawer Sides (ML, MR) and Drawer Front (L).

## STEP 3



1. Align Drawer Back (N) with Drawer Bottom (O) and press firmly into slot .
2. Attach Drawer Back (N) using two Allen Key Screws (1) through guide holes on each side (ML, MR) .
3. Use Allen key (4) to tighten. Do not over-tighten.


## STEP 4




**NOTE:** The screwdriver is not included in the hardware pack.

1. Use Phillips Screwdriver to attach Handle (10) to Drawer Front (L) .

Repeat Step 1-4 for the second drawer.




## STEP 5




1. Attach three Cam Lock Pins (2) into pre-drilled holes on each Divider (DL, DR).
2. Align Cam Lock Pins with guide holes and attach Centre Shelf (E).
3. Insert six Cam Locks (2) into guide holes on Centre Shelf (E).
4. Use a flathead screwdriver to tighten Cam Locks. Do not over-tighten.

## STEP 6




1. Attach Dividers (DL, DR) to Bottom Shelf (C) using six Allen Key Screws (1) through guide holes.
2. Use Allen Key (4) to tighten screws. Do not over-tighten.

## STEP 7




1. Insert four Dowels ③ into guide holes on Bottom Shelf ①.
2. Use rubber mallet to tap Dowels ③ into bottom of holes securely. 1/2 length of Dowels should be exposed.
3. Attach three Cam Lock Pins ② into pre-drilled holes on each Side ①, ②.
4. Align Dowels ③ with guide holes of Sides ①, ②.
5. Align Cam Lock Pins with guide holes and attach Bottom Shelf ①.
6. Insert six Cam Locks ② into guide holes on Bottom Shelf ①.
7. Use flathead screwdriver to secure Cam Locks. Do not over-tighten.

## STEP 8




1. Insert two Dowels ③ into guide holes at top corners of each Side ②BL, ②BR.
2. Use rubber mallet to tap Dowels ③ into bottom of holes securely. 1/2 length of Dowels should be exposed.
3. Attach six Cam Lock Pins ② into pre-drilled holes at the bottom of Top ①A.
4. Align Cam Lock Pins with guide holes and attach Sides ②BL, ②BR.
5. Align guide holes on bottom corners of Top ①A with Dowels ③ in Sides ②BL, ②BR.
6. Insert three Cam Locks ② into guide holes on each Side ②BL, ②BR.
7. Use flathead screwdriver to secure Cam Lock.
8. Use three Allen Key Screws ① attach Top ①A to each Divider ②DL, ②DR through guide holes from Dividers. Do not over-tighten.

## STEP 9




1. Use Phillips Screws Round Head ⑤ to attach Back Panels ①②③④ through guide holes from Back Panels to the back of TV Stand.
2. Use Phillips screwdriver to tighten screws. Do not over-tighten.

## STEP 10



1. Attach hinges on Doors (KL), (KR) to Sides (BL), (BR) using Phillips Screws (7) into pre-drill holes:
  - Using Phillips screwdriver to attach Screws (7) at middle hole of hinges for both top & bottom hinges.
  - Adjust the door to ensure they are aligned straight & square with bottom shelf & side.
  - Using Phillips screwdriver to tighten the rest of screws (7) into pre-drill holes ( top & bottom holes on hinges).
2. Attach Magnet Plates (9) to bottom corner of Doors (KL), (KR) using Phillips Screws (8) into pre-drilled holes on Doors (KL), (KR).
3. Attach Magnets (9) using Phillips Screws (8) into pre-drilled holes on Bottom Shelf (C).


## STEP 11



1. Use four Shelf Supports ⑥ for each Shelf ⑦, ⑧ in desired location .
2. Two Shelf Supports ⑥ may be used on back top of each Shelf ⑦, ⑧ as a tipping restraint.



## STEP 12



1. Insert assembled drawers into glides on assembled TV

## FURNITURE TIP OVER RESTRAINT ASSEMBLY




### WARNING


Serious or fatal crushing injuries can occur from furniture tip-over.

If the furniture tip over restraint kit is not in the box, please contact our customer service department in order to obtain another kit before using the furniture.

### STEP 13




**NOTE:** The screwdriver is not included in the hardware pack.




## FURNITURE TIP OVER RESTRAINT ASSEMBLY

### Furniture Tip Over Restraint Instructions:


1. Attach one of the mounting brackets securely to the back edge of the furniture. Use the shorter screw.



2. Determine where furniture is to be placed and mark location on the wall for mounting bracket screw hole approximately 2 inches **below** the bracket mounted to the furniture.



3. Drill a 3/16 inch hole in the wall. Press the plastic anchor into the hole and gently tap until the flange on the anchor is against the wall surface.
4. Position the bracket over the anchor and use the longer screw to securely attach the bracket to the wall.
5. Place the furniture so the back edge is in line with the bracket on the wall.
6. Lace an end of the nylon zip-tie strap down through each bracket. Bring both ends together and slide the smooth side upright through the square-shaped end and pull through to create the "locked" position.
7. Check to make sure the strap is securely laced and locked to the brackets.



- **DO NOT** place heavy objects in top drawers
- **DO NOT** let children climb or hang on drawers, doors or shelves



## WARRANTY

Thank you for purchasing a **Simpli Home – Wyndenhall – Brooklyn + Max** product. These products have been made to demanding, high-quality standards and are guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase. This warranty does not affect your statutory rights.

In case of any malfunction of your product (failure, missing parts, etc.) please contact us at our toll free service line at 1-866-518-0120 ext. 262 from 9 am to 4 pm, Monday to Friday, Eastern Standard Time or by email at [customerservice@simpli-home.com](mailto:customerservice@simpli-home.com).

We reserve the right to repair or replace the defective product, at its discretion.

This product is guaranteed for 12 months if used for normal purposes. Any warranty is invalid if the product has been overloaded or subject to neglect, improper use or an attempted repair by other than an authorized agent. Heavy-duty or daily professional/commercial usage are not guaranteed.

Due to continuous product improvement, we reserve the right to change the product specifications without prior notice.