



Dishwasher SHE88PZ65N, SHX88PZ65N, SHV88PZ63N, SHXM78ZH5N



en-us Operating instructions

### **Table of contents**

| $\triangle$       | Safety Definitions5                   |
|-------------------|---------------------------------------|
| $\boxed{\Lambda}$ | IMPORTANT SAFETY INSTRUCTIONS         |
|                   | Causes of Damage11                    |
| $\bigcirc$        | Getting Started                       |
|                   | Home Connect                          |
|                   | Water softening system / special salt |
| *                 | Rinse Aid                             |
|                   | Loading the Dishwasher 24             |
|                   | Detergent36                           |
| P                 | Dishwasher Cycles38                   |
| P+                | Dishwasher Cycle Options39            |
|                   | Operating the Dishwasher42            |
| *************     | Care and Maintenance47                |
| (P) o             | Troubleshooting52                     |
| (for              | Customer Service59                    |
|                   | Statement of Limited Product Warranty |

Dear Valued Customer,

Thank you for selecting a Bosch<sup>®</sup> dishwasher. You have joined the many consumers who demand quiet and superior performance from their dishwashers.

This manual was written with your safety and convenience in mind, and the information contained herein is very important. We highly recommend that you read this manual before using your dishwasher for the first time.

To learn more about your dishwasher and available accessories, as well as many other top quality Bosch appliances, visit our web site at:

www.bosch-home.com/us (USA) or www.bosch-home.ca (Canada)

While there, don't forget to register your new dishwasher by clicking on the "Support" tab or filling out the product registration card enclosed with your new unit.

If you have any questions or comments, please contact us by phone at:

1-800-944-2904

or write us at:

BSH Home Appliances Corporation 1901 Main Street, Suite 600 Irvine, CA 92614

## **Safety Definitions**

### **▲** WARNING

This indicates that death or serious injuries may occur as a result of non-observance of this warning.

### **A** CAUTION

This indicates that minor or moderate injuries may occur as a result of non-observance of this warning.

### NOTICE

This indicates that damage to the appliance or property may occur as a result of non-compliance with this advisory.

**Note:** This alerts you to important information and/or tips.



READ AND SAVE THESE INSTRUCTIONS

This dishwasher is provided with Installation Instructions and this Use and Care Manual, Read and understand all instructions before using the dishwasher.

This dishwasher is intended for use up to a maximum altitude of 13,000 ft (4,000 meters) above sea level.

To reduce the risk of fire, electrical shock, or serious injury, observe the following:



### **WARNING**

RISK OF INJURY OR DEATH! Misuse of the dishwasher can result in serious injury or death. Do not use the dishwasher in any way not covered in this manual or for any purpose other than those explained in the following pages.



### ▲ WARNING

**RISK OF INJURY!** Severe injury and/or product damage could result from the use of unauthorized service technicians or non-original replacement parts. All repairs must be performed by an authorized service technician using only original equipment factory replacement parts.

### **▲** WARNING

RISK OF ELECTRICAL SHOCK OR FIRE!

Electrical shock or fire could result if the electrical supply for the dishwasher covered in this manual is incorrectly installed or if the dishwasher has been improperly grounded. Do not use the dishwasher covered in this manual unless you are certain the electrical supply has been correctly installed and the dishwasher has been properly arounded.



READ AND SAVE THESE INSTRUCTIONS

### **▲ WARNING**

### RISK OF EXPLOSION!

Under certain conditions, hydrogen gas may be produced in a hot water system that has not been used for two weeks or more. Hydrogen gas is explosive. Before using a dishwasher that is connected to a hot water system that has been unused for two weeks or longer, turn on all hot water faucets and let the water flow from each for several minutes. This will release any accumulated hydrogen gas. As the gas is explosive, do not smoke or use an open flame during this time.

When cleaning your dishwasher with any

cleaning agent, remove all cookware, utensils or any foreign material from inside. Some cleaning agents are highly acidic and/or caustic alkaline, which can cause hydrogen gas to form if aluminum material is also inside the dishwasher tub. Hydrogen gas is explosive. Refer to the Care and Maintenance section of the dishwasher Use and Care manual for instructions on how to properly clean your dishwasher.

### **▲ WARNING**

**HEALTH HAZARD!** Never use harsh chemicals to clean your dishwasher. Some bleach-based products can damage your dishwasher and may present health hazards!

### **GROUNDING INSTRUCTIONS**

This appliance must be grounded to a metal, permanent wiring system or an equipment grounding conductor must be run with the circuit conductors and connected to the equipment grounding terminal or lead on the dishwasher. See the Installation Instructions included with this dishwasher for more information on electrical requirements.

### **▲ WARNING**

RISK OF ELECTRIC SHOCK! This appliance must be grounded. In the event of a malfunction or breakdown, grounding will reduce the risk of electric shock by providing a path of least resistance for electric current. This appliance is equipped with a cord having an equipment-grounding conductor.

Improper connection of the equipment-grounding conductor can result in risk of electric shock. Check with a qualified electrician if you are in doubt whether the appliance is properly grounded.



READ AND SAVE THESE INSTRUCTIONS

### **Safe Operation**

Use this dishwasher only for its intended function, which is the washing of household dishware and kitchenware rated as dishwasher safe.

Use only detergents or rinsing agents recommended for use in a dishwasher, and keep them out of the reach of children.

### **A** CAUTION

When loading items to be washed:

- Locate sharp items so they are not likely to damage the door seal.
- Load knives and other sharp utensils with their HANDLES UP to reduce the risk of cut-type injuries.
- Do not wash plastic items unless they are marked "dishwasher safe" or the equivalent. For plastic items not so marked, check the manufacturer's recommendations.
- Do not operate your dishwasher unless all enclosure panels are in place.
- Do not tamper with or override controls and interlocks.

Do not abuse, sit or stand on the door or dish racks of the dishwasher.

### **WARNING**

### **RISK OF INJURY!**

To avoid risk of injury, always use caution when opening the door during or following a wash cycle as hot water or steam may escape. Do not fully open the door until water noises have stopped and steam has subsided.

### **▲** WARNING

### CHILD SAFFTY!

- To reduce risk of injury, do not allow children to play in or on the dishwasher
- When children become old enough to operate the appliance, it is the responsibility of the parents/legal guardians to ensure the children are instructed in safe practices by qualified persons

NSF/ANSI 184 Certified residential dishwashers are not intended for licensed food establishments.



READ AND SAVE THESE INSTRUCTIONS

### **Proper Care and Maintenance**

Remove the dishwasher door to the washing compartment when removing an old dishwasher for service or discarding.

To avoid floor damage and possible mold growth, do not allow wet areas to remain around or under the dishwasher.

Note: To avoid dishwasher damage, do not allow water to remain in your dishwasher systems through extended periods of freezing temperatures. Freezing temperatures can damage the water fill valve and potentially other components of your dishwasher.

### **NOTICE**

It is highly recommended for the end user to become familiar with the procedure to shut off the incoming water supply and the procedure to shut off the incoming power supply. See the Installation Instructions or contact your installer for more information.



READ AND SAVE THESE INSTRUCTIONS

### **Proposition 65 Warning:**

This product may contain a chemical known to the State of California, which can cause cancer or reproductive harm. Therefore, the packaging of your product may bear the following label as required by California:

STATE OF CALIFORNIA PROPOSITION 65 WARNING:

Cancer and Reproductive Harm - www.P65Warnings.ca.gov


### A Causes of Damage


#### **NOTICES**

- Never use steam cleaning products to clean your dishwasher. The manufacturer will not be liable for the possible damages or consequences.
- Bleach-based wipes can cause stainless-steel doors and tubs to rust.
- Using harsh chemicals (e.g. bleach), abrasive cleaners, scouring pads (metal or plastic), or abrasive cloths/paper towels can damage your dishwasher's exterior door panel, fascia panel and buttons.
- To avoid dishwasher damage, do not load the dishwasher with paper products, plastic bags, packing materials or anything other than normal, dishwasher safe dishware and kitchenware.

### Getting Started

### **Appliance overview**





The numbers stated below refer to the overview images on the previous page of this manual.

### Operating panel

- On/Off button
- 2 Wash cycles\*\*
- 3 Info button i
- 4 Digital display
- 5 Rinse aid refill indicator
- 6 Salt refill indicator
- 7 Selection buttons
- 8 Delay start / < button</p>
- 9 Remote start / > buttton
- 10 Wash cycle options\*\*
- 11 START button
- 12 Door handle\*
- 13 Front display\*
- \* optional feature which may or may not be included with your dishwasher.
- \*\* the wash cycles and options will vary by model

### Dishwasher interior components

- 20 Interior light \*
- 21 Third rack
- 22 Upper rack
- 23 Upper spray arm
- 24 Detergent tab tray
- 26 Zeolite outlet cover (zeolite container)
- 27 Lower spray arm
- Dispenser for special saltFilters
- 30 Silverware basket \*
- 31 Lower rack
- 32 Rinse aid dispenser
- 33 Detergent dispenser
- 34 Lock for detergent dispenser
- 35 Rating plate
- \* optional feature which may or may not be included with your dishwasher.

### **Display indicators**

0:00 Cycle time remaining \*

Refill rinse aid indicator Lights up when rinse aid is

S Refill salt indicator Lights up when salt is low

### Info button

The Info button 3 can be used to display additional wash cycle information.

- 1. Press the Info button 3.
- 2. Press the wash cycle button. Information on the selected wash cycle is indicated on the display window at the top  $\boxed{4}$ .
- 3. To leave, press Info button 3.

### Time setting

When the appliance is switched on for the first time, the time starts at 12:00 o'clock.

### Set the time as follows:

- 1. Open the door.
- 2. Switch on On/Off switch 1.
- 3. Press Info button 3 for 3 seconds until the following text is indicated on the display window at the top  $\boxed{4}$ :

Scroll with <>

Set with - +

Leave with Setup 3 sec.

- 4. Keep pressing button > 8 until the time setting is indicated on the display window at the top 4.
- Make the setting with setting buttons + - 7. If the selection buttons + - 7 are held down, the set values are changed in 10-minute increments.
- 6. Press and hold the Info button 3 for 3 seconds.

The selected setting has now been stored.

**Note:** If the appliance was disconnected from the power supply for a prolonged period, the time starts at 12:00 o'clock. Set the time.

## Switching on the appliance for the first time

When the dishwasher is switched on for the first time, you are taken directly to the settings for switching on the appliance for the first time.

The following text is indicated on the display window at the top 4:

# Scroll with < > Set with + Leave with Setup 3 sec.

The required settings for switching on the appliance for the first time are listed in the table below.

### Change the setting as follows:

- 1. Keep pressing button > 8 until the required setting is displayed.
- 2. Make the selection with setting buttons + 7.
- Press and hold the Info buttonfor 3 seconds.

The selected setting has now been stored.

| Settings<br>Switching on the appli-<br>ance for the first time | Factory setting  | Infotext<br>by pressing Info button   |
|--|------------------|---|
| Language   | American English | Language selection.   |
| Time format  | 12h              | 12h or 24h.   |
| Time setting   | 12:00            | Set the current time.   |
| Water hardness   | °E0-8 Soft       | Setting water hardness. When using Multitabs, select the lowest setting.    |
| Rinse aid dispenser  | Level 5          | Amount of rinse aid affects drying. When using Multitabs, select setting 0. |

### **Settings**

The dishwasher has been preset with certain settings for your convenience. You can change these factory settings.

### Change the setting as follows:

- 1. Open the door.
- 2. Switch on On/Off switch 1.
- Press Info button 3 for 3 seconds until the following text is indicated on the display window at the top 4:
   Scroll with <>

Set with - +

Leave with Setup 3 sec.

- 4. Keep pressing button > 8 until the required setting is displayed.
- 5. Make the selection with setting buttons + 7.

6. Press and hold the Info button 3 for 3 seconds.

The chosen setting has now been stored.

You have the option of resetting all changed settings back to the original factory settings.

**Note:** When you reset your dishwasher to the factory settings, you are taken directly to the settings for switching on the dishwasher for the first time.

| Setting                | Factory setting          | Infotext<br>by pressing Info button   |
|------------------------|--------------------------|---|
| Time setting           | 12:00                    | Set the current time.   |
| Time format            | 12h                      | 12h or 24h.   |
| Time display           | Time                     | Show end of wash cycle with display "Finish in" or "Finish at".               |
| Language               | American English         | Language selection.   |
| Water hardness         | °E 0                     | Setting water hardness. When using Multitabs, select the lowest setting.      |
| Rinse aid disp.        | Level 5                  | Amount of rinse aid affects drying. When using Multitabs, select setting 0.   |
| Sensor setting         | Standard                 | Adjusting water clarity detection for best cleaning results.                  |
| Extra dry              | Off                      | Improved drying for glasses and plasticware.                                  |
| Eco forecast           | Off                      | Show the water and energy consumption.  |
| Auto Power Off         | Off                      | Appliance automatically switches off at end of rinsing process.               |
| Emotion Light *        | On                       | Interior light.   |
| Front display *        | On                       | The front display can be selected.  |
| Remaining time proj. * | On                       | While wash cycle is running, status information is projected onto floor.      |
| Infolight *            | On                       | Light is projected to signal an active wash cycle.                            |
| Start program          | Auto 130-150° F          | When switching on, the last selected wash cycle appears.                      |
| Tone volume            | Level 2                  | Volume of signal at end of wash cycle.  |
| Button volume *        | Level 2                  | Volume when using buttons.  |
| Wi-Fi                  | on/off                   | Switch wireless network connection on or off.                                 |
| Network login          | Manual or<br>Autom./ WSP | Check WPS function on router. No WPS function: Manual WPS function: Automatic |
| Connect to the app     | Start with +             | Connect appliance to mobile terminal device.                                  |
| Greeting               | On                       | When switching on the appliance, the brand logo can be deselected.            |
| Factory setting        | Reset                    | Resetting to the factory setting.   |

### \* depending on the features of your dishwasher

#### Notes

- The "Network login" menu option is only available if Wi-Fi has been switched on.
- The "Connect to App" menu option is only available if a connection to the home network has been established.



### **Home Connect**

This dishwasher is Wi-Fi capable and can be remotely controlled via a mobile device.

If your dishwasher does not connect to the home network, you can also operate the dishwasher manually by pressing the buttons.

Refer to appliance overview for the location of the buttons.

→ "Appliance overview" on page 12

### Info button

The Info button 3 can be used to display additional wash cycle information.

- 1. Press the Info button 3.
- 2. Press the wash cycle button. Information on the selected wash cycle is indicated on the display window at the top 4.
- 3. To leave, press info button 3.

### Setting up the app

To be able to operate the appliance via Home Connect, the Home Connect app must be installed on your mobile device.

Observe the supplied Home Connect documents with regard to this.

Follow the steps specified by the app to implement the settings.

### **Setting up Home Connect**

You can set your dishwasher by pressing the remote start button 9 or proceed as follows:

- 1. Open the door.
- 2. Switch on the On/Off switch 1.
- 3. Press Info button 3 for 3 seconds until the following text is indicated on the display window at the top 4:

Scroll with <>

### Set with - + Leave with Setup 3 sec.

- Keep pressing button > 8 until the required setting is indicated on the display window at the top 4.
- Make the setting with setting buttons + 7. See table in section → "Settings" on page 14
- 6. Press and hold the Info button 3 for 3 seconds.

The chosen setting has now been stored.

### Wi-Fi 🛜

In the Wi-Fi menu you can activate the wireless network connection with "on" and deactivate it with "off".



#### **Notes**

- If you have selected the Wi-Fi "off" setting, the "Network login" and "Connect to App" settings are not available.
- Remote control of the appliance requires a stable wireless network connection.

### **Network login**

The "Network login" menu option is not available unless you have activated Wi-Fi.

In the "Network login" menu you can select between "Autom./WPS" and "Manual" to connect the dishwasher to your home network.



**Automatic:** Connect to the home network using the WPS function of your router.

Press WPS button on the router 01m47s

Manual: Connect your mobile device to the Home Connect network. The network settings are then manually entered using the Home Connect App to connect to your home network.

Following successful connection, the following text is indicated on the display window at the top 4.



Observe the supplied Home Connect documents with regard to this.

### **Connect to App**

The "Connect to App" menu option is not available unless there was a connection to the home network.

The "Connect to App" setting establishes the link between the dishwasher, App and your user account.



Following successful connection, the following text is indicated on the display window at the top 4.



Observe the supplied Home Connect documents with regard to this.

### About data protection:

When your Home Connect dishwasher is connected for the first time to a WLAN network which is connected to the Internet, your Home Connect dishwasher transmits the following categories of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the installed Wi-Fi communication module).
- Security certificate of the Wi-Fi communication module (to ensure a secure IT connection).
- The current software and hardware version of your dishwasher.
- Status of any previous resetting to factory settings.

This initial registration prepares the Home Connect functions for use and is activated the first time you use these Home Connect functions. Please note that the Home Connect functions can be used only in conjunction with the Home Connect App. Information on data protection can be accessed in the Home Connect App.

### Remote start button

Once the dishwasher is connected to the home network, press the remote start button 9 to control the dishwasher from your device.

If the dishwasher has still not logged into Home Connect, access the Home Connect settings by pressing the remote start button 9.

Follow the directions in Home Connect app.

Note: Your dishwasher is protected against unintentional operation. If the appliance door remains open for more than 4 seconds after pressing the Remote Start button 9, the operation will be paused. Press the Remote Start button 9 again and close the appliance door. Also see section → "Protection against unintentional operation" on page 42

#### **Notes**

- When the login process is complete, the Remote Start buttongoes out.
- To activate the remote control, press the Remote Start button 9.
- If the Home Connect Assistant was aborted during start-up, press the Remote Start button 9 again.
- If the connection to the router fails, the Wi-Fi symbol flashes on the display.
- Opening the door deactivates Remote control.

# Wi-Fi without a connection to the Home Connect server

You can use the Home Connect App to disconnect from the Home Connect server.

The appliance is then locally connected to your mobile device without any connection to the Home Connect server.

**Note:** If you did not deactivate the connection to the Home Connect server, check your Internet connection.

### Remote diagnosis 🖔

Customer Service can use Remote Customer Service to access your appliance if you contact them.

#### **Notes**

- You have to confirm Customer Service access on your appliance.
- You can switch off Remote
  Customer Service busing the
  On/Off switch 1 or deactivate
  Customer Service access in the
  Home Connect App.

## Declaration of Conformity

Robert Bosch Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality meets the basic requirements and other relevant provisions of Directive 2014/53/EU.

A detailed RED Declaration of Conformity can be found online at www.bosch-home.com among the additional documents on the product page for your appliance.



### Water softening system / special salt

To ensure good rinsing results, the dishwasher requires soft water, i.e. water which is low in lime, otherwise limescale will be deposited on the utensils and interior container. Tap water above 7° dH (1.2 mmol/l) must be softened. The water is softened with special salt (regeneration salt) in the water softening system of the dishwasher. The setting and therefore the required amount of salt depends on the degree of hardness of your tap water (see following water hardness table).

### **Using a "Water Hardness Test Strip**"

The strip will be included in the use and care kit.

### Sample test strip


| Kurzeintauchen<br>(1 sec), leicht ab-<br>schütteln und nach<br>1 min ablesen.<br>4 grün/green/vert<br>1 rot/red/rouge<br>2 rot/red/rouge<br>3 rot/red/rouge<br>4 rot/red/rouge |  | Hongex brièvement<br>(1 sec), égouttez<br>l'excès d'eau et com-<br>parez agrès 1 min.<br><3°dH' <3.75°e/ <5.4°!<br>>4°dH' >5°e/>72°*<br>8,4°dH' >10.5°e/>25.2°!<br>>14°dH' >17.5°e/>25.2°<br>>21°dH'>56.25°e/>37.8°! | y. | AQUADUR® Teststäbchen zur Bestimmung der Wasserhärte Test stick for determination of water hardness Bandleette pour déterminer la dureté de l'éau |
|--|--|--|----|---|
|--|--|--|----|---|

Follow the instructions below for the included test strip. (If purchasing a different test strip, follow manufacturers instructions).

- 1. Run the water at the kitchen sink for 5 minutes.
- 2. Dip the end of the test strip with the colored squares into the tap water for 1 second and shake off excess water.
- 3. After one minute, compare the test strip to the chart on the test strip packaging and determine the Dishwasher Water Softener setting (see below).

- 4. Adjust the dishwasher Water Softener setting.
- 5. If required, add salt to the dishwasher salt chamber as shown. → "Using special dishwasher salt" on page 20

### Water hardness table



# Adjusting the water softening system

The amount of salt dispensed can be set from **0** to **62**°E. Salt is not required at the set value **0-8**.

### Set the softening system as follows:

- Ask your local water utility company for the water hardness value of your tap water or use test strip.
- 2. Required setting can be found in the water hardness table.
- 3. Open the door.
- 4. Switch on On/Off switch 1.
- 5. Press Info button 3 for 3 seconds until the following text is indicated on the display window at the top 4:

  Scroll with < >

Set with - +
Leave with Setup 3 sec.

- Keep pressing button > 8 until the water hardness is indicated on the display window at the top
- 7. Make the selection with setting buttons + 7.
- 8. Press and hold the Info button 3 for 3 seconds.

The chosen setting has now been stored.

# Using special dishwasher salt

As soon as the low salt indicator lights up on the digital display 4, salt should be topped off. Always refill with special salt immediately before switching on the appliance. This ensures that overrun special salt solution is immediately washed out and does not corrode the rinsing tub.


### **NOTICE**

Detergent will destroy the water softening system! Never pour detergent into the salt dispenser.

### Top off the salt as follows:

- 1. Undo the screw plug on the dispenser 28.
- Fill the dispenser with water (required only when switching on the appliance for the first time).
- Add salt as illustrated (do not use table salt, salt tablets or salt for use with whole house water softeners).

The water is displaced and runs out.



For more information about buying dishwasher salt, please contact **Customer Service** 1-800-944-2904.

# Using detergents with salt component

If combined detergents with a salt component are used, special salt can usually be omitted up to a water hardness of 21° dH (37° fH, 26° Clarke, 3.7 mmol/l). If the water hardness is over 21° dH, salt must be used.

# Switching off low salt indicator / water softening system

If the use of combined detergents with a salt component impairs the low salt indicator 6 on the control panel or the text on the display window at the top 4 (enough salt for x rinse cycles), the displays can be switched off.

Proceed as described under "Setting water softening system" and set the value to **0-8**. The water softening system and salt refill indicator are now switched off.

### Rinse Aid

To achieve proper drying, always use a liquid rinse aid, even if your detergent contains a rinse aid or drying additive.


Note: The dishwasher indicates low rinse aid by turning on the Rinse Aid indicator. If this indicator lights up, you need to refill the rinse aid dispenser 32 by following the directions below.

### Adding rinse aid


### NOTICE

To avoid oversudsing or clogging, do not overfill the rinse aid dispenser 32. Wipe up any spills with a damp cloth.

 Open the rinse aid dispenser 32 by pressing on the latch of the lid and pull it open.



 Add liquid rinse aid to the dispenser 32 until it is full. Do not overfill. Avoid spilling into air vent hole.



- Close the lid. Lid must be fully closed until it clicks in order to seal.
- Wipe up any excess rinse aid that may have puddled when the dispenser reservoir is full.

The indicator light will go out a few moments after the dishwasher door is shut.

**Tip:** For easier pouring, remove lid from the rinse aid bottle.

#### NOTICE

Do not fill the rinse aid dispenser 32 with detergent. Doing so will damage the dishwasher.

## Setting the amount of rinse aid used

The amount of rinse aid dispensed can be set from **0** to **6**. Set the amount of rinse aid to be dispensed to **5** to obtain a very good drying result.

You should only change the setting if streaks remain on the dishes (lower the amount), or if dishes are not getting dry enough (increase the amount).

### Set the amount of rinse aid as follows:

- 1. Open the door.
- 2. Switch on On/Off button 1.
- 3. Press Info button 3 for 3 seconds until the following text is indicated on the display window at the top 4:

Scroll with < >
Set with - +

Leave with Setup 3 sec.

- Keep pressing button > 8 until the rinse aid dispenser is indicated on the display window at the top 4.
- Make the selection with setting buttons + 7.
- 6. Press and hold the Info button 3 for 3 seconds.

The chosen setting has now been stored.

## Turning off rinse aid indicator

Proceed as described in the section "Setting the amount of rinse aid used" and set value to **0**. The rinse aid indicator is now turned off.

### NOTICE

Using no rinse aid or setting the dispenser to **0** may result in longer cycle times consuming more energy and water. The higher temperatures and longer cycle times can damage fine china or glassware.



### **Loading the Dishwasher**

### **Dishware material**

**Note:** Before using your dishwasher for the first time, check the information in this section. Some items are not dishwasher-safe and should be hand washed; others require special loading.

| Recommended   |   |
|---|---|
| Aluminum  | Colored anodized aluminum may fade over time. Minerals in your water may cause the aluminum to darken or spot. This can usually be removed with a soap-filled steel wool pad.                             |
| China, Crystal,<br>Stoneware                                | Some hand-painted utensils may discolor, fade or spot. Hand wash these utensils. Position fragile glassware so that it will not topple over or come in contact with other utensils during the wash cycle. |
| Glass   | Make sure to use dish-<br>washer-safe glass. Milk<br>glass may discolor or<br>become yellow.  |
| Non-stick Coat-<br>ings                                     | Apply a light coating of veg-<br>etable oil to non-stick sur-<br>faces after drying.  |
| Plastics  | Make sure the plasticware is dishwasher-safe.   |
| Stainless Steel,<br>Sterling Silver<br>and Silver<br>Plates | Load these so they do not come in contact with other metals, stainless steel dishwasher tub walls or the inner door.  |

| Not Recommended            |   |  |  |
|----------------------------|---|--|--|
| Acrylic                    | Crazing or small cracks throughout the acrylic, may occur.  |  |  |
| Adhesive-<br>Joined Pieces | Adhesives that join materials such as plastic, wood, bone, steel, copper, tin, etc. may loosen.       |  |  |
| Bone-Handled<br>Utensils   | Handles may separate.   |  |  |
| Iron                       | Iron will rust. Hand wash and dry immediately.  |  |  |
| Non-Dishware<br>Items      | Your dishwasher is intended for use in cleaning ONLY standard household dishware and kitchenware.     |  |  |
| Pewter, Brass,<br>Bronze   | These items will tarnish.<br>Hand wash and dry immediately.   |  |  |
| Tin                        | Tin will stain. Hand wash and dry immediately.  |  |  |
| Wood                       | Wooden bowls, wooden utensils and utensils with wooden handles can crack, warp and lose their finish. |  |  |

### Loading the racks

For best dishwashing results, observe the following when loading the dishwasher:

- Do not pre-wash items with loosely attached food soil.
- Remove all food particles, bones, toothpicks and excessive grease.
- Pre-treat items having burned-on, baked-on or starchy soils.
- Load dishes in the dishwasher racks so the insides of bowls, pots and pans are facing the spray arms.
- Avoid nesting and contact points between dishes.
- Separate items of dissimilar metals. Use care to not block movement of the spray arms.
- Only wash household dishware and kitchenware rated as dishwasher-safe.
   Refer to the Dishware Materials section for more information about dishware suitability.

#### NOTICE

To avoid dishwasher damage, do not load the dishwasher with paper products, plastic bags, packing materials or anything other than normal, dishwasher safe dishware and kitchenware.

### Loading the upper rack

Ensure items do not protrude through the bottom of the racks and block the spray arms.


Note: When pushing the upper rack 22 into the dishwasher, push it until it stops against the back of the tub so the upper rack spray arm 23 connects to the water supply at the back of the tub. Do not push racks in using the door.

### Loading the lower rack


Place large items in the lower rack 31. Load pots, pans and bowls upside down. Do not block the vent hole 25 with tall baking sheets. Load these items on the right side of the dishwasher.

## Loading patterns for lower rack


## 12 place setting suggested loading pattern



### Alternate loading pattern




## Alternate loading pattern with pots and pans




For best results, load large items face down in the lower rack.

## Loading patterns for upper rack


12 place setting suggested loading pattern, with third rack cutlery drawer \*




## 12 place setting suggested loading with My Way Rack™ \*



### Alternate loading pattern



Alternate loading pattern with stemware




Use supports to load stemware glasses in the upper rack.


\* optional feature which may or may not be included with your dishwasher.

### Loading patterns for third rack

### 12 place setting suggested loading pattern \*



My Way Rack™ \*



### en-us Loading the Dishwasher

\* optional feature which may or may not be included with your dishwasher.

### Loading the silverware basket


Place knives and sharp utensils with their handles up and forks and spoons with their handles down. If large or oddly-shaped items are loaded in the silverware basket, be sure they do not nest together.

### **▲ WARNING**

### **RISK OF INJURY!**

The sharp points and edges of knives and other sharp utensils can cause serious injury. Load knives and other sharp utensils with edges down. Do not allow children to handle or play near knives and sharp utensils.

### Long silverware basket\*



Note: The silverware basket lid may also be folded downward in order to leave the basket open.

\* optional feature which may or may not be included with your dishwasher


### The Double Flex silverware basket \*

This basket splits along its length, resulting in two halves that may be placed in a variety of positions in the lower rack 31, greatly increasing the lower rack's loading versatility. The basket snaps together either side by side or back to back.


To split the Double Flex silverware basket:

Grasp the basket and slide the two halves in opposite directions and then pull the two halves apart.

### Side by side




#### Back to back



To assemble the Double Flex silverware basket:

Hold the two halves side by side or back to back, so that the tab on one basket can slip into the notch on the other basket. Push the two halves in opposite directions until they click.

**Note:** The silverware basket lid may also be folded downward in order to leave the basket open.




\* optional feature which may or may not be included with your dishwasher.

### Suggested loading patterns




- 1 Salad fork
- 2 Teaspoon
- 3 Dinner fork
- 4 Knife
- 5 Tablespoon
- 6 Serving spoon
- 7 Serving fork

### Long silverware basket



### Double Flex silverware basket



### Unloading the dishwasher



### **A** CAUTION

Dishes can be very hot immediately after cycle ends. Open the door slightly and allow dishes to cool for a few minutes before unloading.

Note: Dishes are more likely to chip when unloading before cooling.

When unloading the dishwasher, to prevent water from dripping onto dry dishes, unload the lower rack 31 first. Next, unload the silverware basket 30 followed by the upper rack 22, and then the third rack (if equipped).


## Adjusting the height of the rack

If desired, the height of the upper rack 22 can be adjusted to create more space for taller utensils either in the upper or lower rack.

| With silver-<br>ware basket | Upper rack         | Lower rack         |
|-----------------------------|--------------------|--------------------|
| Setting 1                   | 9.4 in             | 12.6 in            |
| max. ø                      | (24 cm)            | (32 cm)            |
| Setting 2                   | 10.4 in            | 11.8 in            |
| max. ø                      | (26.5 cm)          | (30 cm)            |
| Setting 3 max. ø            | 11.4 in<br>(29 cm) | 10.6 in<br>(27 cm) |

| With third rack     | Upper rack        | Lower rack         |
|---------------------|-------------------|--------------------|
| Setting 1 max. ø    | 7 in (18 cm)      | 12.6 in<br>(32 cm) |
| Setting 2<br>max. ø | 8 in<br>(20.5 cm) | 11.8 in<br>(30 cm) |
| Setting 3 max. ø    | 9 in<br>(23 cm)   | 10.6 in<br>(27 cm) |


Arrange large plates up to a diameter of 12.6 in (32 cm) in the lower basket 31 as illustrated.



### **RackMatic®**

The height of the upper rack 22 can be adjusted in 3 steps to create more space.

- 1. Pull the upper rack out of the dishwasher until it stops.
- 2. To lower the rack, push the RackMatic® lever inward.
- To raise the rack, hold the basket on the sides of the upper rack and lift it up.




**Note:** Check spray arm for clearance after adjustment.

### **Rack accessories**


### Flip tines

The upper and lower rack are fitted with flip tines that can be folded down depending on what you may need to load in the rack.

Lower rack flip tines: To fold down, pull flip tine gently forward and release it from the notch. Push the flip tine downward. To fold up, push flip tines into an upright position until the holder engages in the notch.




Upper rack flip tines: To fold down, push flip tines downward with gentle pressure. To fold up, push flip tines into an upright position until the holder engages in the notch.





### Third rack

The third rack 21 horizontally positions knives, spatulas and other oversized tools for improved cleaning and easier loading and unloading. Arrange cutlery in third rack as illustrated.



You can fold down the side shelves to provide more room for taller items of silverware.\* The front rows of prongs can be folded down to provide room for wider handles.






\* optional feature which may or may not be included with your dishwasher.

### My Way Rack™ \*

This third rack is ideal for small bowls, spatulas and other oversized tools for improved cleaning and easier loading and unloading.


Arrange cutlery in cutlery insert.



\* optional feature which may or may not be included with your dishwasher.

### Cup shelves


The cup shelves and the space underneath them can be used for small cups or for larger serving utensils. They also serve as stemware supports. → "Loading patterns for upper rack" on page 26




### Extra tall item sprinkler\*

If an item is too tall to be placed in the lower rack 31 even with the upper rack 22 in the raised position, remove the empty upper rack 22 by pulling it out of the dishwasher until it stops. Pull the front of the rack upward and outward until the rack will not slide out anymore. Then lift it up and away from the dishwasher, until the rollers are completely free of the roller guides (A).

Set the upper rack 22 aside and push the roller guides (A) back into the dishwasher. Insert the extra tall item sprinkler (B) into the upper rack spray outlet (C) and turn the sprinkler clockwise to lock into position.






Note: Keep the vent hole 25 on the tub's left side clear by placing tall items such as plastic cutting boards and tall baking sheets on the lower rack's right side or center.

### **NOTICE**


To avoid dishwasher damage, do not reinstall the upper rack 22 without removing the extra tall item sprinkler (B).

### Removing/Installing third rack



### Removing third rack 21


- 1. Pull out third rack all the way (1).
- 2. Lift upper rollers over the stopper hooks of both rails (2).
- 3. Pull third rack out forward and upward so that the holding hooks and the lower rollers of the rack slide over the stopper hooks of both rails (3).




<sup>\*</sup> optional feature which may or may not be included with your dishwasher.

### Installing third rack 21

- 1. Pull out third rack rails all the way (1).
- Insert third rack at an angle. Make sure that the stopper hooks of both rails slide in between the holding hooks and the lower rollers of the third rack (2).
- Slide third rack in and lift the upper rollers over the front stopper hooks of both rails (3).
- 4. Push in third rack (4).




## Removing/Installing upper rack with Rackmatic®




### Removing upper rack 22

- 1. Pull out upper rack all the way (1).
- 2. Lift front rollers over the stopper hook of the rail (2).
- 3. Pull out upper rack forwards and upwards so that the upper and lower rollers of the rack slide over the stopper hooks of both rails (3).



### Installing upper rack 22

- 1. Pull out upper rack rails all the way (1).
- 2. Insert upper rack at an angle. Make sure that the stopper hooks of both rails slide in between the upper and lower rollers on the rear side of the rack (2).
- 3. Slide upper rack in and lift the upper rollers over the front stopper hooks of both rails (3).
- 4. Push in upper rack (4).





### Detergent

Use only detergent specifically designed for dishwashers. For best results, use fresh powdered dishwashing detergent or detergent tabs.

### NOTICE

To avoid damage to dishwasher or dishware:

- Do not use hand dishwashing products in your dishwasher.
- Do not use too much detergent if your water is soft. Using too much detergent with soft water may cause etching in glassware and fine china.
- To best protect glassware, use a wash cycle with low temperatures or a specific glass-care cycle (depending on the model) and use a detergent that includes etch protection.

This dishwasher uses less water than most, therefore, less detergent is required. With soft water, 1 tablespoon (15 ml) of detergent will clean most loads. The detergent dispenser cup has lines that measure detergent to 1 tablespoon (15 ml) and 1.75 tablespoons (25 ml). 3 tablespoons (45 ml) of detergent will completely fill the detergent dispenser.

Note: If you do not know the hardness of your water supply, use 15 ml of detergent. Increase the amount if necessary to the least amount required to get your kitchenware clean.


Use the measuring lines in the detergent dispenser cup as a guide to measure the amount of detergent recommended in the following table.

| Wash Cycle | Hard Water/   | Medium Water/ | Soft Water/   |
|------------|---------------|---------------|---------------|
|            | Heavy Soil    | Medium Soil   | Little Soil   |
| Heavy      | 3 tbsp        | 3 tbsp        | 1.75 - 3 tbsp |
|            | (45 ml)       | (45 ml)       | (25 - 45 ml)  |
| Auto       | 1.75 - 3 tbsp | 1.75 tbsp     | 1 - 1.75 tbsp |
|            | (25 - 45 ml)  | (25 ml)       | (15 - 25 ml)  |
| Glass      | 1.75 - 3 tbsp | 1 - 1.75 tbsp | 1 tbsp        |
|            | (25 - 45 ml)  | (15 - 25 ml)  | (15 ml)       |
| Eco        | 1.75 - 3 tbsp | 1 - 1.75 tbsp | 1 tbsp        |
|            | (25 - 45 ml)  | (15 - 25 ml)  | (15 ml)       |
| Normal     | 1.75 - 3 tbsp | 1.75 tbsp     | 1 - 1.75 tbsp |
|            | (25 - 45 ml)  | (25 ml)       | (15 - 25 ml)  |
| Speed60®   | 1.75 tbsp     | 1 - 1.75 tbsp | 1 tbsp        |
|            | (25 ml)       | (15 - 25 ml)  | (15 ml)       |
| Express    | 1.75 tbsp     | 1 - 1.75 tbsp | 1 tbsp        |
|            | (25 ml)       | (15 - 25 ml)  | (15 ml)       |
| Rinse      | none          | none          | none          |

## **Adding detergent**


1. If the detergent dispenser 33 is still closed, push the button 34 to open it.

**Note:** Make sure the detergent dispenser is dry and clear of detergent residue.




When using detergent tabs, lay them such that they do not come in contact with the cover, insert a detergent tab flat, not on its side.

Note: Do not place detergent tabs or utensils in the detergent tab tray 24. Place tabs or other detergent forms directly in the detergent dispenser 33.




Pour detergent into the dry detergent dispenser 33 only. Add detergent. Do not overfill the detergent dispenser.



Dosage: see manufacturer's instructions on the packaging.

Close the lid by placing the finger on the lid as shown. Slide the lid closed until it clicks.



The detergent dispenser will open automatically at the ideal time for the set cycle. The powder or liquid detergent is distributed in the appliance and is dissolved, detergent tabs will fall into the detergent tab tray 24 where it dissolves during the cycle.

**Tip:** If the dishware is only lightly soiled, slightly less than the indicated amount of detergent is usually adequate.

## Dishwasher Cycles

| Wash cycle                              | Recommended use  | Possible wash cycle option  |
|---|--|---|
| Heavy                                   | Best for cleaning items with baked-on food or grease. These dishes would normally require soaking or hand scouring.  | all   |
| Auto                                    | Smartest cycle, with most flexible soil sensing, which is ideal for mixed dishware and food soils.   | all   |
| Eco*                                    | The Eco cycle uses less energy with lower temperatures and a shorter cycle length . Perfect for lightly soiled dishes.   | all   |
| Glass*                                  | Best for delicate dishes and glasses, the Glass cycle lowers temperature and cycle length to decrease energy usage.  | Delay<br>Half Load<br>CrystalDry™   |
| Normal<br>(see note at bottom of table) | Recommended for daily, regular or typical use to completely wash a full load of normally soiled dishes.  | All  Note: In order to obtain optimal performance with minimum energy consumption, it is recommended to disable all available options and settings, except Auto Power Off - set to P:D: |
| Speed60®                                | Cleans freshly soiled dishes with easy to remove soils. This cycle reduces cycle time while still including drying.  | Delay   |
| Express                                 | Cleans lightly soiled dishes and reduces overall wash time. Use this cycle to clean glasses and dessert dishware that may need to be reused at the same event.                                   | Delay   |
| Rinse                                   | Use this cycle if you need to rinse dishes to avoid odors. Place unrinsed dishes inside the dishwasher and select the <b>Rinse</b> cycle. Uses less water than hand rinsing and very low energy. | Delay   |

<sup>\*</sup>the number of wash cycles and options depends on the features of your dishwasher

Note: The Energy Guide label was based on the **Normal** soil sensing cycle as follows: The unit was tested without any rinse aid (liquid) in the rinse aid dispenser 32. A single dose of detergent was inserted into the detergent dispenser 33, with no detergent being used in the prewash. The unit was not subjected to truncated testing per the definitions in the test procedure. We recommend that dish loads such as the one in the energy certification test have the rack position set in the highest position.

# Dishwasher Cycle Options

## Delay

Allows you to delay the start time of your dishwasher up to 24 hours.

## SpeedPerfect™

SpeedPerfect™ is an option that allows saving time without sacrificing wash and dry performance. Selecting this option ensures the same final temperatures as the underlying cycle by starting the heat period at an earlier phase in the program. Selecting this option also increases energy consumption while reducing cycle time.

#### Half Load

Can reduce water consumption when washing small, lightly soiled loads that fill approximately half or less of the dishwasher's capacity.

### **Delicate**

This option's reduced time and temperature are best for lightly soiled items with easy to remove food soils. The option also reduces the likelihood of cloudy glasses. Rinse aid is recommended for the high gloss drying function (even when using combination detergents).

## **Sanitize**

Increases the temperatures and retains them for an extra long time to obtain a defined disinfecting performance. Continuous use of this function increases the hygiene status. This additional option is ideal for cleaning items such as chopping boards and baby bottles.

"Sanitized" will appear in the display window when sanitation requirements are met. Using the Sanitize option may also improve drying. There is a slight increase in energy consumption.

## **CrystalDry**™

Patented CrystalDry™ technology thoroughly dries dishes and plastics such as baby bottles and food storage containers. Natural minerals transform moisture into heat up to 176F to get dishes, even plastics 60% drier.\*

\* Based on aggregate average drying performance of Bosch Dishwashers with CrystalDry™ on combined household load including plastics, glass, steel, and porcelain as compared to Bosch Dishwashers with PureDry. Drying performance may vary by dish type.

## **Wash Cycle Information**

To save energy, this dishwasher has EcoSense where the sensors in the dishwasher automatically adjust the cycle length, temperature and water changes based on the amount of food soil and the incoming water temperature. The "Smart Control"

makes decisions that can cause the cycle time and water usage to adjust intermittently. Wash cycle times are based on 120°F (49° C) water supply. If your household water supply is different than 120°F (49° C), your dishwasher's cycle times may be impacted.

| tempera                 | temperature. The "Smart Control" |                       |                      |                           |                       |              |            |               |
|-------------------------|----------------------------------|-----------------------|----------------------|---------------------------|-----------------------|--------------|------------|---------------|
|                         | Heavy                            | Auto                  | Glass                | Normal                    | Eco                   | Speed60      | Express    | Rinse         |
|                         |                                  |                       |                      |                           |                       |              |            |               |
| Cycle<br>time<br>min.   | 110 -135                         | 105 -129              | 75-85                | 130 -145                  | 75-85                 | 60           | 30         | 9             |
| Water<br>usage<br>gal/L | 4.9-6.4/<br>18.6-24.2            | 3.4-6.4/<br>12.9-24.1 | 2.4-3.9/<br>9.0-14.6 | 2.5-5.5/<br>9.6-21.0      | 2.4-3.9/<br>18.6-24.6 | 3.8/<br>14.3 | 2.7/       | 1.1/<br>4.1   |
| Wash<br>temp.<br>°F/°C  | 151-160/<br>66-71                | 127-140/<br>53-55     | 113-122/<br>45-50    | 113-136<br>/<br>45-55     | 113-122/<br>45-50     | 122/<br>50   | 113/<br>45 | incom-<br>ing |
| Rinse<br>temp.<br>°F/°C | 151/<br>66                       | 136/<br>58            | 122/<br>50           | 136/<br>58                | 122/<br>50            | 158/<br>70   | 126/<br>52 | incom-<br>ing |
| Half Loa                | ıd                               |                       |                      |                           |                       |              |            |               |
| Cycle time min.         | 114                              | 100-110               | 70-80                | 100-115                   | 70-80                 | N/A          | N/A        | N/A           |
| Water<br>usage<br>gal/L | 4.7/<br>17.9                     | 2.7-4.4/<br>10.2-16.5 | 2.4-3.3/<br>9.2-14.5 | 2.9-3.7/<br>10.8-13.<br>9 | 2.4-3.3/<br>9.2-14.5  | N/A          | N/A        | N/A           |
| Rinse<br>temp.<br>°F/°C | 151/<br>66                       | 136/<br>58            | 145/<br>63           | 136/<br>58                | 145/<br>63            | N/A          | N/A        | N/A           |
| Delicate                |                                  |                       |                      |                           |                       |              |            |               |
| Cycle time min.         | 105-120                          | 100-110               | N/A                  | 100-130                   | N/A                   | N/A          | N/A        | N/A           |
| Water<br>usage<br>gal/L | 4.9-6.4/<br>18.6-24.2            | 3.4-6.4/<br>12.9-24.1 | N/A                  | 2.5-5.5/<br>9.6-21.0      | N/A                   | N/A          | N/A        | N/A           |
| Rinse<br>temp.<br>°F/°C | 140/<br>60                       | 122/<br>50            | N/A                  | 140/<br>60                | N/A                   | N/A          | N/A        | N/A           |

|                         | Heavy                 | Auto                  | Glass                | Normal                    | Eco                  | Speed60 | Express | Rinse |
|-------------------------|-----------------------|-----------------------|----------------------|---------------------------|----------------------|---------|---------|-------|
| Sanitize                |                       |                       |                      |                           |                      |         |         |       |
| Cycle<br>time<br>min.   | 125-150               | 125-150               | N/A                  | 135-155                   | N/A                  | N/A     | N/A     | N/A   |
| Water<br>usage<br>gal/L | 4.9-6.4/<br>18.6-24.2 | 3.4-6.4/<br>12.9-24.1 | N/A                  | 2.4-5.6/<br>8.5-20.6      | N/A                  | N/A     | N/A     | N/A   |
| Rinse<br>temp.<br>°F/°C | 162/<br>72            | 162/<br>72            | N/A                  | 162/<br>72                | N/A                  | N/A     | N/A     | N/A   |
| SpeedP                  | erfect™               |                       |                      |                           |                      |         |         |       |
| Cycle time min.         | 100-120               | 90-105                | 70-80                | 95-105                    | 70-80                | N/A     | N/A     | N/A   |
| Water<br>usage<br>gal/L | 4.3-5.4/<br>16.3-20.5 | 4.3-5.3/<br>16.1-20   | 2.4-3.3/<br>9.2-12.5 | 4.4-5.6/<br>16.6-<br>21.1 | 2.4-3.3/<br>9.2-12.5 | N/A     | N/A     | N/A   |
| Rinse<br>temp.<br>°F/°C | 162/<br>72            | 153-162/<br>67-72     | 145/<br>63           | 162/<br>72                | 145/<br>63           | N/A     | N/A     | N/A   |
| Crystal                 | Dry™                  |                       |                      |                           |                      |         |         |       |
| Cycle<br>time<br>min.   | 140-165               | 135-159               | 105-115              | 140-165                   | 105-115              | N/A     | N/A     | N/A   |
| Water<br>usage<br>gal/L | 4.9-6.4/<br>18.6-24.2 | 3.4-6.4/<br>12.9-24.1 | 2.4-3.9/<br>9.0-14.6 | 2.4-5.6/<br>9.1-21.2      | 2.4-3.9/<br>9.0-14.6 | N/A     | N/A     | N/A   |
| Rinse<br>temp.<br>°F/°C | 153/<br>67            | 153/<br>67            | 135/<br>57           | 162/<br>72                | 135/<br>57           | N/A     | N/A     | N/A   |

**Note:** Only sanitizing cycles have been designed to meet the requirements of Section 6 of the NSF/ANSI Standard for Residential Equipment for soil removal and sanitization efficacy. There is no intention, either directly or indirectly, to imply that all cycles have passed sanitization performance tests.



## Operating the Dishwasher

Note: With hidden controls, the door must be opened before changing settings and closed after changing settings.



### **WARNING**

**RISK OF INJURY!** 

To avoid risk of injury, always use caution when opening the door during or following a wash cycle as hot water or steam may escape. Do not fully open the door until water noises have stopped and steam has subsided.

## **Protection against** unintentional operation

Your dishwasher is equipped with a function that helps to prevent unintentional operation (e.g. by children).

After starting the dishwasher, the dishwasher door has to be closed within 4 seconds, otherwise the operation will be paused. There will be a signal on the control panel advising you to press the Start button again and close the door.

This function will be activated when:

- pressing Start to begin a wash cycle
- setting Delay time and pressing Start
- opening the door while Delay time is active
- opening the door during a wash cycle.

Note: This function cannot be deactivated.

## Operating the touch buttons

Buttons are sensitive and should be touched gently. Avoid any grease or food particles resting on the buttons as they could activate the dishwasher.

Wiping and cleaning can also activate the dishwasher. For best results, use bare, clean hands when touching the buttons.

To clean the touch buttons wipe them with a dry or slightly damp cloth.

## Changing the settings

The dishwasher has been preset with certain settings for your convenience. You can change these factory settinas.

#### Change the setting as follows:

- 1. Open the door.
- 2. Switch on On/Off button 1.
- 3. Press Info button 3 for 3 seconds until the following text is indicated in the digital display

Scroll with <> Set with - + Leave with Setup 3 sec.

- 4. Keep pressing button > 8 until the required setting is indicated in the display window at the top 4.
- 5. Make the selection with setting buttons + -7.
- 6. Press and hold the Info button 3 for 3 seconds.

The chosen setting has now been stored.

Tip: If you change several settings, first make all changes in succession. Now press the Info button 3 for 3 seconds. This saves all set values in the appliance.

## **AquaSensor**

The AquaSensor is an optical measuring device which measures the cleanliness of the rinse water.

The AquaSensor is used according to the wash cycle. If the AquaSensor is active, "clean" rinse water can be transferred to the next rinse and water consumption can be reduced by 0.8–1-5 gal (3–6 liters). If the rinse water is not yet clear, the water is drained and is replaced with fresh water. In the automatic wash cycles the temperature and running time can also be adjusted to the degree of soiling.

## **Time display**

The wash cycle time is determined during the wash cycle by the water temperature, the amount of dishes, as well as the degree of soiling and may vary (depending on the selected wash cycle). You can change the time display into time of day or hours/minutes so that the remaining cycle time of the wash cycle appears in the display window "Finish at" (for example 15:20 o'clock) or "Finish in" (for example 3:25 hours).

## Sensor setting

The wash cycle sequence is optimized in Auto wash cycles with the aid of sensors. The sensors adjust the wash cycle strength of Auto wash cycles depending on the amount and type of soiling. You can adjust the sensitivity of the sensors in 3 stages.

**Standard:** This setting is recommend for daily regular or typical use. This is the most energy efficient setting.

**Sensitive:** This setting adjusts the wash cycle strength for the effective removal of food remnants, even if the amount of soiling is low. The energy

and water consumption is increased accordingly.

Very sensitive: This setting adjusts the wash cycle strength for difficult conditions of use, for example firmly dried on food remnants. This setting is recommended if using biological or eco detergents which contain lower amounts of active agents. The energy and water consumption is increased accordingly.

## **Extra Dry**

The final rinse uses a higher temperature which improves the drying result. The cycle time may increase slightly. (Caution if utensils are delicate!) You can switch the Extra Dry function on or off. There is a slight increase in energy consumption.

#### Eco forecast

When Eco forecast is activated, the average water and energy consumption of the selected wash cycle is briefly displayed in the digital display 4.

## Auto power off

This setting determines the length of time the control panel stays illuminated after the cycle is complete.

To save energy, the recommended setting is "after one minute".

### Possible settings are:

- off: The appliance does not switch off automatically.
- After one minute: The appliance switches off after 1 minute. This is the most energy efficient setting.
- After two hours: The appliance switches off after 2 hours.

#### **Tone volume**

The end of the wash cycle is indicated by a buzzer. You can also change this setting.

#### **Button volume**

When you are operating the dishwasher, a signal sounds whenever a button is pressed. You can control the volume of the signal. If you do not like the button volume, you can switch it off.

## Greeting

When you switch on the dishwasher, the brand logo appears. You can switch off the brand logo.

## **Factory setting**

You can reset all settings to the factory setting.

## Switching the appliance on

- 1. Turn the water supply on fully.
- 2. Open the door.
- 3. Switch on On/Off switch 1. The Auto wash cycle has been preset as a default whenever the appliance starts. This wash cycle remains selected if no other wash cycle button 2 is pressed.
- 4. Press Start button 11.
- 5. Close the door.

Wash cycle sequence starts.

**Note:** Your dishwasher is protected against unintentional operation. If the appliance door remains open for more than 4 seconds after pressing the Start button, the operation will be paused. Press the Start button again and close the appliance door.

## **Delay start time**

You can delay the start of the wash cycle by up to 24 hours. Depending on the setting of the time display, the end of cycle is indicated with "Finish in" (for example 3h 25m) or "Finish at" (for example 15:20 hours).

- 1. Open the door.
- 2. Switch on **On/Off** switch 1.
- 3. Select wash cycle 2.
- 4. Press **Delay** start button 8.
- Keep pressing the setting buttons
   + [7] until the displayed time corresponds with your requirements.
- **6.** Press **Start** button 11, timer programming is activated.
- 7. To delete the Delay start time, press **Start** button 11 for about 3 seconds.
- 8. Close the door.

**Note:** Your dishwasher is protected against unintentional operation. If the appliance door remains open for more than 4 seconds after pressing the Start button, the operation will be paused. Press the Start button again and close the appliance door.

## InfoLight®\*

\* depending on the features of your dishwasher

While the wash cycle is running, a light spot shines on the floor under the appliance door.

Do not open the appliance door until the light point is no longer visible on the floor.

If the appliance door is not completely closed, the light spot flashes.

If the appliance is installed at eye-level, with flush furniture front, the light point is not visible.

In darkened rooms, some light scattering may be visible. This is normal and cannot be changed.

You can switch the Infolight on or off.

## **EmotionLight**

The EmotionLight 20 is on when the door is open irrespective of whether the **On/Off** switch 1 is switched on or off. When the door is closed, the EmotionLight is off. You can switch the EmotionLight on or off.

Note: Note that when the door is open the EmotionLight is automatically switched off after 1 hour

## Wash cycle end

The wash cycle has ended when "Finished" is indicated on the digital display(s).

## Switching off the appliance

### Short time after the end of the wash cvcle:

- 1. Press **On/Off** button 1.
- 2. Remove the dishes when they have cooled down.

### ▲ WARNING

#### **RISK OF INJURY!**

To avoid risk of injury, always use caution when opening the door during or following a wash cycle as hot water or steam may escape. Do not fully open the door until water noises have stopped and steam has subsided.

## Interrupting the wash cycle

## **▲** CAUTION

Expansion (overpressure) may cause the appliance door to open and/or water to escape! If the door was opened on an appliance which has a hot water connection or is heated, always leave the door ajar for several minutes and then close.

- 1. Open the door.
- 2. Switch off On/Off switch 1. The LED's go out. The wash cycle is saved.
- 3. To continue the wash cycle, switch on the On/Off switch 1 again.
- Close the door.

**Note:** Your dishwasher is protected against unintentional operation. If the appliance door remains open for more than 4 seconds after pressing the Start button, the operation will be paused. Press the Start button again and close the appliance door.

## Cancel a cycle (reset)

- Open the door and press and hold the **Start** button 11 for approximately 3 seconds until the digital display 4 shows: "Program was terminated".
- 2. Close the door.
- 3. Wait about 1 minute while the dishwasher drains.
- 4. Open the door and press the **On/Off** switch 1.

## Changing the wash cycle

When the **Start** button has been pressed, the wash cycle cannot be changed. The only way a wash cycle can be changed is by terminating the wash cycle (Reset).

## Care and **Maintenance**

A regular inspection and maintenance of your machine will help to prevent faults. This saves time and prevents future problems.

## Cleaning the dishwasher

- Regularly wipe the front of the appliance with a damp cloth water and a small amount of liquid soap is adequate.
- For black stainless steel and anti-fingerprint surfaces, use a soft, dry towel. For stubborn dirt, use warm water diluted with a non-abrasive, mild cleansing soap. Never use stainless steel polish.
- For stainless steel appliances (excluding black stainless and anti-fingerprint), use a stainless steel polish to seal and protect the surface.
- Clean the outer edges of the inside door panel regularly to remove debris that may collect from normal loading. If spots begin to appear on the stainless steel, make sure the rinse aid dispenser is full and functioning properly.
- Clean the door seal regularly with a damp cloth to remove food particles that may collect from normal loading and cause odor. A soiled door seal may not seal properly.

#### NOTICE

- Never use a steam cleaner to clean your dishwasher. The manufacturer is not liable for any resulting damage.
- Do not use sponges as they could scratch the surfaces.

- Do not use bleach-based wipes as they could damage the surface or printing.
- Never use stainless steel polish on a black stainless finish or anti-fingerprint surfaces.

## **▲ WARNING**

#### **RISK OF EXPLOSION!**

When cleaning your dishwasher with any cleaning agent, remove all cookware, utensils or any foreign material from inside. Some cleaning agents are highly acidic and/or caustic alkaline, which can cause hydrogen gas to form if aluminum material is also inside the dishwasher tub. Hydrogen gas is explosive.

### **▲ WARNING**

Use caution when removing parts for cleaning as some debris may be sharp.


#### **Filters**

The Bosch® filter system 29 is designed to prevent the need to pre-rinse normally attached food soils from your dishes. Simply scrape leftover food soils off of dishware before loading. This process will conserve time, water and the energy require to heat your household water supply.

Your dishwasher filter system is designed to filter 100% of the water entering the spray arms to provide a continuous supply of clean water to remove food soils from your dishware.

#### Filter components

## The filter system 29 consists of three parts.



### A Large Object Trap

Prevents objects that should not be placed in your dishwasher from damaging the dishwasher pump system or clogging your household drain.

#### **B** Flat Fine Filter

Prevents food particles from entering the wash chamber and directs particles toward the micro filter.

#### C Micro Filter

Directs the smallest of particles to the household plumbing drain.

#### **Cleaning intervals**

The filter system [29] is designed to minimize maintenance while providing premium cleaning performance and minimum energy consumption.

Depending on use habits and water hardness, the filter system will require some maintenance to sustain premium cleaning performance.

Your filter system may need to be cleaned when:

- You notice food soils remaining on the filter system or objects trapped in the Large Object Trap.
- A drop in cleaning performance or a gritty film forms on the dishware.


When washing normally attached food soils that have been scraped before loading, in a household that runs the dishwasher every other day, your filter should be cleaned:

| Cleaning interval | Usage                |
|-------------------|----------------------|
| 3-6 times a year  | light to average use |
| 8-12 times a year | heavy use            |


Note: Clean the filter system after washing loads with large amounts of food soils or loads with a heavy starch content, like potatoes and pasta, to maintain optimal performance.

#### To check or clean the filter system:

1. Unscrew the Large Object Trap as illustrated and remove the entire filter system.



2. Remove the microfilter from the fine filter for easier cleaning.



3. Rinse the filters under running water and use a soft brush to clean.


> Note: do not use abrasive brushes or steel wool, etc., as they may damage the filter.

4. Reinstall the filter system in reverse sequence and lock into place by screwing the Large Object Trap until the marking arrows align.

## Spray arms

Check spray arms 23, 27 for grease and limescale deposits. If you find such deposits:


- Fill detergent dispenser 33 with detergent and start the appliance without utensils in the cycle with the highest rinsing temperature.
  - → "Wash Cycle Information" on page 40
- Clean the appliance with detergents/appliance cleaners which are particularly suitable for use with dishwashers.
- Unscrew the upper spray arm 23 and pull off the lower spray [27] arm as shown. Inspect for deposits.




## **Drain pump**

Large food remnants in the rinsing water not retained by the filters may block the waste water pump. In this case:

- Disconnect the appliance from the power supply.
- Remove the filters. → "Filters" on page 48
- Scoop out standing water use a sponge if necessary.
- Using a spoon, pry off the pump cover until it clicks, then grip the cover and pull upward until it resists and then pull forward.





 Check inner compartment and remove any foreign objects.

## **WARNING**

Use caution when removing parts for cleaning as some debris may be sharp.

- Place cover in the original position, press down and engage.
- Reinstall filters.

**Note:** The drain pump will not work properly if the drain pump cover is not snapped in completely until it clicks.

## Preparing your unit for vacation

#### **NOTICE**

Before leaving for vacation during warmer weather, besides turning off the main valve, also turn off water supply at the nearest point to the dishwasher. Do not leave soiled dishware in unit and leave door slightly open. During colder weather, please follow the instructions for winterizing your unit below.

## Winterizing your unit

#### **NOTICE**

If your dishwasher will be unused for a period of time in a location that experiences freezing temperatures (holiday home or through a vacation period), have your dishwasher winterized by a professional service.

## Troubleshooting

Dishwashers may occasionally exhibit problems that are unrelated to a malfunction of the dishwasher itself.

The following information may help you with a dishwasher problem without involving a repair professional.

| Problem   | Cause   | Action   |
|---|---|--|
| Error code  | Supply hose kinked.                                       | Install supply hose without kinks.   |
| <i>E</i> : <i>18</i> is lit.  | Water supply turned off.                                  | Turn on the water supply.  |
|   | Water supply line is clogged.                             | Unclog water line.   |
| Error code <b>E:22</b> is lit.  | Water in sump since sump filters 29 are dirty or blocked. | Clean filters.   |
| Error code  | Drain line is clogged.                                    | Unclog drain line.   |
| <i>E:24</i> is lit.   | Drain hose is kinked, clogged or blocked.                 | Replace drain hose.  |
|   | Drain pump impeller (vanes) is clogged or blocked.        | Remove drain pump cover, clean around pump impeller and replace cover.   |
|   | Drain pump cover was loose.                               | Lock drain pump cover into place in the sump.  |
| Error code <i>E:25</i> is lit.  | Drain pump is blocked or pump cover is loose.             | Clean drain pump and lock drain pump cover into place in the sump.   |
| Error code <i>E:27</i> is lit.  | Supply voltage too low (less than 98 volts).              | Not a dishwasher fault; have the supply voltage and electrical installation checked.   |
| A different error code is indicated on the digital display. (E:0 ! to E:30) | A technical fault has probably occurred.                  | Switch off dishwasher with the On/Off switch 1. After a short time restart the dishwasher. If the problem recurs, turn off the tap and pull out the power supply plug. Call customer service and mention the error code. |
| Home network is not loading.  | Wi-Fi is not active on the router.                        | Check the wireless network connection of your router.  |
| Wi-Fi display<br>flashes  | Connection to the home network is not available.          | Activate the wireless network on your router.  |
| Home Connect cannot be implemented correctly.                               | Possible setting errors or a technical fault.             | Refer to the supplied documents and support information for Home Connect.  |

| Dishwasher does not start.  | Door may be ajar or not be properly latched.   | Close door securely until door latch clicks.  |
|---|--|---|
|   | No power to the dishwasher (display won't come on). Fuse may have been blown, circuit breaker may have tripped, power cord may have been unplugged or dishwasher may have been turned off. | Replace blown fuse or reset tripped circuit breaker. Plug power cord into outlet securely. Press the on/off button 1 to turn the dishwasher on.           |
|   | Can't select a wash cycle since the previous wash cycle may not have finished or the dishwasher hasn't been reset.   | Reset the dishwasher by pressing and holding the START button for at least three seconds.   |
|   | Delay start or Child lock may be activated.  | Reset Delay start or Child lock functions (refer to the appropriate section in this manual).  |
|   | The door may have been closed without selecting a wash cycle.  | Select a wash cycle and close the door.   |
|   | Water supply may not be turned on or connected.  | Check and turn on water supply.   |
| Wash cycle<br>won't resume<br>after door was<br>opened and<br>closed. | The door has been open for more than 4 seconds after pressing the <b>Start</b> button.   | Press <b>Start</b> button again and close the dishwasher door within 4 seconds (see "Protection against unintentional operation" section in this manual). |
| Wash cycle abruptly stops.  | Door may be ajar or not properly latched.  | Close door securely until door latch clicks.  |
|   | Objects placed into the upper rack handle tray prevented the door from being closed securely.  | Remove objects from upper rack handle tray and close door securely until door latch clicks.   |
|   | Power and/or water supply interrupted.   | Restore power and/or water supply.  |

## en-us Troubleshooting

| Dishwasher<br>runs a long<br>time.                                  | Incoming water is not warm enough.   | Before starting a cycle, run hot water faucet at the sink closest to the dishwasher.  |
|---|--|---|
|   | Cycle time depends on wash cycle chosen and amount of soil on dishes (dishwasher sensors increase cycle times to ensure dishes are clean when heavy soil is detected). | Scrape food off of dishes and use less intensive wash cycles.   |
|   | Rinse aid dispenser 32 is empty, or rinse aid setting = 0. Without rinse aid, wash cycle defaults to longest time with most number of washes and rinses.               | Add rinse aid and change rinse aid setting depending on water hardness.   |
|   | Dishwasher is connected to cold water supply.  | Connect dishwasher to hot water supply.   |
| Dishes aren't clean enough  | Spray arms are blocked or misaligned where they cannot rotate freely.  | Make sure spray arms [23], [27] can rotate freely.  |
|   | Little or no water spray due to clogged spray arm nozzle.  | Clean out spray arm nozzles and filters of all debris and obstructions. $\longrightarrow$ "Spray arms" on page 49                               |
|   | Little or no water spray due to clogged or misaligned filters 29.  | Clean filters and make sure they're installed correctly. → "Filter components" on page 48   |
|   | Dishes are nested or placed too closely together and racks are over-filled.  | Space dishes apart so spray jets can reach the surface of the dishes and dishes don't contact each other. → "Loading the Dishwasher" on page 24 |
|   | Improper or ineffective wash cycle or detergent used.  | Choose a more intensive wash cycle and use appropriate dishwasher detergents.  — "Wash Cycle Information" on page 40                            |
|   | Detergent is made less effective due to hard water.  | Install a water softener and choose a more intensive wash cycle.  |
| Removable<br>spots or<br>streaks on<br>glasses and sil-<br>verware. | Too much rinse aid causes streaks and too little rinse aid can cause spots.  | Add rinse aid and check rinse aid setting (recommended setting 4-5). → "Rinse Aid" on page 22   |
|   | Mineral deposits from hard water.  | Install a water softener.   |
|   | Water from top (3rd) or upper rack dripped on racks below.   | Unload lower rack 1st, upper rack 2nd and top (3rd) rack last.  |

| Dishes not dry.   | Rinse aid dispenser 32 is empty or incorrect rinse aid amount is set.  | Add rinse aid or adjust setting - the use of rinse agent improves drying, use the Auto cycle, use the Sanitize option.  |
|---|--|---|
|   | Extra Dry heat option not chosen.*   | Activate Extra Dry heat option.*  |
|   | Water collected in depressions on the dishes and silverware.   | Arrange dishes in upper rack to slope so water can drain.   |
|   | Door was opened or dishes removed before wash cycle was completed.   | Wait until wash cycle ends before opening door or removing dishes.  |
|   | Plastics don't absorb heat like cut-<br>lery or china and don't dry as well.   | Use more intensive wash cycles (with hotter rinse water) or activate Extra Dry heat option.*  |
|   | Silverware not arranged properly in the silverware basket or top rack.   | Arrange silverware properly and separate them so they don't contact each other.   |
| Refill indicator  | No rinse aid.  | Refill rinse aid.   |
| for salt and/or<br>rinse-aid is dis-<br>played or lit.*                       | No salt (or sensor doesn't detect salt tablets).   | Refill with dishwasher softener salt.   |
| Odor Note: Water testing is done  | Food debris in the dishwasher sump and door seal.  | Clean sump filters, sump and door seal as needed. → "Care and Maintenance" on page 47   |
| in the factory.<br>Occasionally   | Food debris left on dishes too long.   | Run dishwasher more frequently.   |
| water may still appear in dish-   | Not using rinse aid or using improper detergent.   | Use rinse aid and the proper detergent.   |
| washer at pur-<br>chase which   | Residual standing water in the sump.   | Make sure previous wash cycle has finished.   |
| may create an odor.   | Drain line is clogged or drain hose is kinked, clogged or blocked. Or drain hose was not installed with a high loop. | Unclog drain line or replace drain hose. Be sure drain hose is installed with high-loop.  Note: If odor still persists, run the Normal/Regular cycle until it flushes and interrupt the cycle and place an 8 oz. cup of distilled white vinegar solution on the upper rack and then finish the cycle. |
| Dishwasher  | Water supply hose is kinked.   | Install new supply hose (without kinks).  |
| isn't filling with<br>water (or<br>"Check water<br>supply" display<br>occurs) | Previous wash cycle was not completed or current wash cycle was interrupted.   | Complete wash cycle or reset dishwasher.  |
|   | Delay start or Child lock may be activated.  | Reset Delay start or Child lock functions (refer to the appropriate sections in this manual).   |
|   | Water supply line is clogged.  | Unclog water line.  |
|   | Water supply was turned off.   | Turn on water supply.   |

## en-us Troubleshooting

| Fascia panel is discolored or scratched.                | Panel was cleaned with bleach-based wipes or abrasive cleaners/cleaning pads.  | Use mild detergents with soft damp cloth.  |
|---|--|--|
| Noise from dishes rattling or water strik-              | Dishes weren't loaded properly, allowing dishes to hit each other or spray arms.                                       | Load dishes properly into racks.  → "Loading the Dishwasher" on page 24  |
| ing tub walls.  | Light dishes or lightly loaded racks allow dishes to move or water sprays to strike tubs.                              | Load more dishes or distribute dishes more evenly/securely in the dishwasher.  |
| Water leaks<br>from tub or<br>from around<br>door.      | Suds from using the wrong detergent (i.e. dish) or overfilling/spilling rinse aid.                                     | Use an appropriate dishwasher detergent, don't overfill rinse aid and clean any spilled rinse aid. If suds still persist, add one tablespoon of vegetable oil and run the desired cycle. |
|   | Door seal was misaligned or pulled from its track.   | Make sure the door seal is securely inserted into its track.   |
|   | Condensation vent is blocked.  | Clean out vent and move tall items like trays away from the vent.  |
|   | Improper installation.   | Have an authorized service professional remount the dishwasher.  |
| White limescale on dishes, tub, racks or door.          | White residue coats dishwasher interior and racks wheels squeak from lime scale deposits in hard water.                | Use a dishwasher cleaner every few months. If dishwasher has a water softener, increase the setting.   |
|   | Hard water kept 3 in 1 detergent or Eco detergent from being effective.  | Use separate dishwasher detergent, rinse aid and dishwasher softener salt (if dishwasher has a softener).  |
|   | Under dosing of detergent.   | Use more detergent or change to a more effective detergent.  |
|   | Rinse temperature is too low.  | Select more intensive wash cycles with higher washing temperatures.  |
| Rust spots on stainless steel tub or door.              | Rusting steel (e.g. cookie sheets), silverware or cast iron cookware allowed to rest against tub walls.                | Clean stainless steel tub walls and make<br>sure steel cookware and cutlery doesn't rest<br>against tub walls. Wash cast iron cookware<br>by hand.                                       |
|   | Bleach-based wipes or abrasive cleanser used to clean tub or door.   | Use only mild detergents with a soft damp cloth to clean stainless steel tub and doors.  |
| Rust spots on cutlery ("silverware") or steel cookware. | Cutlery isn't rust-resistant (e.g. knife blades) or is washed with rusting cutlery or cookware.                        | Use rust-resistant cutlery and cookware and don't wash rusting cutlery and cookware. Keep silverware and stainless steel cutlery separated.  |
|   | Salt content was too high due to salt dispenser cap not being fastened securely or salt was spilled during refilling*. | Fasten salt dispenser cap securely and remove spilled salt.*   |

| Colored (blue, yellow, brown), film in the dishwasher or on stainless steel cutlery/ cookware.          | Film from mixture of food and mineral deposits.  | Can be partly removed with dishwasher cleaner or mechanical cleaning.  |
|---|--|--|
|   | Film formed by oxidation of silver or aluminum cookware.   | Can be partly removed with dishwasher cleaner or mechanical cleaning.  |
| Colored (yellow, orange, brown), easily removable film inside the dishwasher (mainly in the floor area) | Soapy film from mixture of food and hard water.  | Use water softener* - refill with salt or increase setting where necessary. Use dishwasher detergent instead of a 3 in 1 or Eco detergent.   |
| Plastic parts<br>stained or dis-<br>colored.  | Water drops form on plastic surfaces and leave visible stains after drying.  | Use more intensive wash cycles (which provide more water changes), arrange dishes in a sloping position and use rinse aid. If dishwasher has a water softener, increase softening setting. |
|   | Plastic parts inside the dishwasher may become discolored over time.   | Some plastics discolor normally, which is not due to the dishwasher.   |
|   | Rinse temperature is too low.  | Select more intensive wash cycles with higher washing temperatures.  |
|   | Dishes pre-cleaned too well, so dishwasher defaults to a less intensive wash cycle and stubborn soiling isn't removed.                 | Do not pre-rinse dishes and remove only large food deposits.   |
| Detergent residue in tub, detergent dispenser or  | Detergent dispenser cover 33 was blocked by dishes and doesn't open fully.   | Don't place dishes above the detergent tab tray 24. Do not place dishes or fragrance dispenser in the detergent tab tray.  |
| detergent tab<br>tray.  | Spray arms are blocked by dishes and detergent isn't rinsed out.   | Make sure spray arms can rotate freely.  |
|   | Detergent dispenser cover 33 blocked by the detergent tab.   | Detergent tab must be inserted flat and not upright.   |
|   | The detergent dispenser was damp when filled.  | Make sure the detergent dispenser is dry before adding detergent.  |
|   | Detergent tab used in the quick or short wash cycle. Dissolving time of the detergent is not reached in the selected short wash cycle. | When using quick or short wash cycles use a detergent powder or select a more intensive wash cycle.  |
|   | Old detergents can be ineffective and not dissolve well.   | Replace with fresh detergent.  |

## en-us Troubleshooting

| Irreversible clouding of glassware.                                    | Glassware not dishwasher-proof or water is too soft, causing minerals in glassware to change.                          | Use only dishwasher-proof glasses. Remove glasses promptly after cycle ends. Use lower temperature wash cycles. Set water softener according to water hardness or one setting lower. Use a detergent with glass protection. —> "Rinse Aid" on page 22 |
|--|--|---|
| Tea or lipstick  | Selected wash cycle is too weak.   | Select a more intensive wash cycle.   |
| residue on<br>dishes.  | Under dosing of detergent.   | Use more detergent or change to a more effective detergent.   |
|  | Dishes pre-cleaned too well, so dishwasher defaults to a less intensive wash cycle and stubborn soiling isn't removed. | Do not pre-rinse dishes and remove only large food deposits.  |
| Detergent dis-<br>penser cover<br>will not shut                        | Cover guides are blocked by sticky detergent residue.  | Remove detergent residue. → "Detergent" on page 36  |
| Unable to select desired cycle   | Previous cycle not finished.   | → "Operating the Dishwasher" on page 42   |
| Touch sensitive keys not activating easily or activating without being | Water or other liquid on the surface.  | Wiping the fascia with a wet cloth may cause unwanted activation. Wipe the fascia with a soft, dry cloth when possible. If you must use a damp cloth to clean, dry immediately. Never pour water on the controls.                                     |
| touched  | Touch keys not being activated properly.   | Press the center of the touch key with the flat area of your fingertip. A beep will sound to indicate that the selection has been made. Touching the keys lightly should work.  Note: There is a built-in delay to prevent                            |
|  |  | someone from launching several actions at once by accidentally wiping their hand (or a cleaning cloth) across the control panel.  |



Your Bosch® dishwasher requires no special care other than that described in the Care and Maintenance section of this manual. If you are having a problem with your dishwasher, before calling for service please refer to the Troubleshooting Guide section of the manual. If service is necessary, contact your dealer or installer or an authorized service center. Do not attempt to repair the appliance yourself. Any work performed by unauthorized personnel may void the warranty.

If you are having a problem with your Bosch® dishwasher and are not pleased with the service you have received, please take the following steps until the problem is corrected to your satisfaction:


- 1. Call us at 1-800-944-2904
- 2. Contact Customer Service from our web site:

# www.bosch-home.com/us or www.bosch-home.ca

- Contact your installer or the Bosch Authorized Service Contractor in your area.
- 4. Write us:

BSH Home Appliances Corporation 1901 Main Street Irvine, CA 92614

Please be sure to include your model information as well as an explanation of the problem and the date it started. You will find the model and serial number information on the label located on the edge of the dishwasher door. Please make a copy of your invoice and keep it with this manual. The customer may be required to show proof of purchase to validate warranty coverage.





# What this Warranty Covers & Who it Applies to:

The limited warranty provided by BSH Home Appliances Corporation (BSH) in this Statement of Limited Product Warranty applies only to Bosch® dishwashers ("Product") sold to you, the first using purchaser, provided that the Product was purchased:

- for your normal, household (non-commercial) use, and has in fact at all times only been used for normal household purposes;
- new at retail (not a display, "as is", or previously returned model), and not for resale, or commercial use; and
- within the United States or Canada, and has at all times remained within the country of original purchase. The warranties stated herein apply only to the first purchaser of the Product and are not transferable.

Please make sure to return your registration card; while not necessary to effectuate warranty coverage, it is the best way for BSH to notify you in the unlikely event of a safety notice or product recall.

# How Long the Warranty Lasts

BSH warrants that the Product is free from defects in materials and workmanship for a period of three hundred sixty five (365) days from the date of purchase. The foregoing timeline begins to run upon the date of purchase, and shall not be stalled, tolled, extended, or suspended, for any reason whatsoever.

This Product is also warranted to be free from cosmetic defects in material and workmanship (such as scratches of stainless steel, paint/porcelain blemishes, chip, dents, or other damage to the finish of the Product), for a period of thirty (30) days from the date of purchase or closing date for new construction. This cosmetic warranty excludes slight color variations due to inherent differences in painted and porcelain parts, as well as differences caused by kitchen lighting, product location, or other similar factors. This cosmetic warranty specifically excludes any display, floor, "As Is", or "B" stock appliances.

## **Extended Limited Warranty**

BSH also provides these additional limited warranties:

- 5 year limited warranty on electronics: BSH will repair or replace any BSH microprocessor or printed circuit board if it proves to be defective in materials or workmanship (excludes labor charges).
- 5 year limited warranty on dish racks: BSH will replace the upper or lower dish rack (excluding rack components), if the rack proves defective in materials or workmanship (excludes labor charges).
- Lifetime warranty against stainless steel rust through: BSH will repair or replace your dishwasher with the same model or a current model that is substantially equivalent or better in functionality, if the inner liner should rust through (excludes labor charges).
- BSH will repair or replace the stainless steel door if the door should rust through (excludes labor charges).

## Repair/Replace as Your **Exclusive Remedy**

During this warranty period, BSH or one of its authorized service providers will repair your Product without charge to you (subject to certain limitations stated herein) if your Product proves to have been manufactured with a defect in materials or workmanship. If reasonable attempts to repair the Product have been made without success, then BSH will replace your Product (upgraded models may be available to you, in the sole discretion of BSH, for an additional charge). All removed parts and components shall become the property of BSH at its sole option. All replaced and/or repaired parts shall assume the identity of the original part for purposes of this warranty and this warranty shall not be extended with respect to such parts. BSH's sole liability and responsibility hereunder is to repair manufacturer-defective Product only, using a BSH-authorized service provider during normal business hours. For safety and property damage concerns, BSH highly recommends that you do not attempt to repair the Product yourself, or use an unauthorized servicer: BSH will have no responsibility or liability for repairs or work performed by a non-authorized servicer. If you choose to have someone other than an authorized service provider work on your Product. THIS WARRANTY WILL AUTOMATICALLY BECOME NULL **AND VOID**. Authorized service providers are those persons or companies that have been specially trained on BSH products, and who possess, in the opinion of BSH, a superior reputation for customer service and technical ability (note that they are independent entities and are not agents, partners,

affiliates or representatives of BSH). Notwithstanding the foregoing, BSH will not incur any liability, or have responsibility, for the Product if it is located in a remote area (more than 100 miles from an authorized service provider) or is reasonably inaccessible, hazardous, threatening, or treacherous locale, surroundings, or environment; in any such event, if you request, BSH would still pay for labor and parts and ship the parts to the nearest authorized service provider, but you would still be fully liable and responsible for any travel time or other special charges by the service company, assuming they agree to make the service call.

## **Out of Warranty Product**

BSH is under no obligation, at law or otherwise, to provide you with any concessions, including repairs, pro-rates, or Product replacement, once this warranty has expired.

## **Warranty Exclusions**

The warranty coverage described herein excludes all defects or damage that are not the direct fault of BSH, including without limitation, one or more of the following:

- Use of the Product in anything other than its normal, customary and intended manner (including without limitation, any form of commercial use, use or storage of an indoor product outdoors, use of the Product in conjunction with air or water-going vessels);
- Any party's willful misconduct, negligence, misuse, abuse, accidents, neglect, improper operation, failure to maintain, improper or negligent installation, tampering, failure to follow operating instructions, mishandling, unauthorized service (including self-performed "fixing" or exploration of the appliance's internal workings);
- Adjustment, alteration or modification of any kind;
- A failure to comply with any applicable state, local, city, or county electrical, plumbing and/or building codes, regulations, or laws, including failure to install the product in strict conformity with local fire and building codes and regulations;
- Ordinary wear and tear, spills of food, liquid, grease accumulations, or other substances that accumulate on, in, or around the Product;

Any external, elemental and/or environmental forces and factors, including without limitation, rain, wind, sand, floods, fires, mud slides, freezing temperatures, excessive moisture or extended exposure to humidity, lightning, power surges, structural failures surrounding the appliance, and acts of God.

In no event shall BSH have any liability or responsibility whatsoever for damage to surrounding property, including cabinetry, floors, ceilings, and other structures or objects around the Product. Also excluded from this warranty are Products on which the serial numbers have been altered, defaced, or removed; service visits to teach you how to use the Product, or visits where there is nothing wrong with the Product; correction of installation problems (you are solely responsible for any structure and setting for the Product, including all electrical, plumbing or other connecting facilities, for proper foundation/flooring, and for any alterations including without limitation cabinetry, walls, floors, shelving, etc.); and resetting of breakers or fuses.

TO THE EXTENT ALLOWED BY LAW, THIS WARRANTY SETS OUT YOUR **EXCLUSIVE REMEDIES WITH** RESPECT TO PRODUCT, WHETHER THE CLAIM ARISES IN CONTRACT OR TORT (INCLUDING STRICT LIABILITY, OR NEGLIGENCE) OR OTHERWISE. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES. WHETHER EXPRESS OR IMPLIED. ANY WARRANTY IMPLIED BY LAW. WHETHER FOR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR OTHERWISE, SHALL BE EFFECTIVE ONLY FOR THE PERIOD THAT THIS EXPRESS LIMITED WARRANTY IS EFFECTIVE. IN NO EVENT WILL THE

MANUFACTURER BE LIABLE FOR CONSEQUENTIAL, SPECIAL. INCIDENTAL, INDIRECT, "BUSINESS LOSS", AND/OR PUNITIVE DAMAGES, LOSSES, OR EXPENSES, INCLUDING WITHOUT LIMITATION TIME AWAY FROM WORK, HOTELS AND/OR RESTAURANT MEALS, REMODELLING EXPENSES IN **EXCESS OF DIRECT DAMAGES** WHICH ARE DEFINITIVELY CAUSED EXCLUSIVELY BY BSH, OR OTHERWISE, SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, AND SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE. No attempt to alter, modify or amend this warranty shall be effective unless authorized in writing by an officer of BSH Home Appliances Corporation.

### **How to Obtain Warranty** Service

TO OBTAIN WARRANTY SERVICE FOR YOUR PRODUCT, YOU SHOULD CONTACT THE NEAREST BSH AUTHORIZED SERVICE CENTER, OR CALL 1-800-944-2904 en-us Statement of Limited Product Warranty

#### Wi-Fi® Module

#### FCC/IC Statements

Model: COM1 FCC ID: 2AHES-COMGEN1 IC: 21152-COMGEN1

The Home Connect module is a communication device designed to provide communication between appliances and smart devices.

This module is integrated at the factory, under direct control of B/S/H Home Appliances Corporation, and is not user serviceable or upgradable.

At least 20cm separation distance should be maintained from device to user.

#### **FCC COMPLIANCE STATEMENT**

CAUTION: Changes or modifications not expressly approved could void your authority to use this equipment.

This device complies with Part 15 of the FCC Rules. Operation to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **INDUSTRY CANADA STATEMENT**

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

BSH reserves the right to change specifications or design without notice. Some models are certified for use in Canada. BSH is not responsible for products which are transported from the United States for use in Canada. Check with your local Canadian distributor or dealer.

BSH se réserve le droit de modifier les données techniques ou le design sans préavis. Certains modèles sont certifiés pour une utilisation au Canada. BSH n'est pas responsable pour les produits transportés des États-Unis pour une utilisation au Canada. Vérifier auprès d'un marchand ou distributeur canadien.

BSH Home Appliances Corporation 1901 Main Street, Suite 600 Irvine, CA 92614 1-800-944-2904

9001410681

(9904)