









Parts List




A  16pcs	B  16pcs	C  16pcs	D 3.5X14  88pcs	F  2pcs	H  4pcs
J  4pcs	K  8pcs	L  8pcs	M  1pc	P  4pcs	



Step 1:





Step 2:




Step 3:




Step 4:




Step 5:




Step 6:




Step 7:





Step 8:




Step 9:




Step 10:







Step 11:




D	3.5X14
	8pcs
K	
	8pcs
M	
	1pc



Step 12:



D	3.5X14
	12pcs
H	
	2pcs
J	
	2pcs
P	
	2pcs



Step 13:





D 3.5X14 	H 
12pcs	2pcs
J 	P 
2pcs	2pcs

Step 14:

USE HINGE P FOR THE 2 SIDE DOORS




D 3.5X14 
32pcs




To adjust the vertical height.

Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.



To adjust depth.



Loosen screw "B" and adjust door, if the door can not be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C".




To adjust side ways.


Turning the screw "C" on BOTH hinges on each door.

Step 15:




Step 16:






1	2	A	B	C
1pc	1pc	2pcs	2pcs	12pcs
D	E	F		
2pcs	2pcs	2pcs		


Step1



Step2



Step3



Step4

