


INSTALLATION & USER MANUAL

CEILING FAN WITH LIGHT



Item#24033

Customer Service: support@breezary.com

Table of Contents

Table of Contents.....	2	Installation Instructions.....	4
Safety Information.....	2	Installation Instructions.....	5
Dimension Reference.....	3	Remote Contorl Instructions.....	11
Hardware Included.....	3	Troubleshooting Guide.....	12
Fan Parts Included.....	3		

Safety Information

READ AND SAVE THESE INSTRUCTIONS.

1. To reduce the risk of electric shock, ensure electricity has been turned off at the circuit breaker or fuse box before you begin.
2. All wiring must be in accordance with the National Electrical Code “ANSI/NFPA 70” and local electrical codes. Electrical installation should be performed by a qualified licensed electrician.
3. The outlet box and support structure must be securely mounted and capable of reliably supporting a minimum of 35 lbs (15.9 kg). Use only UL Listed outlet boxes marked “Acceptable for Fan Support of 35 lbs.(15.9 kg) or less. ”
4. Do not place objects in the path of the blades.
5. To clean the fixture,turn off the power, wait for it to cool, and wipe the fixture with a clean, soft cloth.
6. After making electrical connections, spliced conductors should be turned upward and pushed carefully up into the outlet box. The wires should be spread apart with the grounded conductor and the equipment-grounding conductor on one side of the outlet box and ungrounded conductor on the other side of the outlet box.
7. All setscrews must be checked and retightened where necessary before installation.

!

WARNING:To reduce the risk of electrical shock or fire, not use this fan with any solid-state fan speed control device. It will permanently damage the electronic circuitry.

!

WARNING:To reduce the risk of personal injury, do not bend the blade brackets when installing the rackets balancing the blades, or cleaning the fan. Do not insert

!

WARNING:To reduce the risk of fire, electric shock or personal injury, mount to outlet box marked "acceptable for fan support of 35 lbs. (15.9 Kg) or less" and use screws provided with the outlet box.

!

WARNING:To avoid possible electrical shock, turn the electricity off at the main fuse box before wiring.

!

WARNING:To reduce the risk of electrical shock, this must be installed with an isolating wall control / switch.

!

CAUTION:To reduce the risk of personal injury,use only the screws provided with the outlet box.

!

CAUTION:Please use carefully when working around or cleaning the fan to avoid injury or damage of fan.


!

CAUTION:The fan must be mounted with a minimum of 7 ft (2.1 m) clearance from the trailing edge of the blades to the floor.










!

CAUTION:Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.








Dimension Reference




Hardware Included

Hardware Package				Quantity
	S1		S7	2
	S2		S8	2
	S3		S9	2
	S4			4
	S5			6
	S6			4
				4
				9

Fan Parts Included

Item Name		Quantity
	1. Hanger Bracket	1
	2. Outer Cover	1
	3. Motor Assembly	1
	4. Light Kit	1
	5. Lampshade	1
	6. Remote Control (Batteries not included)	1
	7. Blade	3


Exploded View




Installation Instructions

Step1 INSTALL HANGER BRACKET

- If it is installed on the cement top and don't have outlet box, please use two expansion screws.
- Use an impact drill to drill two $\Phi 8\text{mm}$ holes , Note that the distance between the two holes is about 100mm.
 - Completely insert the pipe part of the screw into the hole and remove the washer and nut.
 - Place the hanger into the screw head, place the washer, and then use a wrench to tighten the nut.





- If installed on a wooden roof, use four wooden teeth screws.
- Use an electric drill to lock the wooden screw onto the top through the four mounting holes on the hanger bracket.




Installation Instructions

- If installed on a wooden roof, use four wooden teeth screws.
- Remove the four screws from the hanger bracket.




Step2 MOUNTING BLADES TO MOTOR

- Install the blades on the motor as shown in the figure.



- Lock the three blades in sequence, Place it on the cardboard box.







Installation Instructions

Step3 LIGHT KIT

WARNING:BE SURE TO TURN OFF POWER BEFORE INSTALLING

- Remove light kit screws.(Fig.3a)
- Align the light kit hole with hte connecting piece and lock the screw.(Fig.3b)
- Insert the terminal of the light wire into the light source port.(Fig.3c)
- Place Lampshade onto the fan and turn to secure.(Fig.3d)





WARNING: Check all connections,set screws and screws are securely tightened before the next step.

Installation Instructions

Step4 CONNECT A WIRE

WARNING: BE SURE TO TURN OFF POWER BEFORE INSTALLING


- Install the internal screws of the outer cover.(Fig.4a)
- Secure the mounted ceiling fan and wire it up(Fig.4b)



Installation Instructions

Step5 CONNECTION REMOTE CONTROL

- A. Make the following wire connections to the receiver unit (see fig. 5a) using the wire nuts supplied
- Connect GREEN fan wire to BARE (earth) wire.
 - Connect BLACK receiver unit wire to BLACK supply wire.
 - Connect WHITE receiver unit wire to WHITE supply wire.
 - After making the wire connections, ensure the wires should be spread apart with the grounded conductor and the equipment-grounding conductor on one side of the outlet box and the ungrounded conductor on the other side of the outlet box.
 - Ensure the splices after being made should be turned upward and pushed carefully up into the outlet box.





NOTE: Once ground wires are connected, carefully tuck all wires and marrettes into the metal box making sure that the wires are clear of the hemisphere and downrod when positioned in hemisphere and downrod when positioned in mounting bracket.

Installation Instructions

Step6 TOP MOUNT


WARNING:BE SURE TO TURN OFF POWER BEFORE INSTALLING

- Reserve housing position on both sides of the screw.(Fig.6a)
- Tighten the four screws.(Fig.6b)



Installation Instructions

- FUNCTION INSTRUCTION OF E MITTER


- Learning code and matching mode is used between emitter and receiver.
- Open battery cover on the hand-held remote and install battery, pair of AAA of emitter (1.5V) that are not included.
- If the emitter can not control the fan, learning code matching mode is used between emitter and receiver.
Turn “ON” the supply power within 10 seconds and press the emitter’s “” button for 5 seconds, it can load normally after hearing a long sound “bee”, which means learning successfully and it can works normally.
- When the emitter cannot control the receiver,please check the battery switch touching normally or not, correction of the positive and negative, full or empty of the power.
- When the emitter cannot control the receiver, please check is there any existence of similar remote controlled products nearby, then check whether they works, because remote controlled product with the same frequency will disturb each other.
- Please take out the battery from the emitter when leaving unused for long time.
- When installing the fan, the fan ceiling cover don’t press the antenna(or other wire),it is easy to breakdown the wire and short-circuited.

- ① Speed Control
- ② FAN ON/OFF
- ③ FAN Forward/Reverse
- ④ Timer
- ⑤ Light ON/OFF
- ⑥ Natural wind

Light Memory Function:

- 1.The default light color when the ceiling fan is turned on.
- 2.The light will lock in a specific color temperature after turning off the light for 1 minute.
- 3.The color temperature will be the same as the last time when turning on the light next time.

NOTICE: If you turn it on and off immediately, it will change the light color.



Troubleshooting Guide

If you have difficulty in operating your new ceiling fan it may be the result of incorrect assembly, installation, or wiring. In some cases these installation errors may be mistaken for defects. If you experience any faults please check this troubleshooting guide.

	Problem	Suggested Remedy
1	If fan does not work .	<div> <input type="checkbox"/> Check the main and branch circuit fuses or breakers. <input type="checkbox"/> Check the line wire connections to the fan and switch wire connections in the switch housing. <input type="checkbox"/> Check the battery in the remote control. <input type="checkbox"/> Ensure you are in the normal range of 10-20 feet. </div>
2	If fan sounds noisy.	<div> <input type="checkbox"/> Ensure all motor housing screws are snug. <input type="checkbox"/> Ensure the screws that attach the fan blade bracket to the motor hub are tight. <input type="checkbox"/> Ensure the wire nut connections are not rattling against each other or the interior wall of the switch housing. <input type="checkbox"/> Allow a 24-hour “breaking in” period. Most noises associated with a new fan disappear during this time. <input type="checkbox"/> If you are using the Ceiling Fan light kit, ensure the screws securing the glassware are tight. Check that the light bulbs are also secure. <input type="checkbox"/> Ensure the canopy is a short distance from the ceiling. It should not touch the ceiling. <input type="checkbox"/> Ensure your outlet box is secure and rubber isolator pads were used between the mounting plate and outlet box. </div>
3	If fan wobbles.	<div> <input type="checkbox"/> Check that all blades are screwed firmly into blade holders. <input type="checkbox"/> Check that all blade holders are tightened securely to motor. <input type="checkbox"/> Make sure that canopy and mounting bracket are tightened securely to ceiling junction box and junction box is mounted firmly to ceiling joist. <input type="checkbox"/> Most fan wobble problems are caused when blade levels are unequal. Check this level by selecting a point on the ceiling above the tip of one of the blades keeping measure within 1/8 in. Rotate the fan until the next blade is positioned for measurement. Repeat for each blade. If all blade levels are not equal you can adjust blade levels by the following procedure. To adjust a blade tip down insert a washer (not supplied) between the blade and blade holder at the screw closest to the motor. To adjust a blade tip up insert washer (not supplied) between the blade and blade holder at the two screws farthest from the motor. <input type="checkbox"/> If blade wobble is still noticeable interchanging two adjacent (side by side) blades can redistribute the weight and possibly result in smoother operation. </div>
4	If light does not work.	<div> <input type="checkbox"/> Check blue wire from fan to make sure it is connected to hot wire from the house. <input type="checkbox"/> Check for loose or disconnected wires in fan switch housing. <input type="checkbox"/> Check for loose or disconnected wires in light kit. <input type="checkbox"/> Check for faulty light bulbs. CAUTION: Make sure main power is turned off before entering switch housing. <input type="checkbox"/> If the fan light shuts off shortly after being switched on it may be due to excessive current demand. Turn off power to the fan and replace the light bulbs with lower wattage bulbs. Turn on power to the fan using the pull chain, wall switch, or remote control (whichever is installed on the particular fan). </div>