


- (en) **Operator's Manual** - Dual Stage Snowthrower
- (es) **Manual del operador** - Lanzanieve de dos etapas
- (fr) **Manuel de l'utilisateur** - Souffleuse à neige à deux phases



Manual Contents:

General Information.....	2
Operator Safety.....	2
Features and Controls.....	5
Operation.....	6
Maintenance and Adjustments.....	12
Storage.....	18
Troubleshooting.....	19
Specifications.....	20

General Information

For additional information, refer to the *Customer Contact Guide* and *Setup Instructions* included with the unit.

The illustrations in this document are representative. Your unit may vary from the images shown. *LEFT* and *RIGHT* are referenced from the operating position.

The use of Important and Note in the text indicates clarifications, exceptions, or alternatives to the procedures given.

All language translations of this document are derived from the original English source file.



All packaging, used oil, and batteries should be recycled according to applicable government regulations.

Operator Safety

Save these instructions for future reference. This manual contains safety information to make you aware of the hazards and risks associated with the product and how to avoid them. It also contains important instructions that should be followed during the initial set-up, operation, and maintenance of the product.


The snowthrower is designed and intended only for clearing of snow from hard-surface ground-level walkways and driveways and is not intended for any other purpose.

It is important that you read and understand these instructions before attempting to start or operate this equipment.

Be thoroughly familiar with the controls and the proper use of the snowthrower.

Know how to stop the unit and disengage controls quickly.

Safety Alert Symbol and Signal Words

The safety alert symbol  is used to identify safety information about hazards that can result in personal injury. A signal word (DANGER, WARNING, or CAUTION) is used with the alert

symbol to indicate the likelihood and the potential severity of injury. In addition, a hazard symbol may be used to represent the type of hazard.


















⚠ DANGER indicates a hazard which, if not avoided, **will result in death or serious injury.**

⚠ WARNING indicates a hazard which, if not avoided, **could result in death or serious injury.**

⚠ CAUTION indicates a hazard which, if not avoided, **could result in minor or moderate injury.**

NOTICE indicates an situation that **could result in damage to the product.**

Snowthrower Hazard Symbols

Symbol	Meaning	Symbol	Meaning
	Safety information about hazards that can result in personal injury.		Read and understand the operator's manual before operating or servicing the unit.
	Amputation hazard - rotating impeller.		Remove the key before performing service. Read the operator's manual before performing service.
	Amputation hazard - rotating impeller.		Amputation hazard - rotating auger
	Amputation hazard - do not touch moving parts.		Thrown objects hazard.
	Fire hazard.		Explosion hazard.
	Shock hazard.		Toxic fume hazard.
	Hot surface hazard.		Kickback hazard.
	Keep a safe distance.		Keep children away.
	Wear safety glasses	---	---

Safety Messages



This snowthrower is capable of amputating hands and feet, and throwing objects. Read and observe all the safety instructions in this manual. Failure to do so could result in death or serious injury.

Hand contact with the rotating impeller inside the discharge chute is the most common cause of injury associated with snowthrowers.



Read, understand, and follow all the instructions on the snowthrower and in the operator's manual before operating this unit. Failure to observe the safety instructions in this manual could result in death or serious injury.

- Only allow operators who are responsible, trained, familiar with the instructions and physically capable to operate the machine.



Always wear safety glasses or eye shields during operation or while performing an adjustment or repair to protect eyes from foreign objects that may be thrown from the machine.



U.S.A. Models: Certain components in this product and its related accessories contain chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm. Wash hands after handling.



U.S.A. Models: The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.


U.S.A. Models: It is a violation of California Public Resource Code Section 4442 to use or operate the engine on any forest-covered, brush-covered, or grass-covered land unless the exhaust system is equipped with a spark arrester, as defined in Section 4442, maintained in effective working order. Other states or federal jurisdictions may have similar laws. Contact the original equipment manufacturer, retailer, or dealer to obtain a spark arrester designed for the exhaust system installed on this engine.

Safety Decals

Before operating your unit, read the safety decals. Compare Figure 1 with the table below. The cautions and warnings are for your safety. To avoid personal injury or damage to the unit, understand and follow all the safety decals.

Important: If any safety decals become worn or damaged, and cannot be read, order replacement decals from your local dealer.

1



B

⚠ DANGER		
Amputation Hazard <ul style="list-style-type: none"> • Contact with auger will cause serious injury. • Keep hands, feet and clothing away. • Keep bystanders away. 		Risque d'amputation <ul style="list-style-type: none"> • Tout contact avec la tarière provoquera de graves blessures. • Tenir vos pieds, vos mains et vêtements à distance. • Tenir les spectateurs à distance.
Thrown Objects Hazard <ul style="list-style-type: none"> • Never direct discharge chute towards persons or property. 		Danger objets projetés <ul style="list-style-type: none"> • Ne jamais diriger la chute en direction des personnes ou biens matériels.
Read the operator's manual for operating and safety instructions.		Lire les consignes de sécurité et d'utilisation dans le manuel d'utilisation.
Shut off engine and remove key before performing maintenance or repair work.		Arrêter le moteur et retirer la clé avant d'effectuer tout entretien ou toute réparation.
<small>This spark ignition system complies with the Canadian standard IC2S-002. Ce système d'allumage par étincelle de véhicule est conforme à la norme MM-002 du Canada.</small>		

C


WARNING ⚠ AVERTISSEMENT	
Read and follow Operating Instructions before running engine.	Lire et suivre le mode d'emploi avant de faire tourner le moteur.
Gasoline is flammable. Allow engine to cool at least 2 minutes before refueling.	L'essence est inflammable. Laisser refroidir le moteur pendant au moins 2 minutes avant de faire le plein.
Engines emit carbon monoxide. DO NOT run in enclosed area.	Les moteurs émettent du monoxyde de carbone. NE PAS faire tourner le moteur dans des espaces clos.
Muffler area temperature may exceed 150°F. Do not touch hot parts.	Autour du silencieux, la température peut dépasser 150° F. Ne pas toucher des pièces chaudes.

A




⚠ DANGER
Amputation hazard <p>Contact with moving parts inside chute will cause serious injury.</p> <ul style="list-style-type: none"> • Shut off engine before unclogging discharge chute. • Use clean-out tool, not hands!
Risque d'amputation <p>Tout contact avec des pièces en mouvement à l'intérieur de la goulotte provoquera de graves blessures.</p> <ul style="list-style-type: none"> • Arrêter le moteur avant de dégager la goulotte d'éjection. • Utiliser l'outil de dégagement, pas les mains!






Features and Controls







Match the call out letters in Figure 2 to the features and controls listed in the accompanying table.



Control Symbols and Meanings

A		Auger Control Lever
B		Speed Selector Lever
C		Deflector Control - In Dash
D		Chute Rotation Crank - In Dash

E		Free Hand™ Feature
F		Steerable Control Lever
G		Traction Control Lever
H		Clean-Out Tool
I		Skid Shoes
J		Headlight

K		Fuel Shut-Off Valve
L		Throttle Control
M		On/Off Switch
N		Choke Closed; Choke Open
O		Primer Button
P		Grp Warmer Switch

Operation



WARNING

This snowthrower is only as safe as the operator. If it is misused, or not properly maintained, it can be dangerous. Remember you are responsible for your safety and those around you.

- When leaving the operating position always disengage the auger, turn off the engine, and remove the key. Never leave a running machine unattended.
- Never operate the snowthrower without proper guards, and other safety protective devices in place and working.
- Be careful when operating on or crossing gravel drives, walks, or roads. Stay alert for hidden hazards or traffic.
- Never operate the snowthrower without good visibility or light. Always be sure of your footing, and keep a firm hold on the handles. Walk; never run.
- Be careful to avoid slipping or falling, especially when operating the snowthrower in reverse.
- Be careful when operating on slopes.
- After striking a foreign object, stop the engine, remove the wire from the spark plug, thoroughly inspect the snowthrower for any damage, and repair the damage before restarting and operating the snowthrower.
- Do not operate the equipment without wearing adequate winter garments. Avoid loose fitting clothing that can get caught in moving parts. Wear footwear that will improve footing on slippery surfaces.
- Never touch a hot muffler or engine. Allow muffler and engine cylinder to cool before touching.

Operating Area

1. Familiarize yourself with the area in which you plan to operate the snowthrower. Mark off all boundaries of walkways and driveways.
2. Ensure the area to be cleared is free of debris or objects that could be picked up by the auger and thrown from the chute.



WARNING



This machine is capable of throwing objects that could injure bystanders or cause damage to buildings.

3. Before starting the engine, move the snowthrower outdoors and away from windows and doors.



WARNING



Engines give off carbon monoxide, an odorless, colorless, poison gas. Breathing carbon monoxide can cause nausea, fainting, or death.

- Start and run engine outdoors.
 - Do not run the engine in an enclosed area, even if doors or windows are open.
4. Ensure the operating area is clear of bystanders, especially children.



This snowthrower is capable of amputating hands and feet, and throwing objects. Read and observe all the safety instructions in this manual. Failure to do so could result in death or serious injury.

- Keep children out of the area during operation.
- Children are often attracted to the equipment. Be mindful of all persons present.
- Be alert and turn the unit off if bystanders enter the area.
- Use extra care when approaching blind corners, shrubs, trees, or other objects that may obscure vision.

Starting the Engine


Checking Oil

NOTICE The engine was shipped from the factory without oil. Before you start the engine, ensure that you add oil according to the instructions in this manual. If you start the engine without oil, it will be damaged beyond repair and will not be covered under the warranty.

Use Briggs & Stratton Synthetic 5W-30 Warranty Certified oil for best performance. Other high-quality detergent oils are acceptable if classified for service SG, SH, SJ or higher. Do not use any additives.

1. Place the unit on a level surface.
2. Clean the oil fill area of any moisture or debris.
3. Remove the oil dipstick (A, Figure 3) and wipe it with a clean cloth.
4. Insert and tighten the dipstick, then remove it again to check the oil level. It should be at the top of the full indicator (C)
5. To add oil, pour slowly into the engine oil fill (B). Do not overfill.
6. Wait one minute before checking the oil level.
7. When the oil level is at the top of the full indicator (C), install and tighten the dipstick.

3



Adding Fuel

Fuel must meet these requirements:

- Clean, fresh, unleaded gasoline
- A minimum of 87 octane / 87 AKI (90 RON)
- Up to 10% ethanol is acceptable

NOTICE Do not use unapproved gasolines, such as E15 and E85. Do not mix oil in gasoline or modify the engine to run on alternate fuels. Use of unapproved fuels will cause engine damage that will not be covered under warranty.

This engine is certified to operate on gasoline. The emissions control system for this engine is EM (Engine Modifications).

At altitudes over 5,000 feet (1524 meters), a minimum 85 octane / 85 AKI (89 RON) gasoline is acceptable. To remain emissions compliant, high altitude adjustment is required. Operation without this adjustment will cause decreased performance, increased fuel consumption, and increased emissions. See an authorized service dealer for high altitude adjustment information. Operation altitudes below 2,500 feet (762 meters) with the high altitude adjustment is not recommended.




Fuel and its vapors are extremely flammable and explosive. Always handle fuel with extreme care. Failure to observe these safety instructions can cause a fire or explosion which could result in severe burns or death.

- Do not add fuel while engine is running. Let the engine cool at least 2 minutes before adding fuel.
- Fill the fuel tank outdoors only, using an approved fuel container with the unit directly on the ground.
- Keep fuel away from sparks, open flames, pilot lights, heat, and other ignition sources.
- Allow any spilled fuel to evaporate before starting the engine.

- If fuel is spilled on clothing change clothing immediately.

1. Slowly remove the fuel cap (A, Figure 4) and fill the tank (B) with fuel. Do not fill higher than the bottom of the fuel tank neck (C).
2. Reinstall the fuel cap. Allow any spilled fuel to evaporate before starting the engine.



Starting Engine



Fuel and its vapors are extremely flammable and explosive. Always handle fuel with extreme care. Failure to observe these safety instructions can cause a fire or explosion which could result in severe burns or death.


- Ensure that spark plug, muffler, fuel cap, and air cleaner (if equipped) are in place and secured.
- Do not crank the engine with the spark plug removed.
- Do not use pressurized starting fluids because their vapors are flammable.
- Do not over-prime the engine. Follow the engine starting instructions in this manual.
- If the engine floods, set choke (if equipped) to OPEN/RUN position, move throttle (if equipped) to FAST position and crank until engine starts.

1. Ensure the auger control (A, Figure 5) and traction control (K) are disengaged.
2. Turn the fuel shut-off valve (C) (if equipped) to the Open position.
3. Move the throttle control (D) (if equipped) to the Fast position.
4. Insert the ignition key (E) and turn it to the ON position or insert the push/pull key.
5. Turn the choke control (F) to the Closed position.

Note: Choke is usually not needed when starting a warm engine.

6. Press the primer (G) two times.

Note: Primer is usually not needed when starting a warm engine.



7. For rewind start: Firmly hold the starter cord handle (H). Pull the handle slowly until resistance is felt, then pull rapidly.



Rapid retraction of the starter cord (kickback) will pull your hand and arm toward the engine faster than you can let go. Broken bones, fractures, bruises, or sprains could result.

8. For electric start: Connect the extension cord (A, Figure 6) to the starter box (B) on the engine, and then to the wall receptacle (C). Press the starter box pushbutton (D). After the engine starts, disconnect the extension cord from the wall receptacle and then from the starter box.



Damaged or ungrounded power cords could cause electric shock. Electric shock could cause severe burns or death.

- Use only a three-conductor power cord properly grounded to the power source.
- If the extension cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person.


NOTICE

To extend the life of the starter, use short starting cycles (five seconds maximum). Wait one minute between starting attempts.

If the engine does not start after repeated attempts, contact an authorized service dealer or go to our website.

9. Allow the engine to warm up for several minutes. Gradually move the choke control (F, Figure 5) to the Open position.

6



Stopping the Engine

1. Turn the ignition key (E, Figure 5) to the Off position and remove it or remove the push/pull key (if equipped).
2. Keep the key in a safe place out of the reach of children. The engine cannot be started without the key.

Adjusting the Discharge Chute and Deflector



WARNING



Ice, gravel, or other unintended objects can be picked up by the auger and thrown from the chute with force.

Objects thrown from the chute could cause death, serious injury, or property damage.

- Always be aware of the direction the snow is being thrown.

1. Rotate the chute rotation crank (I, Figure 5) to set the direction of the discharge chute.
2. Use the deflector control lever (J) to move the deflector up or down. Raise the deflector to throw snow further.

Engaging the Auger and Impeller

The auger and impeller work together to break up the snow as the snowthrower moves forward and throws it out the discharge chute.



DANGER



The snowthrower contains a rotating auger and impeller to throw snow. Fingers or feet can quickly become caught in the auger or impeller resulting in traumatic amputation or severe laceration.

1. Fully press the auger control lever (A, Figure 5) on the left handle to engage the auger and impeller.
2. Release the lever to stop the auger. The auger must stop within 5 seconds after the auger control is released. If it does not:
 - Adjust the control cable. See *Adjusting the Auger and Traction Cable*.
 - If the auger still does not stop within 5 seconds, see an authorized dealer.

Engaging the Drive Wheels

NOTICE Do not move the speed select control while the traction control is engaged. This may result in damage to the drive system.


1. To drive forward, shift the speed select control (B, Figure 5) into one of the forward positions. Select a lower number for heavy snow, a middle number for light snow, and a higher number for light snow or transporting.
2. To move press and hold down the traction control (K) on the right handle.
3. To stop, release the traction control. Unit must stop immediately. If it does not:
 - Adjust the traction control cable. See *Adjusting the Auger and Traction Cable*.
 - If the unit still does not stop, see an authorized dealer.
4. To drive backward, shift the speed select control into one of the reverse positions.
5. Press and hold down the traction control on the right handle.
6. To stop, release the traction control. Unit must stop immediately. If it does not:
 - Adjust the traction control cable. See *Adjusting the Auger and Traction Cable*.
 - If the unit still does not stop, see an authorized dealer.

NOTICE Do not overload the machine capacity by attempting to clear snow at too fast of a rate.

Using the Steering Feature

This model is equipped with a steering feature. A small trigger under each hand grip controls the steering of the machine.


1. Engage the traction control lever (A, Figure 7) to move the machine forward.
2. Pull up on the left trigger (B), to turn left.
3. Release the left trigger, to continue straight.
4. Pull up on the right trigger (C), to turn right.
5. Release the right trigger, to continue straight.




Using Free Hand™ Feature

Some models are equipped with the Free Hand™ feature, which allows the operator to release the auger control to reach other controls without stopping the unit. If your model is equipped with Free Hand, it will have the decal shown in Figure 8 affixed to the dash panel.

8



9



1. Press down and hold the auger control (A, Figure 9).
2. Press down and hold the traction control (B).
3. Release the auger control so the left hand is free to reach other controls.
 - If the auger stops, see an authorized dealer.

Note: Free Hand cannot be actuated by releasing the traction control.

Clearing a Clogged Discharge Chute




DANGER

The discharge chute contains a rotating impeller to throw snow. Fingers can quickly become caught in the impeller resulting in traumatic amputation or severe laceration. Never clear a clogged discharge chute with your hands. Always use a clean-out tool.

To safely clear a clogged discharge chute, follow these instructions:


1. Stop the engine and remove the key.
2. Ensure that the impeller has stopped rotating.
3. Use a clean-out tool (A, Figure 10) to remove snow from the discharge chute. Never clear a clogged discharge chute with your hands!

10



2. Turn off the grip warmer switch before stopping the snowthrower.

11




Using the Wheel Release - Lock Pins

One or both wheels can be temporarily disengaged from the drive axles for ease of handling when transporting the unit.

1. Open the pull ring (A, Figure 12) over the wheel hub.

12



2. Insert the retaining pin through the outer hole in the axle and close the pull ring over the axle.
3. To engage the wheel and axle, align the wheel hub and the inner axle hole, then install the retaining pin fully and close the pull ring over the wheel hub.

Using the Headlight

Some models are equipped with a headlight (L, Figure 5) to help illuminate the area in front of the snowthrower. The headlight is on whenever the engine is running. There is no switch.

Using the Heated Hand Grips

1. Turn on the grip warmer switch (A, Figure 11) to activate the heated hand grips.

Maintenance and Adjustments

We recommend contacting an authorized service dealer for all maintenance, adjustments, and servicing of the unit. Some routine maintenance tasks can be performed by the owner. Refer to the maintenance schedule and procedures that follow.

CAUTION

All the components used to build this product must remain in place for proper operation. Replacement parts must be of the same design and installed in the same position as the original parts. Other parts may not perform as well, may damage the unit, and may result in injury.

WARNING

This snowthrower must be properly maintained to ensure safe operation and performance. Failure to observe the safety instructions in this manual could result in death or serious injury.

- Before performing any maintenance or repairs on the snowthrower, shut OFF the engine and remove the ignition key or the push/pull key.

Maintenance Schedule

First 5 Hours
Change oil
Before Each Use
<ul style="list-style-type: none">• Check engine oil level• Check auger and impeller stop time
After Each Use
Remove accumulated snow and slush to prevent freezing of the controls, wheels, discharge chute, and auger
Every 25 Hours or Annually
<ul style="list-style-type: none">• Change the engine oil• Check tire pressure• Check auger and traction cable adjustment• Lubricate control lever linkages• Lubricate the discharge chute and deflector• Lubricate the auger assembly• Lubricate the hex shaft and gear• Lubricate the drive wheel axles• Check muffler and spark arvester (if equipped)• Clean, gap, or replace sparkplug (dealer service)

- Check valve clearance (dealer service)

Emissions Control

Maintenance, replacement, or repair of the emissions control devices and systems may be performed by any non-road engine repair establishment or individual. However, to obtain "no charge" emissions control service, the work must be performed by a factory authorized dealer.

Changing the Engine Oil

Used oil must be disposed of properly. Do not discard with household waste. Check with your local authorities, service center, or dealer for safe disposal or recycling facilities.


Use Briggs & Stratton Synthetic 5W-30 Warranty Certified oil for best performance. Other high-quality detergent oils are acceptable if classified for service SG, SH, SJ or higher. Do not use any additives.

1. With the engine stopped but still warm, turn the ignition key to the OFF position and remove it or pull out the push/pull key (if equipped).

WARNING

Fuel and its vapors are extremely flammable, which could cause burns or fire resulting in death or serious injury.


- When performing maintenance that requires the unit to be tipped, the fuel tank must be empty or fuel can leak out and result in a fire or explosion.
2. Remove the oil drain plug (D, Figure 13) and tilt the snowthrower slightly to drain the oil into an appropriate container.
 3. After the oil has drained, install and tighten the oil drain plug (D).



4. Place the unit on a level surface.
5. Clean the oil fill area of any moisture or debris.

6. Remove the dipstick (A, Figure 14) and wipe it with a clean cloth. Set it aside.

14



7. To add oil, pour slowly into the engine oil fill tube (B). See Specifications for the oil capacity. Do not overfill.
8. Wait one minute before checking the oil level.
9. Insert and tighten the dipstick, then remove it again to check the oil level. It should be at the top of the full indicator (C).
10. When the oil level is at the top of the full indicator, install and tighten the dipstick.

Adjusting the Skid Shoe Height



DANGER

This snowthrower contains a rotating auger to collect snow. Fingers can quickly become caught and traumatic amputation or severe laceration will result.

Turn the engine OFF, wait for all moving parts to stop, and remove the ignition key or push/pull key before performing any maintenance or repairs.



WARNING

If struck by the auger or impeller, objects such as gravel, rocks, or other debris may be thrown with sufficient force to cause personal injury, property damage, or damage to the snowthrower.

Skids shoes are secured to either side of the auger housing. They can be adjusted to increase or decrease the distance between the scraper bar and the surface to be cleared.

Set the skid shoes at the proper height to maintain ground clearance for the type of surface being cleared.


1. Shut the engine off and remove the key.
2. Determine the scraper bar clearance needed for the surface to be cleared.

- When removing snow from a hard surface area such as a paved driveway or walk, adjust the skids shoes up to lower the scraper bar closer to the surface.
- When removing snow from gravel-covered or uneven surfaces, adjust the skids shoes down to raise the scraper bar further from the surface. This will help prevent rocks and other debris from being picked up and thrown by the auger and impeller.

3. Place the unit on a level surface.
4. Loosen the skid shoe mounting nuts (A, Figure 15) on the skid shoe (B).
5. Under each end of the scraper bar, place a wooden block of the same thickness as the desired clearance height.
6. Allow each skid shoe to firmly touch the surface. Then tighten the mounting nuts.

NOTICE To prevent contact with the auger, ensure the mounting nuts are to the outside of the auger housing.


15



Lubricating the Control Lever Linkage

Lubricate the control lever linkage (A) at the locations shown in Figure 16. Use fresh, clean engine oil.


16



Lubricating the Discharge Chute, Deflector, and Wheel Axle

1. Shut off the engine and remove the key.
2. At the locations shown in Figure 17:
 - Lubricate the discharge chute (A) with lithium grease.
 - Lubricate the deflector (B) with fresh, clean engine oil.
 - Lubricate both wheel axles (C) with lithium grease.


17



Lubricating the Auger Assembly

1. Shut off the engine and remove the key.
2. Lubricate the auger shaft assembly (A, Figure 18) with grease at the grease fittings, (if equipped).

18



Lubricating the Hex Shaft and Gear

For friction drive systems only:

NOTICE Do not allow grease or oil to contact the rubber friction wheel or the disc drive plate. If grease or oil comes into contact with the friction wheel, replace it. Do not attempt to clean it. If grease or oil comes into contact with disc drive plate, clean it thoroughly with an alcohol based solvent.


1. Shut off the engine and remove the key.
2. Position speed select lever in the first forward gear.



Fuel and its vapors are extremely flammable, which could cause burns or fire resulting in death or serious injury.


- When performing maintenance that requires the unit to be tipped, the fuel tank must be empty or fuel can leak out and result in a fire or explosion.
3. Stand the snowthrower up on the auger housing end.
Note: When the crankcase is filled with oil, do not leave the snowthrower standing up on the auger housing for an extended period of time.
 4. Remove screws (A, Figure 19) and bottom panel (B).

19



5. Wipe the hex shaft (C, Figure 20) with motor oil, before storage and at the beginning of each season.
6. Lubricate the sprocket (D) and chain (E) with motor oil, before storage and at the beginning of each season.

20



7. Install the bottom panel (B, Figure 19) and screws (A).

Adjusting the Auger and Traction Cable



The snowthrower contains a rotating auger and impeller to throw snow. Fingers or feet can quickly become caught in the auger or impeller resulting in traumatic amputation or severe laceration.

- Over-tightening the auger and impeller cable may cause the auger and impeller to rotate even if the auger control is not pressed down.
- Over-tightening the traction cable may cause the drive to engage even if the traction control is not pressed down.


Follow the adjustment procedure to ensure the cables are not over-tightened.

The auger and impeller should rotate only when the auger control is engaged and must stop within 5 seconds when the auger control is released. If the auger and impeller do not rotate or do not stop as described, adjust the control cable or contact an authorized service dealer to adjust the control cable.

The unit should only move when the traction control is engaged and must stop immediately when the traction control is released. If the unit does not stop as described, adjust the control cable or contact an authorized service dealer to adjust the control cable.

1. Shut off the engine and remove the key.
2. Loosen jam nut (A, Figure 21).

21



3. Hold control cable (B) to keep it from rotating.
4. Turn collar (C) to remove slack but do not over-tighten.
5. Tighten jam nut.
6. After adjustment, check the operation of the auger and traction controls, as well as the Free Hand feature using the tests below:

Test 1 - Auger/Impeller Control

With the engine running:

- Press down on the auger control lever. (The auger/impeller should rotate)
- Release the auger control lever. (The auger/impeller must stop within 5 seconds)

Test 2 - Traction Drive Control

With the engine running and speed control in 1st gear:

- Press down on the traction control lever. (The unit should move forward)
- Release the traction lever. (The unit must stop)

Test 3 - Free Hand Feature

With the engine running:

- Engage the auger and traction control levers, then release the auger control lever. (Both controls should remain engaged)
 - Next, release the traction control lever. (Both controls must release)
7. If the unit does not operate as described, DO NOT use it. Contact an authorized service dealer to have the unit inspected and adjusted or repaired.

Adjusting the Steering Feature Cables




The snowthrower contains a rotating auger and impeller to throw snow. Fingers or feet can quickly become caught in the rotating auger or impeller resulting in traumatic amputation or severe laceration.

- Turn the engine OFF, wait for all moving parts to stop, and remove the ignition key or push/pull key before performing any maintenance or repairs.

The Steering cable may stretch slightly after repeated usage during the first season of operation. If the cable has stretched, it may prevent the drive gears from disengaging when the control is activated.

1. Shut off the engine and remove the key.
2. Use one wrench to hold stationary the adjustment nut (B, Figure 22) while using another wrench to loosen the jam nut (A).
3. With the Steering control released, rotate the adjustment nut (B) clockwise or counterclockwise until slack is removed from the cable. Do not make the cable tight or it will actuate the Steering feature even when the control is not engaged.
4. When adjustment is complete, hold stationary the adjustment nut (B) and tighten the jam nut (A).

22




Replacing the Auger Shear Bolt



The snowthrower contains a rotating auger and impeller to throw snow. Fingers or feet can quickly become caught in the auger or impeller resulting in traumatic amputation or severe laceration.

- Turn the engine OFF, wait for all moving parts to stop, and remove the engine key before performing any maintenance or repairs.
1. Shut off the engine and remove the key.
 2. Remove the existing shear bolt (A, Figure 23) and locknut (C).
 3. Add grease at the auger grease fittings, (if equipped). Spin the auger to lubricate the auger shaft.
Note: Some models are not equipped with grease fittings and are exempt from this step.
 4. Align the bolt holes. Install the new shear bolt through the auger shaft (B). Secure with the locknut (C).

23




Replacing the Impeller Shear Bolt



The snowthrower contains a rotating auger and impeller to throw snow. Fingers or feet can quickly become caught in the auger or impeller resulting in traumatic amputation or severe laceration.

- Turn the engine OFF, wait for all moving parts to stop, and remove the engine key before performing any maintenance or repairs.

24



1. Shut the engine off and remove the engine key.
2. Remove the existing shear bolt (A, Figure 24) and locknut (C) from impeller shaft (B).
3. Align the bolt holes. Install the replacement shear bolt through the impeller shaft. Secure with the locknut.

Replacing the Scraper Bar



The snowthrower contains a rotating auger and impeller to throw snow. Fingers or feet can quickly become caught in the rotating auger or impeller resulting in traumatic amputation or severe laceration.


- Turn the engine OFF, wait for all moving parts to stop, and remove the ignition key or push/pull key before performing any maintenance or repairs.

Over time the scraper bar will gradually wear and need replacement.

1. Shut off the engine and remove the key.
2. Loosen the retaining nuts (A, Figure 25) and bolts (B) and remove the scraper bar (C).
3. Align the holes in the new scraper bar with the holes on the auger housing.
4. Install the retaining nuts and bolts, and tighten them securely.

5. Check the clearance between the scraper bar and the surface.
6. Adjust the skid shoes, if necessary, to maintain ground clearance for the type of surface being cleared. See *Adjusting the Skid Shoe Height*.

25



Checking Tire Pressure



Explosion hazard

Over-inflation of tires may cause them to explode, which could result in serious injury.

Do not inflate the tires above the maximum pressure.

Tire pressure should be checked periodically. Recommended tire pressure varies by tire manufacturer. A good rule of thumb is to inflate the tire up to, but not exceeding, the "Max Inflation" stamped on the side-wall of the tire.

Storage

Storing for Off-Season

At the end of the season, or whenever the unit will be stored for 30 days or more, follow the storage checklist below.



Gasoline is highly flammable and its vapors are explosive. Fumes may travel to a distant ignition source and an explosion and/or fire may result.

- If there is fuel in the tank, do not store the unit indoors or in a poorly ventilated area where fumes could reach sparks, open flames, pilot lights, heat, and other ignition sources.

Engine:

Fuel can become stale when stored more than 30 days. Stale fuel can cause acids and gum deposits to form in the fuel system and the carburetor. To keep fuel fresh, add **Briggs & Stratton Advanced Formula Fuel Treatment and Stabilizer**.

- There is no need to drain the fuel from the engine if a stabilizer is added according to instructions. Run the engine for 2 minutes to circulate the stabilizer throughout the fuel system. If no stabilizer is added, the fuel must be drained from the engine into an approved container. Then run the engine until it stops from lack of fuel.
- While the engine is still warm, change the oil. See *Changing the Engine Oil*.

Snowthrower:

- Thoroughly clean the unit and ensure all nuts, bolts, and screws are securely fastened.
- Inspect all visible moving parts for damage, breakage, and wear. Replace if necessary.
- Lubricate the control lever linkages, chute and deflector, auger assembly, and drive wheel axles. See *Maintenance and Adjustments*.
- For any rusted or chipped paint surfaces, sand lightly and apply touch-up paint.
- For unpainted or bare metal surfaces, apply a rust preventative product.
- Store the unit indoors and cover it. If stored outdoors, cover it with a heavy tarpaulin.

Returning the unit to Service:

- Have authorized service dealer perform annual maintenance tasks. See *Maintenance Schedule*.
- Check the engine oil level and add oil, if necessary.
- Fill the fuel tank with a fresh, clean fuel.
- Check tire pressures.
- Ensure all guards, shields, and covers are in place. Ensure all fasteners are tight.
- Check the auger and impeller control, and the traction drive control.

Troubleshooting

Troubleshooting Chart

Perform the inspection or repair as indicated in the Troubleshooting Chart.

Problem	Look for	Remedy
Auger does not stop within 5 seconds after auger control lever is released.	Auger control cable out of adjustment.	See <i>Adjusting the Auger and Traction Cable</i> .
Discharge chute or deflector does not work.	Discharge chute or deflector out of adjustment or needs lubrication.	Adjust and/or lubricate control linkage.
Scraper bar does not clean hard surface.	Skid shoes and scraper bar improperly adjusted.	See <i>Adjusting the Skid Shoe Height</i> .
Unit does not propel itself.	Traction control cable out of adjustment.	See <i>Adjusting the Auger and Traction Cable</i> .
Engine does not start.	Key is in OFF position.	Turn key to ON position.
	Primer button not pressed (cold engine).	Press primer button twice and restart.
	Fuel shut-off valve (if equipped) is in CLOSED position.	Turn valve to OPEN position.
	Out of fuel.	Fill fuel tank.
	Choke turned to OPEN/RUN (cold engine).	Turn choke to CLOSED/START, set throttle to FAST.
	Engine flooded.	Move the choke to OPEN/RUN position, move throttle to FAST position, and crank until the engine starts.
Engine is hard to start or runs poorly.	Water in fuel, or old fuel.	Fill with fresh fuel.
	Fuel cap vent is blocked.	Clear vent or replace fuel cap.
Excessive vibration.	Loose parts or damaged impeller.	Stop engine immediately. Tighten all hardware. If vibration continues, have the unit serviced by an Authorized Dealer.
Snowthrower does not stop when traction control lever is released.	Traction control cable out of adjustment.	See <i>Adjusting the Auger and Traction Cable</i> .
Unit does not discharge snow.	Auger control cable out of adjustment.	See <i>Adjusting the Auger and Traction Cable</i> .
	Broken auger shear bolt.	See <i>Replacing the Auger Shear Bolt</i> .
	Broken impeller shear bolt.	See <i>Replacing the Impeller Shear Bolt</i> .
	Discharge chute clogged.	STOP THE ENGINE! Ensure that the auger and impeller have stopped rotating. Use a clean-out tool to remove snow from the discharge chute. Never clear a clogged discharge chute with your hands! See <i>Clearing a Clogged Discharge Chute</i> .
	Foreign object lodged in auger.	STOP THE ENGINE! Ensure that the auger and impeller have stopped rotating. Use a clean-out tool to remove foreign object. Never clear a lodged object with your hands! See <i>Clearing a Clogged Discharge Chute</i> .
Snowthrower does not turn when steering trigger is engaged.	Steering cable out of adjustment.	See <i>Adjusting the Steering Feature Cable</i> .

For all other issues, contact an authorized service dealer.

Specifications

Specification Chart

The spark ignition system on this snowthrower complies with Canadian standard ICES-002.

Item	Engine Model 130000	Engine Model 150000	Engine Model 19J000
Armature air gap	.010 - .014 inch (.25 - .36 mm)	.010 - .014 inch (.25 - .36 mm)	.008 - .016 inch (.2 - .4 mm)
Intake Valve Clearance	.004 - .006 inch (.10 - .15 mm)	.004 - .006 inch (.10 - .15 mm)	.005 - .007 inch (.13 - .18 mm)
Exhaust Valve Clearance	.006 - .008 inch (.15 - .20 mm)	.009 - .011 inch (.23 - .28 mm)	.005 - .007 inch (.13 - .18 mm)
Oil Capacity	18 - 20 oz (.54 - .59 L)	18 - 20 oz (.54 - .59 L)	36 - 38 oz (1.0 - 1.1 L)
Sparkplug gap	.030 inch (.76 mm)	.030 inch (.76 mm)	.030 inch (.76 mm)

Engine power will decrease 3.5% for every 1,00 feet (300 meters) above sea level and 1% for every 10 degrees F (5.6 degrees C) above 77 Degrees F (25 Degrees C). The engine will operate satisfactorily at an angle up to 15 degrees.

Power Ratings

The gross power rating for individual gasoline engine models is labeled in accordance with SAE (Society of Automotive Engineers) code J1940 Small Engine Power & Torque Rating Procedure, and is rated in accordance with SAE J1995. Torque values are derived at 2600 RPM for those engines with "rpm" called out on the label and 3060 RPM for all others; horsepower values are derived at 3600 RPM. The gross power curves can be viewed at www.BRIGGSandSTRATTON.COM. Net power values are taken with exhaust and air cleaner installed whereas gross power values are collected without these attachments. Actual gross engine power will be higher than net engine power and is affected by, among other things, ambient operating conditions and engine-to-engine variability. Given the wide array of products on which engines are placed, the gasoline engine may not develop the rated gross power when used in a given piece of power equipment. This difference is due to a variety of factors including, but not limited to, the variety of engine components (air cleaner, exhaust, charging, cooling, carburetor, fuel pump, etc.), application limitations, ambient operating conditions (temperature, humidity, altitude), and engine-to-engine variability. Due to manufacturing and capacity limitations, Briggs & Stratton may substitute an engine of higher rated power for this engine.