



28-Cup Multi-Use Rice Cooker

Olla Arrocera Multiuso de 28 tazas (6.5 l)

Cuiseur à riz polyvalent de 28 tasses (6.5 l)

Customer Care Line:

USA 1-800-231-9786

Accessories/Parts (USA)

1-800-738-0245

For online customer service

and to register your product, go to

www.prodprotect.com/applica

Service line à la clientèle :

Canada 1-800-231-9786

Accessoires/Pièces (Canada)

1-800-738-0245

Pour accéder au service à la clientèle en ligne ou pour inscrire votre produit en ligne, rendez-vous à

www.prodprotect.com/applica



Servicio para el cliente:

México 01-800 714-2503

Accesorios/Partes (EE.UU.)

1-800-738-0245

Para servicio al cliente y para registrar su garantía, visite

www.prodprotect.com/applica

MODEL/ MODELO/MODELE

○ RC5428

IMPORTANT SAFEGUARDS

When using electrical appliances basic safety precautions should always be followed including the following:

- ☐ Read all instructions.
- ☐ Do not touch hot surfaces. Use handles or knobs.
- ☐ To protect against electrical shock, do not immerse cord, plug or base unit in water or other liquid.
- ☐ Close supervision is necessary when any appliance is used by or near children.
- ☐ Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- ☐ Do not operate appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to an authorized service facility for examination, repair or adjustment.
- ☐ The use of accessory attachments not recommended by this appliance manufacturer may cause injuries.
- ☐ Do not use outdoors.
- ☐ Do not let cord hang over edge of table or counter, or touch hot surfaces.
- ☐ Do not place on or near a hot gas or electric burner, or in a heated oven.
- ☐ Extreme caution must be used when moving an appliance containing hot food, water or other hot liquids.
- ☐ To disconnect, turn any control to "off", then remove plug from wall outlet.
- ☐ Do not use appliance for other than intended use.
- ☐ To reduce the risk of electric shock, cook only in removable container.

SAVE THESE INSTRUCTIONS.

This product is for household use only.

POLARIZED PLUG (120V Models Only)


This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

ELECTRICAL CORD

- a) A short power-supply cord (or detachable power-supply cord) is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
- b) Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.
- c) If a long detachable power-supply cord or extension cord is used,
 - 1) The marked electrical rating of the detachable power-supply cord or extension cord should be at least as great as the electrical rating of the appliance,
 - 2) If the appliance is of the grounded type, the extension cord should be a grounding-type 3-wire cord, and
 - 3) The longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over.

Note: If the power supply cord is damaged, it should be replaced by qualified personnel or in Latin America by an authorized service center.

Product may vary slightly from what is illustrated.



1. Lid handle
2. Lid hanger
- † 3. Tempered glass lid with steam vent (Part # RC5428-01)
- † 4. Steamer basket divider (Part # RC5428-02)
- † 5. Steamer basket (Part # RC5428-03)
- † 6. Cooking bowl with water level marks (inside) (Part # RC5428-04)
7. Cool-touch side handles
8. Warm indicator light
9. "On" switch
10. Cook indicator light
- †11. Condensation catcher (Part # RC5428-05)
- †12. Rice measure (Part # RC5428-06)
- †13. Serving scoop (Part # RC5428-07)

Note: † indicates consumer replaceable/removable parts

How to Use

This appliance is for household use only.

GETTING STARTED

- Remove all packing material and stickers from the product.
- Remove and save literature.
- Wash and dry all removable parts as instructed in Care and Cleaning section of this manual.
- Place appliance on a flat, stable surface.

COOKING RICE:



1. Measure desired amount of rice to be cooked using rice measure provided; do not use standard 1 cup measuring cup (A). (The rice measure provided holds $\frac{2}{3}$ cup uncooked rice – about 5 oz. or 150 grams) This rice cooker can cook up to 15 measures of uncooked rice and yield a maximum of about 28 cups of cooked rice.
2. Place rice in the cooking bowl.

NOTE: Use only the cooking bowl provided with this appliance to cook rice.

3. Using the water level markings on the inside of the cooking bowl as a guide, add the amount of water that matches the number of measures of rice to be cooked. For example, if preparing 4 measures of rice, add water to 4 cup water level mark. Adding too much water may make the appliance boil over.
4. Add butter or oil and desired seasonings.

NOTE: For softer, fluffy rice add a little more water; for rice that is more firm and has a drier texture add a little less water.

5. Before placing cooking bowl into rice cooker, be sure the heating plate and outside surface of the cooking bowl are clean and dry. Avoid having rice kernels or other foods fall into the rice cooker.
6. Insert cooking bowl into rice cooker.
7. Place glass lid on the cooking bowl. For best results always keep glass lid on while cooking.

NOTE: As rice cooks, steam will escape through vent in lid. Place lid on rice cooker so vent is facing away from cabinets and walls. Do not place hands over steam vent while rice is cooking or has finished cooking; the hot steam may burn.

8. Uncoil cord and plug into standard electrical outlet. The WARM indicator light comes on.
9. Press down the ON switch. The COOK indicator light comes on and cooking begins. As the rice cooks and expands, steam comes out through the steam vent on the lid.
10. When rice is cooked, the COOK indicator light turns off and the switch pops up; the rice cooker automatically switches to the Warm function. The WARM indicator light will stay on until the appliance is unplugged.

NOTE: Do not try to stop the rice cooker from switching to the Warm mode. Do not try to press the ON switch once the Warm cycle has begun.

11. For best results, let the cooked rice rest for 15 minutes, covered, to further steam the rice. If holding cooked rice longer than 30 minutes, stir rice occasionally to prevent browning of rice on the bottom of the cook bowl.



12. Just before serving, remove lid and fluff rice. The lid hanger may be placed into the hole in the handle with the lip of the lid resting on the condensation catcher to keep water off the countertop (B).

CAUTION: When removing the lid always lift it away from the body to prevent getting burned from the hot steam.

NOTE: Use serving scoop provided with appliance to prevent damage to nonstick surface of the cooking bowl.

13. Unplug appliance when not in use.

STEAMER BASKET



1. Using standard liquid measuring cup, pour about 4 cups of cold tap water into cooking bowl. Add seasoning, if desired.
2. Place food to be cooked in the steamer basket.
3. Place basket on top of cooking bowl (C).

NOTE: Before placing cooking bowl into rice cooker, be sure the heating plate and outside surface of the cooking bowl are clean and dry. Avoid having any food fall into the rice cooker.

4. Cover with glass lid. Always keep glass lid on while steaming.

NOTE: As food cooks, steam will escape through vent in lid. Place lid on rice cooker so vent is facing away from cabinets and walls. Do not place hand over steam vent while food is cooking; the hot steam may burn.

5. Plug cord into standard electrical outlet. The WARM indicator light comes on.
6. Press down the ON switch. The COOK indicator light comes on and cooking begins.

NOTE: When steaming foods, the COOK indicator light is not intended to be an indication of cooking time. Always use a kitchen timer and do not leave these foods unattended.

7. Steaming time will vary depending upon type and amount of food to be cooked.
8. Use a kitchen timer and begin checking vegetables after about 10 minutes.
9. When cooking is completed remove food and serve. Unplug appliance.
10. The steamer basket has a removable divider that allows you to cook 2 different foods at one time.

MAKING SOUPS AND STEWS

1. Combine foods to be cooked in the cooking bowl provided with this appliance. **Do not use another bowl.** Stir with wooden spoon or rubber spatula to distribute food evenly.
2. Use only boneless meats cut in cubes no larger than 1½ inches. It is not necessary to brown meats first but this does add more flavor.
3. Do not overfill the cooking bowl.
4. For best results, select dishes that can be prepared in less than 1 hour.
5. If using frozen vegetables, they only require about 5 to 10 minutes to cook. Add them near the end of the cooking time.
6. Always use a kitchen timer when preparing foods with a sauce.

NOTE: The switch on the rice cooker is not intended to be an indicator of cooking time for soups and stews.

7. Do not hold soups and stews in the Warm cycle. Unplug the unit once the food is finished cooking.

Care and Cleaning

This product contains no user serviceable parts. Refer service to qualified service personnel.

- Unplug the unit before cleaning and let it cool completely.
- Never immerse the unit in water or other liquid.
- Wash the cooking bowl, lid, serving scoop and rice measure in hot, soapy water or in the dishwasher. Do not use abrasive cleaners or metal scouring pads-they may scratch the nonstick surface or could result in poor contact with the heating plate.

Helpful Tips: Since the rice cooking bowl has a nonstick coating, try this method: add hot, soapy water and allow the bowl to stand for several minutes. This releases any food particles and with just a wipe of a sponge or plastic scrubber the bowl is perfectly clean.

- Wipe the interior of the unit with a dry cloth. Clean the outside surface with a damp cloth and dry thoroughly.
- If water accidentally gets into the switch area or onto the heating plate, allow to dry thoroughly before using the rice cooker.