USER MANUAL

LP189

Mini 360L Lantern

USB
Rechargeable



FEATURES

- Small size
- Hanging Hook
- USB-C Rechargeable
- Dimmable
- Carabiner Included

ANSI/PLATO FL1 STANDARD			
MODES	**LUMENS**	**RUN TIME**	**BEAM DISTANCE**
FLOOD MODES			
Flood High	360 lm	4H	13 m (43 ft)
Flood Low	55 lm	10H 15M	5 m (16 ft)

OPERATION INSTRUCTIONS

On/Off: Press and release the power button to turn the lantern on and off.

Cycle Modes: (Warm/White/Natural/Red/Off): Press and release button to switch modes. Hold the button to adjust brightness.



CHARGING INSTRUCTIONS

Charging Instructions: To charge the light, locate the USB-C cover on the back of the light. Open the cover to access the charging port. Plug the USB-C end of the charging cable (included) into the port. Plug the opposite end of the charging cable into a 5V USB power source.

The battery indicator blinks blue when charging and is solid blue when fully charged. The charge time is approximately 3 hours.

PRODUCT WARRANTY

The LP189 has a Limited 1-Year Warranty Against Manufacturer's Defects from time of purchase.
For warranty claims please contact us by calling 801-553-8886 or sending an email to info@luxpro.com

14725 S Porter Rockwell Blvd Ste C
Bluffdale, UT 84065