01 Table of Contents

Safety Information ---------- 02
Warranty ---------- 03
Ceiling installation ---------- 04
Accessory drawing ---------- 05
Installation procedure ---------- 06
Remote control manual ---------- 07
Match code ---------- 08
Fans Balance ---------- 09
Care and cleaning ---------- 10
Trouble shooting ---------- 11

02 Safety Information

READ ALL SAFETY INFORMATION AND INSTALLATION INSTRUCTIONS BEFORE YOU BEGIN INSTALLING THE FAN AND SANE INSTRUCTIONS.

Warning:
Kindly turn off the power when connecting cables.



1. To reduce the risk of electric shock, ensure the electricity has been turned off at the circuit breaker or fuse box before you begin.

2. All wiring must be in accordance with the National Electrical Code ANSI/NFPA 70-1999 and local electrical codes. Electrical installation should be performed by a qualified licensed electrician.

3. The outlet box and support structure must be securely mounted and capable of reliably supporting 35 lbs. (15.9 kg). Use only UL Listed outlet boxes marked "Acceptable for Fan Support of 35 lbs. (15.9 kg) or less".

4. The fan must be mounted with a minimum of 7 ft. (2.1 m) clearance from the trailing edge of the blades to the floor.

5. Do not place objects in the path of the blades.

6. To avoid personal injury or damage to the fan and other items, use caution when working around or cleaning the fan.

7. Electrical diagrams are for reference only. Light kits that are not packed with the fan must be UI-listed and marked suitable for use with the model fan you are installing. Switches must be UL General Use Switches. Refer to the instructions packaged with the light kits and switches for proper assembly.

8. After making electrical connections, spliced conductors should be turned upward and pushed carefully up into the outlet box. The wires should be spread apart with the grounded conductor and the equipment-grounding conductor on one side of the outlet box.

9. All setscrews must be checked and re-tightened where necessary before installation

WARNING: To reduce the risk of personal injury, do not bend the blade brackets (also referred to as flanges) during assembly or after installation. Do not insert objects in the path of the blades.

WARNING: To reduce the risk of fire or electric shock, this fan is NOT suitable for use with solid-state speed controls.

WARNING: To avoid possible electrical shock, make sure that the electricity is turned off at the main power box before starting work. If you feel you do not have enough electrical wiring knowledge or experience, contact a licensed electrician.

WARNING: Electrical diagrams are for reference only. Optional use of any light kit shall be UL-listed and marked suitable for use with this fan

WARNING: To reduce the risk of fire, electrical shock or personal injury, ensure that the fan mounting bracket is supported directly from the building structure or the outlet box marked "Acceptable for Fan Support of 35 lbs. (15.9 kg) or less". Use only the screws provided with the outlet box.

03 Warranty

The supplier warrants the fan motor to be free from defects in workmanship and material present at time of shipment from the factory for a lifetime after the date of purchase by the original purchaser. The supplier also warrants that all other fan parts, excluding any glass or acrylic blades, to be free from defects in workmanship and material at the time.

of shipment from the factory for a period of two years after the date of purchase by the original purchaser. We agree to correct such defects without charge or at our option replace with a comparable or superior model if the product is returned.

To obtain warranty service, you must present a copy of the receipt as proof of purchase. All costs of removing and re-installing the product are your responsibility. Damage to any part such as by accident, misuse, improper installation, or by affixing any accessories, is not covered by this warranty.


Because of varying climatic conditions this warranty does not cover any changes in brass finish, including rusting, pitting, corroding, tarnishing, or peeling. Brass finishes of this type give their longest useful life when protected from varying weather conditions. A certain amount of “wobble” is normal and should not be considered a defect.


Servicing performed by unauthorized persons shall render the warranty invalid. There is no other express warranty. Sofucor hereby disclaims any and all warranties, including but not limited to those of merchant ability and fitness for a particular purpose to the extent permitted by law. The duration of any implied warranty which cannot be disclaimed is limited to the time period as specified in the express warranty. Some states do not allow a limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

The retailer shall not be liable for incidental, consequential, or special damages arising out of or in connection with product use or performance except as may otherwise be accorded by law. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion or limitation may not apply to you. This warranty gives specific legal rights, and you may also have other rights which vary from state to state. This warranty supersedes all prior warranties. Shipping costs for any return of product as part of a claim on the warranty must be paid by the customer.


04 Three ceiling installation methods


Concrete Ceiling Mounting Bracket







Hanger for Junction Box Mounting Bracket






Wooden ceiling Mounting Bracket





05 Accessory drawing









06 Installation procedure


1. Fit the gasket over the screw.




2. Put the blade arm onto one blade and align the holes.



3. Insert the blade screws into the holes and tighten each blade screw.



4. Remove blade screws on the motor.



5. Align the holes on the blade arm with the holes on the motor, and tighten the screws.




6. Repeat install the remaining blades, and tighten all the blade screws.




06 Installation procedure


7. Loosen and remove the 3 silver screws pre-locked on the motor
(Do not remove them all)




8. Put on the lamp panel and feed the wire plugs through the center hole.



9. Tighten the 3 silver lamp panel screws.




10. Loosen and remove the 3 brass light kit screws pre-locked on the lamp panel (They will be needed later).



11. Connect the light source with the wires from the motor.



12. Align the screw holes and tighten the 3 brass light kit screws.




06 Installation procedure


13. Turn the fan over.




14 Remove the 2 screws from the top of the fan motor.




15. Remove 2 screws on the hanger ball.




16. Remove the lock pin and the bolt of the base of the downrod.



17. Select one downrod and pass all motor wires/light cables through it.



18.Insert the bolt.
Fix the bolt with the lock pin.



06 Installation procedure

19. Tighten the 2 screws to prevent fan shaking during operation.



20. Put the decorative cover through the downrod.



21. Put the canopy cover through the downrod.




22. Put the canopy through the downrod.



23. Put the hanger ball through the downrod.




24. Insert the bolt.




06 Installation procedure


25. Use screws to align the screw holes and tighten the screws.




26. Connect the wire from the ceiling fan to the receiver(Red,White and Black wires).



27. Connect the wire from the ceiling fan to the receiver
(Red,Yellow and White wires).




28. All wires are connected.




29. Install the ceiling bracket with four self tapping screws.




30. Place the downrod ball into the slot in the ceiling bracket. If the slot doesn't align properly then rotate the ball.



31. Put the receiver into the mounting bracket.



32. Use wire connecting nuts to connect the three ground wires(Green)coming from the downrod, receiver and hanging bracket.



33. Connect the fan live wire (black) to your house live wire; Connect the fan neutral wire (white) to your house neutral wire.




34. Lift the cannopy into place so that the screw holes are aligned.



35. Wrap keyhole slots around the screws, twist clockwise and tighten 2 screws.



36. Lift the canopy cover to the canopy, then turn and tighten.




06 Installation procedure

37. Install the lampshade and rotate it to lock.




WARNING: Turn off the electric power during installation and making wire connection.

1. Connect the wire which from ceiling fan into the receiver
2. Connect the wire from receiver with the wire from house.



07 Use of remote control

USER MANUAL FOR REMOTE CONTROL TRANSMITTER



(1) Turn OFF the Fan and Light
Trun OFF the Fan and Light together.

(2) Fan speed
Press the key 1-6 to start the fan.

(3) Timing control of the Fan and Light
- Press the key to set up the timer at 1hour ,4 hours or 8 hours to set up fan and lamp timer. At the end of the timing, the fan and lamp will be automatically turned off.
- When the timing function is in effect, you can operate all the functions of the ceiling fan, and then press any timing button to recalculate the timing time.
- Timer setting cancellation : When timing function is working, press key(1) to cancel the timing function.

(4) Anti-theft mode
Press the key to turn on or turn off Anit-theft mode:
Every three hours, the light will automatically turn on and go out after 30 minutes. Press the key again to cancel.

(5) Color temperature Switch of the light
Press the key to change LED light color : white-yellow-warm (circulate).

(6) Light dimming
When the light is on, press and hold the key, the light gradually brightened - gradually dimmed(circulate).

(7) Direction of the fan
Press the key to change direction of the fan.

(8) Natural wind
Press the key, the fan speed automatic change between 1 to 6 speed.

(9) Fan OFF / Remote control pairing
- Turn OFF the fan.
- **Remote control pairing** : when AC power on, press and hold the key for 3-5 seconds, then ☒inish the remote control pairing.

Notice：
The remote controller only needs to be paired once. After the paired product, the controller will have memory. The products have been paired before leaving the factory. When the remote control is damaged or lost, it is necessary to implement remote control pairing before using a new remote control.

(10) Turn ON/OFF the Light

(11) Fan speed and Timing time indicator
The indicator light will light up when press any key of the remote control


(12) AAA battery * 2
- Please install 2 pieces of AAA batteries before use.
- Please remove the battery when it is not used for a long time.

Note: the remote control must match the same code receiver

When the reversible button is pressed, the fan slowly slows down to a stop and then begins to reverse.

08 Match code

if it does not work




1.Turn on the main switch.




2.Pressing and holding this key for 5 seconds.


09 Adjusting and balancing your ceiling fan blades



Put the clip in the center of a blade.
turn on the fan and if the shake persists, put the clip in another blade until the shake is reduced. Then this blade will need the counterweight.



Place the clip on the blade that needs the counterweight and try the best place to place it, from the center to the tip of the blade, until the wobble disappears.



Paste the counterweight on the surface of the blade which near the clip, remove the clip and test the fan. If it keep staggering, put another counterweight. if it gets worse, try another better area to place it.
please try it patiently till the fan is balance.