

**INSTRUCTIONS**

**TOOLS REQUIRED:** Screwdriver,  
Adjustable wrench

1. Turn off water supply.
2. Remove handle screw (A) and pull off handle (B).
3. Unscrew bonnet (C) and pull out stem (D).
4. Insert new seat (E) into faucet body.
5. Insert new stem into faucet body.
6. Replace bonnet (C) and tighten.
7. Place handle (B) on stem and tighten with screw (A).
8. Turn on water supply.  
Check for leaks.

**INSTRUCCIONES**

**HERRAMIENTAS NECESARIAS:**  
Destornillador, Llave ajustable

1. Cierre el suministro de agua.
2. Quite el tornillo de la llave (A) y quite la llave (B).
3. Desatorille el bonete (C) y quite el vástago (D).
4. Inserte la nueva base (E) en el cuerpo del grifo.
5. Inserte el nuevo vástago en el cuerpo del grifo.
6. Vuelva a colocar el bonete (C) y apriete.
7. Coloque la llave (B) sobre el vástago y apriete con el tornillo (A).
8. Conecte el suministro de agua.  
Revisar si hay fugas.

