LP184

Pop-up 200L Lantern

3 AAA Batteries



FEATURES

Hanging Hook

Magnetic

ANSI/PLATO FL1 STANDARD

MODES	LUMENS	RUN TIME	BEAM DISTANCE
FLOOD MODES			
Flood High	214 lm	2H	14

OPERATION INSTRUCTIONS

On/Off: Press and release top of the lantern



BATTERY REPLACEMENT

Battery Replacement:

Open the battery compartment by unscrewing the bottom of the lantern. Remove the old batteries and install the new batteries, matching the + and – polarity markings inside the compartment. Once the batteries are installed, securely close the bottom of the lantern.

Do not mix old and new batteries, use brand new batteries of the same voltage and brand. If the light will not be used for an extended period, remove the batteries to help prevent leakage and corrosion.



PRODUCT WARRANTY

The LP184 has a Limited 1-Year Warranty Against Manufacturer's Defects from time of purchase.
For warranty claims please contact us by calling 801-553-8886 or sending an email to info@luxpro.com

14725 S Porter Rockwell Blvd Ste C
Bluffdale, UT 84065