USER MANUAL

XP713

Pro Power 11K DS

USB
Rechargeable



FEATURES

- OLED Display
- Lockout
- Dual-power (9AAA holder included)
- Smooth Focus
- TACKGRIP®
- Power Bank

ANSI/PLATO FL1 STANDARD			
MODES	**LUMENS**	**RUN TIME**	**BEAM DISTANCE**
Turbo	11600 lm	45s	241
High	4378 lm	2H 30M	140
Medium	1992 lm	5H 45M	96
Low	61 lm	55H	16

OPERATION INSTRUCTIONS

DEMO Mode: Initial charging required to permanently unlock flashlight from demo mode.
TO UNLOCK FROM LOCKOUT: Double press button

On/Off: Press and release button. Cycle through modes to Off, or press button when it not illuminated to go directly to Off.

CYCLE MODES: While illuminated, press button to change modes



CHARGING INSTRUCTIONS

Charging Instructions: To charge the flashlight, locate the USB-C port cover on the back of the light. Open the cover and insert the USB-C end of the charging cable into the port. Connect the other end of the cable to a 5V USB power source.

Battery Indicator: A blue light means the battery is above 30% charged. A red light indicates low power—charging is recommended.

The XP713 has a charge time of approximately 3 hours.

Using AAA Batteries: To switch power sources, unscrew the tail cap, remove the rechargeable battery, and insert 9 AAA batteries into the included battery holder. Place the holder into the flashlight with the arrow pointing downward, then securely screw the tail cap back on.

PRODUCT WARRANTY

The XP713 has a Limited Lifetime Warranty Against Manufacturer's Defects from time of purchase.
For warranty claims please contact us by calling 801-553-8886 or sending an email to info@luxpro.com

14725 S Porter Rockwell Blvd Ste C
Bluffdale, UT 84065