IMPORTANTINSTRUCTIONS AND OPERATING MANUAL

ELECTRIC FIREPLACE

JBK36E-DBL-SSDQ/JBK42E-DBL-SSDQ
JBK50E-DBL-SSDQ/JBK60E-DBL-SSDQ
JBK68E-DBL-SSDQ/JBK72E-DBL-SSDQ

NO VENTING REQUIRED

WARNING Read and understand this entire owner's manual, including all safety information before plugging in or using this appliance. Failure to do so could result in fire, electric shock or serious personal injury.

wolfhontech@gmail.com

Please choose SMS or email as your first choice for communicating with us.

CERTIFIED UNDER CANADIAN AND AMERICAN NATIONAL STANDARDS. ETL

Intertek 5024127

TABLE OF CONTENTS

IMPORTANT SAFETY INSTRUCTIONS 4
1.0 PACKING LIST 9
1.1 DIMENSIONS 9
2.0 ELECTRICAL INSTALLATION NOTES 10
2.1 GENERAL INSTRUCTIONS 10
3.0 INSTALLATION INSTRUCTIONS 11
3.1 UNPACKING AND TESTING APPLIANCE WALL 11
3.2 GROUNDING APPLIANCE 12
3.3 ASSEMBLY 12
Wall Hanging 13
Built-in construction 17
4.0 FINISHING 20
5.0 OPERATING INSTRUCTIONS 20
5.1 MAIN POWER BUTTON 20
5.2 CONTROL PANEL/REMOTE CONTROL OPERATION 20
5.3 HEATER CONTROL 21
6.0 TROUBLE SHOOTING GUIDE 23
7.0 MAINTENANCE 25
7.1 PARTIALLY REFLECTIVE GLASS CLEANING 25
7.2 SCHEMATIC DIAGRAM 26
8.0 LIMITED WARRANTY 26
9.0 Q&A AND CONTACT INFORMATION 27

IMPORTANT SAFETY INSTRUCTION

WARNING

These instructions should be carefully read before installation. The booklet must be kept and delivered to the new user. The Manufacturer reserves the right to vary the features of the product without prior notice. The technical data are indicative only.

1. THIS APPLIANCE IS NOT WHEN OPERATED AND CAN CAUSE SEVERE BURNS IF TOUCHED.
2. Do not operate appliance before reading and understanding instructions. Failure to operate appliance could cause fire or injury.
3. Keep this appliance away form combustible materials at least 3 feet (0.9 m), such as furniture, bedding, papers, clothes and curtains at least 3 feet (0.9 m). WARNING. In order to avoid overheating, do not cover the heater. The openings must be inadequate when installed it in a Recreational Vehicle.
4. Risk of burns. Please do not touch the appliance directly after use and cooling it for a while. Please turn off the control when you plug if you want disconnect power supply from power of appliance.
5. Do not install damaged or incomplete components.
6. Do not use this appliance outdoors and please store they are in the same room with the appliance. They may be susceptible to accidental contact burns.
7. Do not install damaged, incomplete or substitute components.
8. To prevent accidents, unbleeding, small kits should be kept away from children and infants.
9. There is small batteries in the remote. Please keep away from children.
10. Do not install battery in the wrong direction, as it close to fire or mix with other type of batteries.
11. Ensure you have adequate safety measures to protect infants/toddlers from touching hot surfaces.
12. It is imperative that the control compartments, circulating blower and ventilation channel in the appliance are kept clean. The appliance should be inspected before use and examined by a qualified service person at least a year.
13. Any electrical service should this appliance be modified.
14. Do not use this appliance if any part has been in contact with water. Please call a qualified service technician to inspect the appliance immediately and to replace any parts which has been in contact with water.
15. Do not operate the appliance when the glass door was removed, cracked or broken. Replacement of the glass service should be done by a qualified service person.
16. Do not strike the glass door of appliance.
17. Keep the packaging material away from children and dispose of the materials in a safe manner.

18. Always unplug appliance when not in use.
19. Do not operate this appliance with a damaged cord or plug after the appliance malfunctions, please return appliance to authorized service facility for electrical or mechanical adjustment, or repair.
20. Do not use appliance outdoors.
21. Never place appliance where it may fall into a bathtub or other water container.
22. Do not run cord under carpet. Do not cover cord with throw rugs, runners etc. Place cord away from cluttered area and where it will not be tripped over.
23. Connect to properly grounded outlet only.
24. Do not use appliance in any area where any ventilation or exhaust valve as this may cause an electric shock or fire, or damage the appliance.
25. To prevent fire cases, do not block the air intake or exhaust valve in any way. Do not use appliance on soft surfaces, such as carpet, where exhaust valve may become blocked.
26. Always plug appliances directly into a wall outlet/receptacle. Do not use extension cord or relocatable power tap (outlet/power strip).

1.0 PACKING LIST

NO.	Description	Quantity
1	Front frame	1 pc
2	Electric Fireplace	1 pc
3	Back hook(Pre-attached)	36E-42E: 5ZW (Spec) 50E-72E: 7pcs
4	Manual	1 pc
5	Decorative Stuff	Varies
6	Remote Control	1 pc
7	Bumper bracket	36E-42E: 5ZW (Spec) 50E-68E, 72E: 7pcs

Style A

HARDWARE INCLUDED

A B C

Part	Description	Model	Number
A	ST5*30mm	36E,42E,50E	6pcs
		60E,68E,72E	8pcs
B	M8*35mm Plastic expansion tube	36E,42E,50E	6pcs
		60E,68E,72E	8pcs
C	ST4*12mm Glass fixing screws	36E,42E,50E 60E,68E,72E	2pcs
	The hook has a safety bracket mounting screw	36E,42E,50E	10pcs
		60E,68E,72E	10pcs

1.1 DIMENSIONS



Model	Amm	Bmm	Cmm	Dmm	Emm	Ain	Bin	Cin	Din	Ein
JBK36E	914	460	836	113	440	36	18.11	32.91	4.45	17.32
JBK42E	1067	460	988	113	440	42	18.11	38.9	4.45	17.32
JBK50E	1270	460	1191	113	440	50	18.11	46.89	4.45	17.32
JBK60E	1524	460	1445	113	440	60	18.11	56.89	4.45	17.32
JBK68E	1728	460	1648	113	440	68	18.11	64.88	4.45	17.32
JBK72E	1828	460	1750	113	440	72	18.11	68.9	4.45	17.32



Model	A(mm)	B(mm)	C(mm)	A (in)	B (in)	C (in)
JBK36E	846-856	115-125	445-455	33.1-33.7	4.53-4.92	17.52-17.72
JBK42E	996-1008	115-125	445-455	39.29-39.69	4.53-4.92	17.52-17.72
JBK50E	1201-1211	115-125	445-455	47.28-47.68	4.53-4.92	17.52-17.72
JBK60E	1455-1465	115-125	445-455	57.28-57.68	4.53-4.92	17.52-17.72
JBK68E	1658-1668	115-125	445-455	65.28-65.67	4.53-4.92	17.52-17.72
JBK72E	1760-1770	115-125	445-455	69.29-69.69	4.53-4.92	17.52-17.72

NOTE:
- **The size of column B left same space for the main power switch on the top, you can also choose 3.54 inch for full embedding, since the front screen also has a main power switch.**
- **Please leave enough space to pass the power cord on the right side of the fireplace.**

LISTING APPROVALS

This appliance has qualified with the ETL Standards for fixed and location-dedicated electric room appliances in the United States and Canada.If you need assistance during installation, please contact your local dealer.

NOTE: This appliance must be electrically wired and grounded in accordance with local codes or, in the absence of local codes, the Electric Code ANSI/NFPA 70 latest edition in the United States or the Canadian Electric Code, ETL in Canada.

Models No.	
Description	Wall-mount, recessed, or free standing fireplace
Voltage	120V
Rating	Max 1500W
Amps	12.50AP
BTUS	5100BTU

2.0 ELECTRICAL INSTALLATION NOTES

2.1 GENERAL INSTRUCTIONS

CAUTION - Some parts of this product can become hot and it easy to cause burns. Pay attention to keep away from them.

A. Please confirm that house circuit breakers for the outlet are on, before plugging your appliance into an electrical outlet.

B. This appliance may emit a slight harmless odor when first used. It is caused by the initial heating of internal appliance elements and will not occur again.

C. If your appliance does not emit heat, check the operation section of this manual for further information. Else with an ETL or UL certified presence.

RISK OF FIRE THE POWER CORD MUST NOT BE PINCHED AGAINST A SHARP EDGE.. DO NOT PLUG INTO AN EXTENSION CORD. DO NOT PLUG INTO A SURGE PROTECTOR. ELECTRIC SHOCK, AND PERSONAL INJURY. DO NOT RUN CORD UNDER CARPETING. DO NOT COVER THE CORD WITH THROW RUGS ETC.

ARRANGE THE CORD AWAY FROM CLUTTERED AREAS AND WHERE IT WILL NOT BE TRIPPED OVER. RISK OF FIRE TO PREVENT A POSSIBLE FIRE, DO NOT BLOCK AIR INTAKE OR EXHAUST VALVE IN ANY MANNER. DO NOT USE ON SOFT SURFACES, SUCH AS A BED, WHERE OPENINGS MAY BECOME BLOCKED. RISK OF FIRE! DO NOT BLOW OR PLACE INSULATION AGAINST THE APPLIANCE.

THIS ELECTRIC APPLIANCE IS TESTED AND LISTED FOR USE ONLY WITH THE APPROVED OPTIONS/ACCESSORIES. USE OTHER ACCESSORIES THAT NOT TESTED FOR THIS ELECTRIC APPLIANCE COULD DISABLE THE WARRANTY AND THE FIRE HAZARD RESULT.

A FIRE RESULT MAY CAUSING PROPERTY DAMAGE, PERSONAL INJURY, OR DEATH OF THE CUSTOMER DO NOT FELLOW THE INSTRUCTION EXACTLY, DO NOT STORE OR USE GASOLINE OR OTHER FLAMMABLE VAPORS AND LIQUIDS IN THE VICINITY OF THIS OR ANY OTHER APPLIANCE.
THIS APPLIANCE IS MADE TO BE USED FREE TWO PEOPLE FOR INSTALLING.
IN ANY WAY, HEATER VENTS ON THE ELECTRIC APPLIANCE CAN NOT BE COVERED.AS IT MAY LEADE A FIRE HAZARD.
THE FIRE HAZARD RESULT.

Follow all national and local electrical codes.

1. The heater should be installed only using the mounting brackets we provided.
2. Do not use the heater if any part has been under water. There must be enough space around the top of the heater to ensure adequate ventilation.
3. The heater should be placed at least 48 inch away from surrounding walls.
4. At least 30 cm should always be left in front of the heaters to ensure safety.
5. The heater can not be located either directly below, or in front of a socket outlet.
6. Do not use the heater where condensation may prevent any control switches from being able to be touched by anyone who is in the shower or bath.
7. Make sure that there is no possibility of inflammable material, combustible material, or curtains coming into contact with the heater.
8. DO NOT USE THE HEATER WITHOUT SUPERVISION.

3.0 INSTALLATION INSTRUCTIONS

3.1 UNPACKING AND TESTING APPLIANCE WALL

Carefully remove the appliance from the box. Before installing the appliance, make sure the appliance operates properly by plugging the power supply cord into a conveniently located 120 Volt grounded outlet.

3.2 GROUNDING APPLIANCE

This appliance is for use on 120 Volts. The cord has a plug as shown in GI.An adapter as shown in C is available for connecting three-blade grounding type plugs to two-slot receptacles. The green grounding lug extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box. The adapter should not be used if a three-slot grounded receptacle is available.
To disconnect the appliance, turn the controls off, then remove the plug from the outlet.

3.3 ASSEMBLY

The fireplace can be installed with 2 options:

1. Wall Hanging....page 13-16
2. Built-in construction (in wall recessed).

Follow the installation instructions below based on installation preference.



Installation Option 1-Wall Hanging

The fireplace can be installed with 2 options:
-Remove the fixed screw on the side plate.
-Lift the glass frame 1-2 cm vertically. Then the entire glass frame can be removed from the front .Take the glass frame 10-20 cm away from the appliance, put the glass panel down on the ground before complete separation.



MAXIMUM DISTANCE: 50cm

JBK36E-DBL-SSDQ JBK42E-DBL-SSDQ JBK50E-DBL-SSDQ JBK60E-DBL-SSDQ JBK68E-DBL-SSDQ JBK72E-DBL-SSDQ

As many different finishing materials are used on the walls, it is highly recommended that you consult a local builder before installing this fireplace on the walls. Choose an area that is not susceptible to moisture and is at least 3¼ inches away from curtains, furniture,bedding or other combustible materials. Make sure the wall is strong enough to support the weight of the fireplace, the back to be hung, and the glass frame.Install screws and wall anchors (not supplied) appropriate for the wall material. Make sure the screws are installed in the position of the support must be according tothe diagram, otherwise it can not be hung on the wall.

Step 3. Choosing a Wall Location

- Find a safe location, where minimum clearance from the front of the fireplace is 914 mm (36 inch) and 1524 mm (60 inch) minimum clearance from the front must be at least 3 feet (900 mm). Choose a location near an outlet so an extension cord is not required.

Note: DO NOT position the unit directly below a power outlet. Please check Safety information on page 3 and 4 for more warnings about placement, installation, and use of this product.

Step 4. Drilling the Holes and Installing the Mounting Bracket

Mark the position of the fixed hole on the wall according to the size requirements of the position below, and then use the hole puncher to punch the hole matching with the projection pipe of the accessories of the machine according to the mark position Insert the plastic expansion tube into the drilled hole. The expansion tube should be flush with the wall. Fix the mounting bracket on the wall with screws and tighten the screws. Note: Do not tighten the screws too much to avoid damage to the expansion tube, but the tightened expansion tube cannot be pulled out of the wall with about 10 Newton. Otherwise, the fixed hole and the expansion pipe are not qualified, and can not be hung on the fireplace.

Step 5. Hanging the Fireplace on the Bracket

- Thread the ST4*12 screw into the threaded holes on the glass panel. Check the alignment of the glass panel and securely tighten the screws.

After installing the fireplace, have two people lift the fireplace up and see if the hanging bracket on the back board is aligned with the wall.
Then, hang the fireplace on the bracket with a slight pushing force to slowly introduce the fireplace into the fixing slot of the hanging plate, and then use ST5*20 wood screws to put the safety bracket.
Fixed on the wall has been installed plastic expansion tube see the picture below)

Step 6. Placing the Decorations

- Carefully place crystal together with the appliance) or other decoration into the bottom tray on the front of the appliance as illustrated.

NOTE: Media bed kits may have sharp edges, wear safety goggles and gloves when handling.

Step 7.

- Connect the data cable connector before hanging the glass frame on the appliance. Gently push on the glass panel by aligning the 4 hooks until it snaps into position (sinks down 1-2 cm).



Step 8.Refasten the Glass Frame

- Thread the ST4*12 screw into the threaded holes on the glass panel. Check the alignment of the glass panel and securely tighten the screws.

Installation -Built in Construction

Step 1. Removing the Glass Frame

Step 2. Removing the Mounting Bracket

- (Step 1 and Step 2 please refer to page 13-14 same as Wall Hanging installation.)

Step 3. Setting the Holes of Screw



- The appropriate cavity (1-2 cm bigger for each side) needs to be prepared according to the size of the appliance.
- Put the fireplace in place, mark the holes which need to be drilled with a pencil. Then take it out of the cavity again.

Step 4. Drilling & Installing the Wall Anchors

- Drill the holes T/25 in. (T=wall on the prepared marks.
- Insert the wall anchors (Part B) into the holes by using a hammer.

Step 5. Placing the Pads and Fixing the Fireplace

-Screws (Part A) pass through the holes from the front of fireplace with screwdriver. **(Note: install carefully and don't let the screws fall into the fireplace.)**
- Put the fireplace into the prepared cavity.
-Fasten the fireplace firmly into the wall by the screws for each side.

Step 6. Placing the Decorations

-Carefully place crystal together with the appliance) or other decoration into the bottom tray on the front of the appliance as illustrated.

NOTE: Media bed kits may have sharp edges, wear safety goggles and gloves when handling.

Step 7. Hanging the Glass Frame

- Connect the data cable connector before hanging the glass frame on the appliance. Gently push on the glass panel by aligning the 4 hooks until it snaps into position (sinks down 1-2 cm).

WARNING: It's better to reserve a space between frame and wall to enable better air circulation during working if available.

Step 8.Refasten the Glass Frame

- Thread the ST4*12 screw into the threaded holes on the glass panel. Check the alignment of the glass panel and securely tighten the screws.

4.0 FINISHING

WARNING

GRILLE MAY BE HOT, DO NOT TOUCH AN OUTLET UNTIL COOLED
THE DOOR HOOKS ARE PART OF A SAFETY SYSTEM AND MUST BE PROPERLY ENGAGED, SO NOT OPERATE THE APPLIANCE WITH HOOKS DISENGAGED.
FACING FINISHING MATERIALS MUST NOT INTERFERE WITH AIR FLOW THROUGH AIR OPENINGS, AND MUST NOT BLOCK ACCESS FOR SERVICE, DESIRE ALL CLEARANCES WHEN APPLYING COMBUSTIBLE MATERIAL.
BEFORE DOOR IS REMOVED. TURN THE APPLIANCE OFF AND WAIT UNTIL APPLIANCE IS COOL DOORS ARE HEAVY AND FRAGILE, SO HANDLE WITH CARE.

NOTE: Glass front must be removed and the appliance must be finished in its final location before the media bed kits are installed, Media bed kits may have sharp edges, wear safety glasses and gloves when handling.

5.0 OPERATING INSTRUCTION

Once the appliance has been plugged into a grounded electrical outlet, it is ready to operate.

5.1 MAIN POWER BUTTON

The main power switch for the fireplace is on the front right.



5.2 CONTROL PANEL/REMOTE CONTROL OPERATION

(Main Power Switch must be turned ON before using remote control.)
- The keypad is on the upper right.
- **Please open the back cover of the remote control and put in the battery before use.**

Heater Flame Speed Dimmer Flame Red Color Flame Color Timer Power On/Off

POWER	Plug in the power plug to have a long buzzer, the electric fireplace in standby mode, even time you operate, the remote control will not work. **Note:** Click the POWER button on the remote control keypad or on the keypad in the off state, the electric fireplace will start to work in the default state. The flame will start to burn, the heater will not turn on, and the flame light and the colors the light will light up. The heater only starts at the third time you press the button, and the heater will start to work in the default state. The heater will automatically shut down after 1 hour. Restart or keypad will restart by hand.
HEATER	Click the heater button to start the heater, and the electric fireplace will start to work in the default heating mode and will work. To turn on the heating function of the electric fireplace, press the heating setting key on the remote control or the keypad on the panel. The heater will start to work in the default state. The electric fireplace in the previous power mode, then press the heating setting key, the digital tube displays the, the heating function of the electric fireplace is turned off, the heating indicator light on the display board goes out, at this time, the electric fireplace will continue to work in the previous power mode, and then press the heating switch key, then the heating mode is in HI > LO first mode cycle switching, every time you press the heating switch key.
TIMER	Electric fireplace has a timer shutdown setting function, the timing range can be set between 0.5 hours, when the timer is set, the timer indicator will be on the display board, and the timer will start to work, and the timer will shut down automatically, the electric fireplace is open to work, click on the remote control on the "TIMER" button, the digital tube displays the default time of 0.5 hours, and then press the button to change the time.
FLAME SPEED	Click the flame speed button on the remote control keypad or on the keypad on the panel, the flame will change in three speeds, and the flame will change in the order of 1>2>3>1 when the electric fireplace heater function is turned off, the heating indicator light on the display board goes out, at this time, the electric fireplace will continue to work in the previous power mode, and then press the heating switch key, then the heating mode is in HI > LO first mode cycle switching, every time you press the heating switch key.

DIMMER	Adjust brightness of flame and heat level Click the dimmer button on the remote control keypad or on the keypad on the panel, the flame will change in three speeds, and the flame will change in the order of 1>2>3>1 when the electric fireplace heater function is turned off, the heating indicator light on the display board goes out, at this time, the electric fireplace will continue to work in the previous power mode, and then press the heating switch key, then the heating mode is in HI > LO first mode cycle switching, every time you press the heating switch key.
FLAME COLOR	Click the flame color change button on the remote control keypad or on the keypad on the panel, the flame color will change in the order of 1>2>3>4>5>6>7>8>9>10>11>12>1 when the electric fireplace heater function is turned off, the heating indicator light on the display board goes out, at this time, the electric fireplace will continue to work in the previous power mode, and then press the heating switch key, then the heating mode is in HI > LO first mode cycle switching, every time you press the heating switch key.
FLAME RED COLOR	Click the flame red color button on the remote control keypad or on the keypad on the panel, the flame red color will change in the order of 1>2>3>4>5>6>7>8>9>1 when the electric fireplace heater function is turned off, the heating indicator light on the display board goes out, at this time, the electric fireplace will continue to work in the previous power mode, and then press the heating switch key, then the heating mode is in HI > LO first mode cycle switching, every time you press the heating switch key.
ON/OFF	Click on the button, the electric fireplace will light up in the default state of the previous use, and the flame will start to burn, the heater will not turn on, and the flame light and the colors the light will light up. The heater only starts at the third time you press the button, and the heater will start to work in the default state. The heater will automatically shut down after 1 hour. Restart or keypad will restart by hand.

After 10 seconds without operating the keys, all the displays on the display will go out and the electric fireplace will work normally. If you click on the display during this time, the display will light up for 10 seconds and the function is turned to standby again. Note: Wake-up function operation press any key when the first time just wake up the display without executing the function of the key.
With power failure memory and shutdown memory function. When power is lost, firewood color and flame, frosted color and flame, heating brightness, and the rest of the functions are restored to the default state.

NOTE: The heater will not work if the tip-over switch is tripped when the appliance is plugged in and operating. This will cause the remote control and touch panel to no longer function.

NOTICE: When the heater is first turned on, a slight odor may be present. This is normal and should not occur again unless the heater has been unused for a long time.

NOTICE: To improve operation, set the remote control at the front of the fireplace. DO NOT press the buttons too quickly. Use the unit time to respond to each command.

5.3 REMOTE CONTROLLR

Note:
1.Please open the back cover of the remote control and put in the battery before use
2.Due to the express delivery requirements, this product does not come with any batteries, You need to buy two AAA batteries yourself
Thanks for your kind understanding!

Battery must be recycled or disposed of properly. Check with your Local authorities for recycling advice in your area.

6.0 TROUBLE SHOOTING GUIDE

PROBLEM	SOLUTION
The mounting bracket cannot be removed	1. The mounting bracket is pre-attached. Unscrew the two screws at both sides of the bracket to the fireplace, and then remove the bracket. Then use attached mounting screw. 2. If the problem is still not solved, please contact us via **Amazon Message** or message
The control panel function does not work	1. Make sure the Power Switch on the control panel is turned on before operation. 2. Make sure you have reconnected the data cable which was pull out when you removed the glass frame. 3. If the problem is still not solved, please contact us via **Amazon Message.**
Sudden power outage during use of the fireplace	1. Don't over the air outlet. 2. Please restart after 10-15 minutes and try to open it again. 3 If the problem is still not solved, please contact us via **Amazon Message.**
The appliance does not heat and there is an error code on the display	This is normal. The fans time run set while the appliance gradually heat up. The fans time slow after the appliance turn off to cool the appliance and prevent overheating.
The appliance does not heat and there is an error code on the display	1. Main Power switch is turned off. Turn the main power switch to "ON" position 2. Thermal cut-out protection switch is activated. Switch to "ON" position 3. Heater is unplugged from wall outlet. Make sure the power cord is plugged into a function wall outlet and gently pressed it deep into the receptacle. 4. Power cord or power plug are damaged. Contact a qualified electrician to replace power cord 5. Power outlet for power plug wiring is loose. Check the power outlet and replace with a new one. 6.Loose wiring. Check all wiring for loose connections. Contact a qualified electrician.
Heater is on, but no heat is coming out.	1. Heater switches in on, but heater is not on.	Check all wiring for loose connections. Contact a qualified electrician.

Flame is dim	1. Flame Adjusting knob is at low position 2. Loose wiring 3. Flame element is not attached to the motor.	Turn the knob to maximum setting Check all wiring for loose connections. Contact a qualified electrician Contact us via **Amazon Message**
Flame are frozen	1. Flame element is not attached to the motor.	Contact us via **Amazon Message**
	2. Resistor motor is defective.	Contact us via **Amazon Message**
Excessive noise in the lower portion of the heater	1. Flame element isn't seated properly	Contact us via **Amazon Message**
	2. Motor is defective.	Contact us via **Amazon Message**
Heater system doesn't turn on.	1. Heater power switch is off.	Turn the heater power switch to the "ON" position
	2. Heater system is overheated	Maybe the heater is covered or air inlet or air outlet is blocked completely. Remove the blockage, wait for 30 minutes, turn off the power switch and unplug it. Wait 20 minutes, and then turn the heater on again.
	3. Loose wiring.	Check all wiring for loose connections. Contact a qualified electrician.
Heater system doesn't turn on.	4. The air inlet or air outlet is blocked completely.	Loose adequate space around the unit. Remove the blockage, on or in front of the air outlet.
	5. The heater system is overheated.	Check the air inlet and outlet. Turn off the power switch for 30 minutes, Reset 20 minutes, and then turn the heater on again.
"HEAT" switch has been pressed, but there is no airflow.	1. Fan motor is defective.	Contact us via **Amazon Message**
	2. Fan blower is balanced badly.	Contact us via **Amazon Message**
	3. Fan blower is defective.	Contact us via **Amazon Message**
Fan runs but no heat is coming out.	1. Fan "POWER" and fan "HEAT" switches are not turned on.	Turn these two switches on
	2. Loose wiring.	Check all wiring for loose connections. Contact a qualified electrician.
	3. Bad heating element.	Contact us via **Amazon Message**
	4. Built-up of dirt on the fans.	Clean all fans.
	5. Heater fan is defective.	Contact us via **Amazon Message**

The remote control does not work.	1. The battery is not properly installed.	Make sure the battery is properly installed. Rinse the battery is transposed incorporating power away before installed.
	2. Not pointing to the right position.	Aim the remote control at the receiver.
	3. Flash an obstacle in front of the receiver.	Remove objects that may be in the way. Items between the remote control and the remote control receiver will keep the signal.
	4. Press the remote control buttons too quickly.	Don't press the remote control buttons too quickly. Press each control button separately.
There is an odor coming from the heater.	The heater may emit a slight harmless odor when first used. This is a normal condition caused by initial heating of the internal parts and will not occur again.	

NOTE: For the most of functional problems, you can unplug the plug, wait for 10 minutes and plug it again, the machine will reset to the initial status(factory original). If the problem is still not solved, feel free to contact us via Amazon Mes-sage.

7.0 MAINTENANCE

DISCONNECT POWER AND ALLOW HEATER TO COOL BEFORE ATTEMPTING ANY MAINTENANCE OR CLEANING TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR DAMAGE TO PERSON.
THE FIREPLACE SHOULD NOT BE OPERATED WITH AN ACCUMULATION OF DUST OR LINT ON OR IN THE UNIT, AS THIS COULD CAUSE A BUILD UP OF HEAT AND SUBSEQUENT EVENTUAL DAMAGE. FOR THIS REASON THE HEATER MUST BE INSPECTEDREGULARLY, DEPENDING ON CONDITIONS AND AT LEAST AT YEARLY INTERVALS.

7.1 PARTIALLY REFLECTIVE GLASS CLEANING

The partially reflective glass is cleaned in the factory during the assembly operation. During shipment, installation, handling, etc., the partially reflective glass may collect dust particles; these can be removed by dusting lightly with a clean dry cloth. Fingerprints or other marks, the partially reflective glass can be cleaned with a damp cloth. They partially reflective glass should be completely dried with a lint-free cloth to prevent water spots. To prevent scratching, do not use abrasive cleaners.

7.2 SCHEMATIC DIAGRAM

8.0 LIMITED WARRANTY

This warrants to the original purchaser that this product is free from defects in material and workmanship as of the date of purchase and that it will, under normal use and proper care, remain so for one year from the date of purchase. Missing or initially defective parts will be replaced free of charge during the period of this limited warranty.
If parts are unavailable, comparable replacement of refund will be given. **The original dated sales receipt is required for all warranty claims.** This warranty does not cover damage which has occurred during transport from the point of purchase to the consumer's home. This warranty does not cover glass, light bulbs, batteries, ransportation, labor, or other issues not associated with the manufacture of the product.
This product is for residential use only. Any and all commercial use of this product voids all warranties, and frees the manufacturer from all liability.

Read and understand all assembly and operating instructions, and all safety information and warnings, before use.
The following void this warranty: Damage caused from tampering with, modifying, or altering the fireplace insert in any manner, Damage due to incorrect assembly, improper care, misuse, or abuse, Damage from being used with the wrong power source, Water damage, Damage caused from this insert being used outdoors; Damage caused from this insert being used for excessive periods of time; Damage caused by the insert being used in a commercial applications; Damage from use as a primary heat source: Other misuse or abuse not specifically listed herein.
This product is not intended to be used as a primary heat source, it is for supplemental heating purposes only.

9.0 Q&A AND CONTACT INFORMATION

1.
Q: After installation, I found that half screen of my fireplace was no light. Whats hould i do?
A: This problem was caused by the lamp strip of the product, which installed in the back inner wall of the fireplace. Please check the plug of the lamp strip was fully inserted or not. If the problem couldn't be solved with above step,please contact customer service for help.

2.
Q: I turn on the fireplace and the flame is weak what should I do?
A: This problem is caused by the reflective strip (installed in the back inner place of fireplace). Please contact us to replace the reflective strip to solve this problem.

3.
Q: My fireplace makes a lot of noise, could you please tell me why?
A: Firstly, please confirm where the noise come from? There are usually 3 causes of noise.
(1) Motor noise. It is coming from the bottom of the fireplace and could be solved by changing motor, please contact with customer service for change

(2) Reflected strip noise. It is coming from the back of the fireplace. Please take the fireplace apart, find the reflective strip, and cut off the excess.
(3) Fan noise. It is coming from top of the fireplace. Please contact customer service. They will send you a repair video and provide you with a repair plan as help to repair the fireplace.
If the problem can't be solved by above steps, please contact with customer service for help.

4.
Q: My fireplace does not heat up after plug in, what should I do?
A: It may be the control board is damaged, please send the video and your order number to the email, we will help you solve the problem.

5.
Q: The remote control is insensitive, what should I do?
A: Please confirm you already take out the insulating parts in the remote and load the battery correctly. Then please aim at the upper right corner of thescreen to test when using. If the remote still insensitive after above steps,please contact customer service.

HELP CENTER

Question about your product? We're here to help. Visit us at:

Chat Support | Product Inquiry | Orders FAQ | Product Assembly | Returns & Refunds

We Stands Behind the Quality of The Fireplace

1. If you have any issue with your item, please let us know! We will always do our best to come up with a solution that you will be happy with.
2. Please get in touch with our customer service team before returning the product
3. And please do not throw away the original box(es) if you have not finished assembling and confirmed no quality issues.

Length of return period:
You can return items within 30 days of purchase
In the meanwhile, every gifting you purchased from us comes with a one-year warranty.

Who is responsible for the return shipping fee:

We will cover the return shipping fees if:
1. Your item has a manufacturing defect in materials or workmanship. For example, the wicker has misaligned screw holes. We will send you a prepaid shipping label after you send us photos or videos of the defect.
2. Your item has been damaged in transit. For example, glass is broken or product is damaged. We will send you a prepaid shipping label after you send us photos of the damage.
3. You receive the wrong box(es) due to a warehouse error. We will send you a prepaid shipping label after you send us the wrong SKU numbers on the shipping box(es).
4. One or more boxes are lost in transit, We will send you a prepaid shipping label if you no longer want the item.

* However, we still hope to work with you for a better solution instead of a return. Please don't hesitate to contact our customer service team.

Customer will cover the return shipping fees if:
1. You don't like the product(s) after receiving the box(es).
2. You no longer need the product(s) but you have received the box(es).
3. You buy the product(s) by mistake but you have received the box(es).
4.Order/shipment cancellation talked and you have received the boxes

Return Request