

TOOLS NEEDED:

HERRAMIENTAS NECESARIAS:



INSTRUCTIONS:

- 1. Remove door from hinges by removing hinge pins. Remove damaged door seal and clean surface.**
 - 2. Measure width of door and cut door seal to length with hacksaw.**
 - 3. Install door seal with drip fin to the outside. Attach to bottom of door with screws or nails between the vinyl fins. Replace door onto hinges. Insert hinge pins.**
-

INSTRUCCIONES:

- 1. Quite la puerta de las bisagras quitando las clavijas. Quite la base para puerta dañada y limpie la superficie.**
- 2. Mida el ancho de la puerta y corte la base para puerta con tijeras.**
- 3. Instale la base para puerta con la aleta de goteo hacia afuera. Fijela en el canto inferior de la puerta con tornillos o clavos entre las aletas de vinilo. Cuelgue la puerta en las bisagras e instále los pasadores.**



QUESTIONS? | PREGUNTAS?

800.654.8454

MDBUILDINGPRODUCTS.COM

