LP476

Camp 1000L Weatherproof

3 C Batteries



FEATURES

- Rubberized Edges
- Rubberized Metal Carry Handle
- Weather Resistant

ANSI/PLATO FL1 STANDARD			
MODES	LUMENS	RUN TIME	BEAM DISTANCE
FLOOD MODES			
Flood High	1000 lm	7H	22
Flood Medium	500 lm	15H	15
Flood Low	30 lm	90H	5

OPERATION INSTRUCTIONS

On/Off: Press and release button.

Cycle Modes: Low/Med/High/Red - Press and release button

BATTERY REPLACEMENT

Battery Replacement: The LP476 uses 3 C.
To replace the batteries, turn the base of the lantern counterclockwise to remove it. Slide out the old batteries and insert new batteries according to the (+/-) symbols. For best results, we recommend using brand new alkaline batteries that are the same voltage and brand. Re-attach the base of the lantern by pressing down lightly and turning it clockwise until tight.

If you know it will be a while between uses, we suggest removing the batteries from the flashlight and storing it in a dry, protected place.



PRODUCT WARRANTY

The LP476 has a Limited Lifetime Warranty Against Manufacturer's Defects from time of purchase.
For warranty claims please contact us by calling 801-553-8886 or sending an email to info@luxpro.com

14725 S Porter Rockwell Blvd Ste C
Bluffdale, UT 84065