1,500 LB RATCHET STRAP

INSTALLATION INSTRUCTIONS

⚠ **WARNING:** Read and observe all warnings, instructions, and capacity limitations before using this product. Failure to comply with this warning and the associated instructions and capacity limitations may result in serious personal injury and/or significant property damage.

INSTRUCTIONS:

1. Attach hook WITHOUT Ratchet mechanism to a suitable anchor point.
2. Pass webbing over cargo.
3. Attach hook WITH Ratchet mechanism to a suitable anchor point.
4. Pass free end of webbing through split axle of Ratchet and pull to remove slack.
5. Pump Ratchet handle to tension webbing while being careful not to over-tighten.
6. Rated capacity is based upon 1-1/4 – 1-1/2 turns of the split axle while tensioning the webbing. Tie down must be re-tensioned if the split axle turned less than 1-1/4 turns.
7. Once cargo is properly secured, close Ratchet handle fully to lock the mechanism.
8. To release, pull spring loaded pawl in handle and open Ratchet a full 180 degrees.



IF YOU EXPERIENCE ANY PROBLEMS WITH YOUR SMARTSTRAPS PRODUCT DO NOT RETURN THE UNIT TO THE RETAILER FROM WHICH IT WAS PURCHASED. INSTEAD, PLEASE CALL 1-844-295-9218 FOR ASSISTANCE WITH ANY PROBLEMS. WARRANTY INFORMATION IS AVAILABLE UPON REQUEST AND CAN BE FOUND ONLINE AT SMARTSTRAPS.COM.

©05/2022

WINSTON PRODUCTS COMPANY
SMARTSTRAPS.COM
WINSTON PRODUCTS, LLC.
30339 DIAMOND PARKWAY
CLEVELAND, OH 44139

CORREA CON MATRACA PARA 1,500 LB

INSTRUCCIONES DE INSTALACION

⚠ **ADVERTENCIA:** Lea y siga todas las advertencias, instrucciones y limitaciones de capacidad antes de usar este producto. El incumplimiento de esta advertencia y las instrucciones asociadas y las limitaciones de capacidad puede resultar en lesiones personales graves y o daños materiales significativos.

INSTRUCCIONES:

1. Conecte el gancho SIN mecanismo de trinquete para un punto de anclaje adecuado.
2. Pase las correas más de la carga.
3. Conecte el gancho con el mecanismo de trinquete para un unto de anclaje adecuado.
4. Pase el extremo libre de la trama a través del eje división de trinquete y tire de él para eliminar la holgura.
5. Trinquete de mango de la bomba a la tensión, mientras que las correas con cuidado de no apriete en exceso.
6. La capacidad nominal se basa en 1-1/4 - 1-1/2 vueltas del eje rasguen durante el tensado de la correa. Amarre bien se debe volver a tensados si el eje de división se volvió menos de 1-1/4 vueltas.
7. Una vez que la carga esté bien seguro, cerca de la palanca de trinquete para bloquear totalmente el mecanismo.
8. Para soltar, tirar muelle del trinquete cargado en el mango de trinquete y abra un completo de 180 grados.



SI LISTED PRESENTA CUALQUIER PROBLEMA CON SU PRODUCTO SMARTSTRAPS NO DEVUELVA LA UNIDAD A LA TIENDA DON DE COMPRÓ. AL CONTRARIO, POR FAVOR LLAME AL 1-844-295-9218 PARA OBTENER AYUDA CON CUALQUIER PROBLEMA. LA INFORMACIÓN DE LA GARANTÍA ESTÁ DISPONIBLE A PETICIÓN Y SE PUEDE ENCONTRAR EN LÍNEA EN SMARTSTRAPS.COM.

©05/2022

UNA EMPRESA DE WINSTON PRODUCTS
SMARTSTRAPS.COM
WINSTON PRODUCTS, LLC.
30339 DIAMOND PARKWAY
CLEVELAND, OH 44139