Shark®

EVERYMESS

Wet + Dry + Stain

VX101ANZ

OWNER'S GUIDE



Scan QR code to view
HOW-TO VIDEOS

IMPORTANT SAFETY INSTRUCTIONS

FOR HOUSEHOLD USE ONLY

⚠ WARNING

To reduce the risk of fire, electric shock, injury, or property damage, when using an electrical appliance, basic precautions should always be followed, including the following:

ELECTRICAL & POWER SAFETY

1. Inspect power cord and plug for any damage before use. **DO NOT** use vacuum cleaner with a damaged cord or plug. Turn off all controls before plugging in or unplugging the vacuum cleaner. To minimise the risk of power cord damage, store your vacuum cleaner with the power cord secured around the handle.
2. **DO NOT** handle the plug or vacuum with wet hands.
3. The use of an extension cord is **NOT** recommended.
4. **DO NOT** damage the charging cord:
   - **a) DO NOT** pull or carry vacuum cleaner by the cord or use the cord as a handle.
   - **b) DO NOT** unplug by pulling on cord. Grasp the plug, not the cord.
   - **c) DO NOT** run vacuum over the cord, close a door on the cord, pull the cord around sharp corners, or leave the cord near heated surfaces.
5. Turn off all controls before unplugging the vacuum.
6. Unplug from electrical outlet when not in use and before any maintenance or cleaning.
7. **DO NOT** immerse the product in water.
8. To reduce the risk of electrical shock, use indoors only.
9. To reduce the risk of electric shock, always install the debris screen before any wet pickup operation.
10. This appliance is provided with double insulation. Use only identical replacement parts. See instructions for Servicing of Double-Insulated Appliances.

GENERAL USE & MAINTENANCE

11. Carefully observe and follow the instructions provided below to avoid improper use of the appliance. **DO NOT** use the vacuum for any purpose other than those described in this manual.
12. Before use, carefully inspect all parts for any damage. **DO NOT** use if any parts are damaged.
13. **DO NOT** use if vacuum cleaner is not working as it should, or has been dropped, damaged, left outdoors, or dropped into water.
14. Use only identical replacement parts.
15. Only use Shark® branded filters and accessories.
16. **DO NOT** modify or attempt to repair the vacuum yourself. **DO NOT** use the vacuum if it has been modified or damaged.
17. Your vacuum cleaner consists of a vacuum pod. This device contains electrical connections, electrical wiring, and moving parts that potentially present a risk to the user. **DO NOT** use when damaged.
18. This vacuum cleaner contains no serviceable parts.
19. Always turn off the vacuum cleaner before connecting or disconnecting the hose or opening and closing the lid.
20. Make sure the dust cup, debris screen, and all filters are in place before plugging in and turning on the unit.
21. **DO NOT** use without filters in place.
22. Make sure the dust cup and all filters are in place after routine maintenance.
23. **DO NOT** leave appliance when plugged in. Unplug from outlet when not in use and before servicing.
24. **DO NOT** leave the vacuum cleaner unattended while plugged in.
25. Store indoors. **DO NOT** expose to rain.
26. **DO NOT** place vacuum cleaner on unstable surfaces such as chairs or tables.
27. Secure the hose around the unit lid and power cord around the handle during storage.
28. Use extra care when cleaning on stairs.
29. Check manufacturer's tag prior to cleaning area rugs for any specific cleaning guidelines. We **DO NOT** recommend deep cleaning delicate rugs (including wool, cotton, silk, antique, or area rugs that **DO NOT** have a manufacturere's tag).
30. Always perform a small patch test on a small hidden spot of the area rug or surface you are cleaning to make sure it is ok to clean with this product.
31. Choose the correct bristle for your surface to prevent property damage. The rubber nubs are designed to be used for more delicate surfaces. The tough bristles are ideal for stubborn agitation on hard wearing surfaces for deep stain cleaning.

CHILDREN & PETS SAFETY

32. This appliance can be used by persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
33. Cleaning and user maintenance shall not be made by children.
34. Keep the appliance and its cord out of reach of children.
35. **DO NOT** allow the appliance to be used by children. **DO NOT** allow to be used as a toy. Close supervision is necessary when used near children.
36. **DO NOT** use near pets or in occupied pet enclosures.
37. Allow all treated surfaces to dry completely before reintroducing pets.
38. Any treated surface should be allowed to dry completely, and ventilate areas as needed before allowing pets access to the treated areas.

FIRE, CHEMICAL & MATERIAL SAFETY

39. **DO NOT** use to pick up:
   - **a)** Large quantities of dust (e.g., drywall dust, fireplace ash, or embers). **DO NOT** use as an attachment to power tools for dust collection.
   - **b)** Smoking or burning objects (e.g., hot coals, cigarette butts, or matches).
   - **c)** Flammable or combustible materials (e.g., lighter fluid, gasoline, or kerosene).
   - **d)** Toxic materials (e.g., chlorine bleach, ammonia, or drain cleaner).
40. To reduce the risk of fire, **DO NOT** use a flammable or combustible liquid to clean a floor.
41. **DO NOT** spray solution on your skin or in your eyes.
42. **DO NOT** use in the following areas:
   - **a)** Poorly lit areas.
   - **b)** Spaces that are enclosed and may contain explosive or toxic fumes or vapors (lighter fluid, gasoline, kerosene, paint, paint thinners, mothproofing substances, or flammable dust).

CLEANING & MAINTENANCE

43. Hand wash components with warm soapy water. Washing with harsh cleaning chemicals could damage the unit.
44. Allow all filters to air-dry completely before replacing in the vacuum to prevent liquid from being drawn into electric parts.
45 Before cleaning a surface with the cleaning solution, check the manufacturer's tag. **DO NOT** clean delicate rugs (including wool, cotton, silk, antique, or area rugs) unless they have a manufacturer's tag. If the manufacturer's tag says S or "Dry Clean Only", **DO NOT** clean that surface. If the tag says W or WS, you **CAN** use SHARK Cleaning Solution on that surface.

OPERATION & AIRFLOW SAFETY

46. **DO NOT** put any objects into end of the hose or accessory openings. **DO NOT** use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
47. **DO NOT** use if the hose or accessory airflow is restricted. If the air paths become blocked, turn the vacuum cleaner off and unplug from electrical
48. Keep all vacuum openings away from hair, face, fingers, uncovered feet, or loose clothing.
49. When using on any surface, always keep the end of the hose or accessory moving to avoid damaging the surface (e.g., carpet fibers).


⧈ SERVICING OF DOUBLE-INSULATED APPLIANCES


A double-insulated appliance is marked with one or more of the following: The words "DOUBLE INSULATION" or "DOUBLE INSULATED."

In a double-insulated appliance, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated appliance, nor should a means for grounding be added to the appliance. Servicing a double-insulated appliance requires extreme care and knowledge of the system, and should be done only by qualified service personnel. Replacement parts for a double-insulated appliance must be identical to the parts they replace.

SAVE THESE INSTRUCTIONS

GETTING TO KNOW THE EVERYMESS





NOTE: *DISHWASHER SAFE.

AVAILABLE ACCESSORIES


NOTE: Included accessories differ by model. For a list of accessories included with this model, see the top inside flap of the box. To order additional accessories, visit
AU | sharkclean.com.au/collections/accessories-parts NZ | sharkclean.co.nz/collections/accessories-parts

Ⓐ **Squeegee Tool***
A tool designed to clean wet and mixed messes on bare floors. Also effective at removing stubborn embedded pet hair from carpet and upholstery.

Ⓑ **Crevice Tool***
Great for cleaning fine and small debris from hard-to-reach crevices, corners, and other tight spaces.


Ⓒ **Stain-Eliminator Tool**
Use with StainForce solution to remove stubborn spots and stains.

Ⓓ **StainForce Spray Solution**
Spray generously directly onto stains, then use the Stain Tool to scrub.




NOTE: *DISHWASHER SAFE.

SPRAY BOTTLE ASSEMBLY




Twist off both caps on the cleaning solution bottle, then peel off the foil seals.




Press the sprayer down over the openings on top of the bottle. Make sure it clicks securely in place.

Scan QR code to view
HOW-TO VIDEOS


ASSEMBLY




Insert rear hose clip into the back of the main unit, just above the power cable.




Insert the **Accessory Holder** into the notch on the side of the unit. Press the holder down over the **Dust Cup** until it clicks securely into place.




Insert the **Hose Connector** into the opening on the side of the unit until it clicks into place.



Insert the hose into the rear hose clip, then into the accessory holder clip. Wrap the hose around the bottom of the main unit.




To store the hose on the unit, press the tab Ⓐ on the hose inlet, then inset the tab into the opening Ⓑ near the bottom of the main unit. When connected properly, it will click securely into place.



Insert accessories into the slots in the holder. Store the power cord by wrapping it around the handle.

USING YOUR EVERYMESS


DUST CUP CAPACITY




The dust cup has a dry debris capacity of 3.8 L and a wet debris capacity of 1.9 L. When vacuuming wet or sloppy messes, **do not fill the dust cup above the Wet Debris Max Fill** line.

When debris reaches the Max Fill line, the float mechanism in the dust cup will rise automatically to cut off airflow. Suction will cease and motor noise will become higher in pitch. When this happens, turn off the vacuum, unplug the power cord, and empty the dust cup.

OPENING THE LID



Pull out the bottom of the latch to release, then pull the latch down to unhook from the lid.



After unlatching the lid, open it by lifting the handle.



IMPORTANT: Unplug the power cord before opening the lid.


ANYBAG TECHNOLOGY


The EveryMess can be used **with or without** a bag.

Vacuuming without a bag
You can vacuum straight into the dust cup without a bag. The dust cup is removable and dishwasher safe.

Vacuuming with AnyBag Technology
Line the inside of the dust cup with any plastic trash bag (8L to 50L) for easy disposal of debris.

Note: Carefully inspect the bag for damage or holes. **DO NOT** use a bag with holes. **DO NOT** use a bag when vacuuming sharp or industrial debris.









1. Insert an undamaged plastic bag to line the inside of the dust cup. Push the bottom of the bag down to the base of the dust cup.
2. Tuck the top of the bag between the **Bag Guides** and **Dust Cup Shelf**.
3. Run any excess bag through the **Bag Holder Slot** on the top of the accessory holder.
4. Close the lid to secure the bag in place. The lid should clamp over the excess bag.

USING YOUR EVERYMESS




POWER BUTTON

Press the power button to turn on the vacuum.




HOSE INLET


Use the hose inlet to suction up **ANY** mess.



SQUEEGEE TOOL



CREVICE TOOL*




STAIN TOOL

Attach a cleaning tool by inserting it into the hose inlet until it clicks into place. (See Available Accessories for more information.)

*Accessory tools may vary by model.


USING YOUR EVERYMESS

DRY VACUUMING




HOSE INLET

Use the hose inlet to vacuum up any mess, wet or dry.



SQUEEGEE TOOL

Use the Squeegee Tool to lift fine dust and debris from hard floors and smooth surfaces.



CREVICE TOOL


Use the Crevice Tool to clean in tight spaces, crevices, and other hard-to-reach areas.

WET VACUUMING



HOSE INLET

Use the hose inlet to vacuum up any mess, wet or dry.



SQUEEGEE TOOL


The squeegee tool's wide cleaning path is ideal for removing liquid messes.

STAIN CLEANING TIPS

REMEMBER to vacuum any debris with another attachment first. The stain tool's inlet is designed to maximize suction power for stains.

Always follow the Stain Cleaning Guide on the next page.
Always use Stain Tool with StainForce bottle only.


IMPORTANT:
Use StainForce chemical only on soft surfaces such as carpets, rugs, and upholstery. **DO NOT** use on hard surfaces (wood, tile, laminate, etc.), as this may cause damage.



STAIN CLEANING

PRE-TREAT


WET STAIN CLEANING



EXTRACT LIQUID

First, suction up the liquid spill to prevent spreading the stain.

DRY STAIN CLEANING




SCRUB STAIN & EXTRACT

Scrub stain back and forth using bristles or fins, then, turn on unit, tilt handle, and drag backwards to extract dry debris.




SPRAY - OVERSATURATE (X2)

Spray cleaning solution to over-saturate, 5 cm from the stain. Let soak for a few minutes and spray again. Apply at least 2 layers of solution.



SCRUB - TO AGITATE STAIN

Scrub the stain with the bristles again with a back-and-forth motion.




EXTRACT - USING PRESSURE

For best suction be sure to tilt up (as shown) and apply pressure. Slowly pull backwards to extract the solution. **Pull back only.**

LET DRY, THEN REPEAT STEPS 2 TO 4 UNTIL THE STAIN FULLY FADES.

REVERSIBLE BRISTLES AND FINS



The Stain Tool has both bristles and hair-gripping fins. To use the fins, lift off the bristles, turn them over, then reinstall, with the fins on top.


TIPS:

- Use bristles for deep cleaning and to agitate stains.
- Use the Hair-Gripping Fins to remove hair from delicate or hairy surfaces and to prevent tangling.

EMPTYING THE DUST CUP*



IMPORTANT: Unplug the power cord before opening the lid.



Always empty the dust cup after vacuuming.

1. Open the lid, then lift out the dust cup by the sides. **DO NOT** grab the dust cup by the bag guides.
2. Dump debris into the trash and rinse out the dust cup with warm water.
3. Allow the dust cup to air-dry completely before reinstalling it back into the unit.

RINSE & READY: AUTOMATICALLY RINSING THE HOSE, LID, AND DUST CUP



Run a Rinse & Ready cleaning cycle after picking up any **wet** or **organic mess.**


1. Empty the dust cup. If using AnyBag Technology, remove the bag and dispose of it.
2. Vacuum up 300 mL of water from a cup, bowl, or other container.
3. Unplug the unit and open the lid. If any stubborn debris remains, follow the instructions in the Cleaning the Lid and Debris Screen section.


RINSING THE LID AND DEBRIS SCREEN





IMPORTANT: Unplug the power cord before opening the lid.

Rinse the lid and debris screen after picking up any **wet** or **organic mess.**










1. Open the lid to a 180-degree angle then pull out to detach it from the hinges.
2. Twist the debris screen counterclockwise and pull it out.
3. Rinse the lid and debris screen in the sink with warm water. Allow the lid and debris screen to air-dry completely before reinstalling.
4. To reinstall the debris screen, align the arrow in the lid with the arrow on the side of the debris screen and twist clockwise to the lock symbol to secure.
5. To reattach the lid, align the hinge connection points at 180 degrees and push until it snaps into place.

CLEANING THE ACCESSORIES



The Squeegee Tool*, Crevice Tool*, and Stain Tool should be cleaned after picking up any wet and organic mess.


1. Wash the accessories in the sink with warm, soapy water.
2. Allow accessories to air-dry completely.

NOTE: *DISHWASHER SAFE. STAIN TOOL IS NOT DISHWASHER SAFE.

NOTE: Included accessories differ by model. For a list of accessories included with this model, see the top inside flap of the box. To order additional accessories, visit
AU | sharkclean.com.au/collections/accessories-parts
NZ | sharkclean.co.nz/collections/accessories-parts


CLEANING THE FILTERS

Regularly rinse and replace the filters to maintain your vacuum's suction power. The pre- and post-motor filters should be cleaned **once a month** and replaced **once a year** for optimal performance.



PRE-MOTOR FILTERS

1. Lift out the foam filter by the handle, then pull out the felt filter.
2. Rinse both filters with cold water **ONLY. DO NOT** use soap. Allow both filters to air-dry completely before reinstalling.
3. Reinsert the felt filter first, followed by the foam filter.




POST-MOTOR FILTER

1. Pull up on the post-motor filter cover to remove it, then lift out the post-motor filter.
2. Wash the filter gently with cold water **ONLY. DO NOT** use soap. Leave the filter out to air-dry completely before reinstalling it.
3. Reinsert the post-motor filter back into the opening, then place the cover over it and press down until it clicks into place.

IMPORTANT: DO NOT use soap when cleaning the filters.


CHECKING FOR BLOCKAGES

1




Remove any attached accessories and check the inlet for blockages.

2



Check the hose and opening in the unit for blockages.


3




Remove the debris screen and check for any blockages inside the openings in the lid. Wash the debris screen if needed.

STORAGE

Before storing the EveryMess, empty the dust cup. Clean the unit and allow all parts to air-dry completely. Always store the EveryMess indoors.



Wrap the hose around the unit and clip it in place. (See Assembly section.)



Neatly wrap the power cord around the handle. Use the cord clip on the plug to hold the wrapped cord securely in place.

TROUBLESHOOTING

⚠ **WARNING:** To reduce the risk of shock and unintended operation, turn off power before servicing.

ISSUE	WHAT IT MEANS	WHAT TO DO
Vacuum will not operate.	1. No power supply.	1. Check power cord, breakers, fuses.
	2. Faulty power cord.	2. Unplug and check the power cord. If damaged, call Customer Service AU 02 8801 7666 NZ 0800 112 660.
Fine dust comes out from the motor exhaust.	1. The pre- or post-motor filters are missing or need maintenance.	1. Follow the instructions in the Cleaning the Filters section.
No suction or low suction.	1. There are blockages in the accessory, hose, hose port, debris screen, or lid openings.	1. Unplug and check accessories, hose, hose port, debris screen, and lid openings for blockages.
	2. The pre- and post-motor filters need maintenance.	2. Follow the instructions in the Cleaning the Filters section.
	3. Dust cup is full.	3. Empty the dust cup.
	4. The bag was not inserted correctly.	4. Carefully follow the instructions in the AnyBag Technology section.
Motor noise.	1. Dust cup filled beyond Max Fill line and float valve has been activated.	1. Empty the dust cup.
	2. The pre- and post-motor filters need maintenance.	2. Take out the filters and clean with cold water only or install new filters.
Wet debris leaking.	1. Dust cup filled beyond Wet Debris Max Fill line.	1. Follow the instructions in the Maintenance section. Once complete, plug in and turn on the vacuum. Allow it to run for 2 minutes to dry out.
Vacuum is emitting air that smells bad.	1. The unit needs to be cleaned.	2. Follow the instructions in the Maintenance section.
Vacuum turns off while vacuuming.	1. Motor has overheated.	1. Shut the vacuum off, unplug, and let it sit for 60 minutes.

For all other issues, please call Customer Service AU 02 8801 7666 NZ 0800 112 660

TWO (2) YEAR LIMITED REPLACEMENT WARRANTY

For guarantee claims, you will need to submit a proof of purchase in the form of a valid receipt that displays date and place of purchase. This warranty does not replace but is in addition to your statutory rights.

If your product becomes defective due to faulty material or workmanship within a period of 2 years from the date of purchase, we warrant to do the following:

• For New Zealand Consumers:
We will replace the defective/faulty part with a new product, free of charge or if the unit is deemed defective/ faulty we replace the unit with an equivalent or upgraded model, at our discretion.

• For Australian Consumers:
Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Replacement items will be covered by the limited warranty for the balance of the warranty period from the date of the original purchase.

Please note: Your warranty is subject to the following conditions:

- DO NOT operate the appliance with a damaged plug or cord or if the unit has been dropped,damaged or dropped in water.
- To avoid the risk of electric shock, do not disassemble or attempt to repair the appliance on your own. If the supply cord is damaged, it must be replaced by a qualified electrician to avoid a hazard. Incorrect re-assembly or repair can cause a risk of electric shock or injury to persons when the appliance is used.
- The item has not been misused, abused, neglected, altered, modified or repaired by anyone.
- The item has been subjected to fair wear and tear.
- The item has not been used for trade, professional or hire purposes.
- The item has not sustained damage through foreign objects, substances or accident

What is not covered?
- Accessories supplied with the item.
- Components that are subject to natural wear and tear caused by normal use in accordance with operating instructions.
- Unauthorised/improper maintenance/handling or overload is excluded from this warranty.

REGISTER YOUR PURCHASE

AU sharkclean.com.au
NZ sharkclean.co.nz

Scan QR code using mobile device.

RECORD THIS INFORMATION

Model Number: _____

Serial Number: _____

Date of Purchase: _____
(Keep receipt)

Store of Purchase: _____

TECHNICAL SPECIFICATIONS

Voltage: 230V~, 50Hz

Watts: 780W

The power consumption in Off mode: 0.0W

Benefits of registering your product and creating an account:

- Get easier, faster product support and access to warranty information.
- Access troubleshooting and product care instructions.
- Be among the first to know about exclusive product promotions.
-

TIP: You can find the model and serial numbers on the QR code label on the bottom of the back of the vacuum pod.

PLEASE READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

This Owner's Guide is designed to help you get a complete understanding of your new Shark® product.

SHARKNINJA PTY. LTD.
Suite 23.02, Level 23, 45
Clarence St, Sydney NSW 2000
AU 02 8801 7666
NZ 0800 112 660
AU sharkclean.com.au
NZ sharkclean.co.nz

Illustrations may differ from actual product. We are constantly striving to improve our products; therefore the specifications contained herein are subject to change without notice.

This product may be covered by one or more U.S. patents. See sharkninja.com/patents for more information.

© 2026 SHARK is a registered trademarks of SharkNinja Operating LLC.

VX101ANZ_CondensedIB_MP_Mv4
PRINTED IN CHINA

@sharkhomeau | @sharkhomenz