尺寸：148*210mm　　装订，封面160G双胶纸，内页100G双胶纸

30mm
5mm
73mm
1.5mm
录入区域6.5mm

封面

GeekChef®
Air Fryer Countertop Oven

User Manual
Model No.: GT010A

Toll Free:1-844-801-8880
IMPORTANT: Read the instructions carefully before operating the appliance and keep them for future reference.

Table Of Contents

Safety Instructions	2
Product Components	5
How To Use	6
Cleaning And Maintenance	12
Troubleshooting	13
Limited Warranty	14

Specification

SPECIFICATION

Model No.	GT010A
Rated Voltage	120V~60 Hz
Rated Power	1260 W
Oven Capacity	14QT
Product Dimension	13.15*13.5*12.6 (inch)

Safety Instructions

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. UNPLUG FROM OUTLET WHEN NOT IN USE AND BEFORE CLEANING. Allow to cool before cleaning or handling, putting on or taking off parts.
3. Do not touch hot surfaces. Use handles or knobs.
4. To protect against electrical shock, do not place any part of the Air Fryer Countertop Oven in water or other liquids. See Instructions for Cleaning and Maintenance.
5. This appliance should not be used by or near children or individuals with reduced capabilities.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance has malFUNCTIONed or has been dropped or damaged in any way or is not operating properly. Return the Air Fryer Countertop Oven to the store or retailer where purchased for examination or repair, or replacement.
7. The use of accessory attachments not recommended by Homeasy may cause injuries.
8. Do not use outdoors.
9. Do not let cord hang over the edge of the table or countertop, where it could be pulled on inadvertently by children or pets, or touch hot surfaces, which could damage the cord.
10. Do not place this Air Fryer Countertop Oven on or near a hot gas or electric burner, or in a heated oven.
11. Do not use this Air Fryer Countertop Oven for anything other than its intended purpose.
12. Extreme caution should be exercised when using containers constructed of materials other than metal or glass in the oven.

Safety Instructions

13. To avoid burns, use extreme caution when removing Air Fryer Countertop Ovenaccessories or disposing of hot grease.
14. When not in use, always unplug the unit. Do not store any materials other than manufacturer's recommended ovenproof accessories in the Air Fryer Countertop Oven.
15. Do not place any of the following materials in the Air Fryer Counter top Oven: paper,cardboard, plastic and similar products.
16. Do not cover Crumb Tray or any part of the oven with metal foil. This will cause overheating of the oven.
17. Oversize foods, metal foil packages and utensils must not be inserted in the Air Fryer Countertop Oven, as they may involve a risk of fire or electric shock.
18. A fire may occur if the Air Fryer oven is covered or touching flammable materials such as curtains, draperies or walls, when in operation. Do not cover Crumb Tray or other appliance when in operation. Do not operate under wall cabinets.
19. Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, involving a risk of electric shock.
20. Do not attempt to dislodge food when the Air Fryer Countertop Oven is plugged into the electrical outlet.
21. Warning: To avoid possibility of fire, NEVER leave Air Fryer Counter top Oven unattended during use.
22. Do not rest cooking utensils or baking dishes on glass door.
23. Do not place any combustible materials on, near or under oven in wall cabinet. When storing in an appliance garage, always unplug the unit from the electrical outlet. Not doing so could create a risk of fire, especially if the appliance touches the walls of the garage or the door touches the unit as it closes.
24. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
25. Turn thermostat knob to the lowest possible setting to "OFF" position, then remove plug from the wall outlet.

Safety Instructions

SAVE THESE INSTRUCTIONS

Please read and keep these instructions handy. These instructions will help you use your Air Fryer Countertop Oven to its fullest so that you will achieve consistent, professional results.

SPECIAL CORD SET INSTRUCTIONS

Short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord. Extension cords are available and may be used if care is exercised in their use. If an extension cord is used,

1. The marked electrical rating of the extension cord must be at least as great as the electrical rating of the appliance.
2. The longer cord should be arranged so that it will not drape over the countertop or tabletop, where it can be tripped over unintentionally or pulled on by children.

NOTICE

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

FOR HOUSEHOLD USE ONLY
NOT INTENDED FOR COMMERCIAL USE

Product Components

PRODUCT COMPONENTS

1. Air Fry oven
2. Air Fry basket
3. Wire rack
4. Baking pan
5. Crumb tray

Product Features

1. **Air Fry basket**
   The Air fry basket is grated to allow air to pass through the basket for even cooking. The Air Fry basket can only be used in conjunction with either the Baking pan or on the Wire rack. The Air fry basket should be placed in the middle rack position unless a recipe states otherwise.
2. **Wire rack**
   The oven rack can be used in three rack positions, bottom, middle, and top. See "Oven Rack/Pan Position" section in the manual. Generally, the top position should be used for Broil, the middle for Air Fry and Toast, and the bottom for Warm and Bake. Always reference recipe instructions for proper position.

How To Use

HOW TO USE

Control Panel

1. **Power On Light**
   Indicator light will turn on and remain lit when oven is in use.
2. **SPEED Dial**
   Use to select desired fan speed. All FUNCTIONs can be set fan speed.
3. **FUNCTION Dial**
   Use to select the cooking FUNCTION – Warm, Broil, Toast, Bake, Air Fry.
4. **TEMP ⅴ Dial**
   Use to set the desired TEMP ⅴ.
5. **TIME Dial**
   Use to set the desired time for all FUNCTIONs except Toast, timeRange from 1 to 60 minutes. Setting the oven TIMER, powers the unit on and begins the cooking cycle, and the light of inside will be lighting. When the TIMER runs out, sound a bell ringing, and the unit will power off.

How To Use

Before First Use

1. Unpack the Air Fryer oven and remove all packaging materials.
2. Place the Air Fryer oven on a flat, stable, level surface. Ensure that the oven is 2 to 4 inches away from the wall or any other objects.
3. We recommend performing a trial run of your Air fryer oven to eliminate any protective substance from the heating elements. Conduct the trial run in a well-ventilated area as a small amount of smoke and odor may be detected. This is normal and should be expected.

Note:
* Objects should not be stored on the top of the oven.
* The exterior housing will get very hot when in use, keep out of reach of children.

Oven Rack / Pan Positions
Oven have 3 rack/pan positions: Position 1 (bottom), Position 2 (middle), position 3 (top). Usually suggested put over rack or pan in position 2 (middle) for best cooking result.

How To Use

1. **Place your Air Fryer Countertop Oven on a flat surface.**
   Before using your Air Fryer Counte top Oven, place it 4 inches away from the wall or from any objects on the counter.
   Do not use on heat-sensitive surfaces.

2. **Crumb Tray**
   Open the door, put crumb tray into the unit according to the directions shown in the picture below.

3. **Bake Tray**
   Put the food into the bake tray and put it into the cooking chamber, tand then close the door.

How To Use

4. **Oven Rack**
   Insert the oven rack into the unit according to the directions shown in the picture below.

5. **Air Fry Basket**
   Insert the air fry basket into the unit according to the directions shown in the picture below.

Note:
* Choose proper accessories for different cooking purpose.
* Please use oven mitts to take out the crumb tray, bake tray, oven rack and air fry basket to avoid burning hands.
* Please always keep the crumb tray on the bottom of the cooking chamber for gathering oil from the fried food.

How To Use

Operations

Unwind the power cord. Check that the Crumb Tray is in place and that there is nothing in the oven. Plug power cord into the wall outlet.

Warm
Set the FUNCTION Dial to Warm. Then turn the TIMER Dial to the desired warming time to start the oven and begin warming.The bottom heating elements will turn on. The power light will illuminate. The TIMER will ring once when the cycle is complete and the oven will power off when the time expires. To stop warming, turn the TIMER Dial to the OFF position.

Broil
Set the FUNCTION Dial to Broil . Set TEMP ⅴ Dial to desired TEMP ⅴ. Then turn the TIMER Dial to the desired cooking time to start the oven and begin broiling. The top heating elements will turn on. The power light will illuminate. The TIMER will ring once when the cycle is complete and the oven will power off when the time expires. To stop broiling, turn the TIMER Dial to the OFF position.

Broiling Tips:
Never use glass oven dishes to broil.
Be sure to keep an eyes on foods can get dark quickly while broiling.

Toast
Set the FUNCTION Dial to Toast. Set the TEMP ⅴ Dial to desired TEMP ⅴ. Then turn the TIMER Dial to the desired cooking time to turn on the oven and begin toast.The oven power light will illuminate. When completed, the TIMER will ring and turn off. To stop toasting,turn the TIMER Dial to the OFF position.

How To Use

Bake
Set the FUNCTION to Bake. Set the TEMP ⅴ Dial to desired TEMP ⅴ. Then turn the TIMER Dial to the desired cooking time to start the oven and begin baking.It is recommended to preheat oven for 5 minutes prior to baking. Incorporate this into the total baking time). The upper heating elements will turn on. The oven temperature will cycle. The power light will turn on. The TIMER will ring once when the cycle is complete and the oven will power off when the time expires. To stop operation, turn the TIMER Dial to the OFF position.

Air Fry
Place the Air Fry basket into the Baking Pan or Oven Rack. Air Fry in rack Position 2.
Set the FUNCTION Dial to Air Fry. Set TEMP ⅴ Dial to desired TEMP ⅴ. Then turn the TIMER Dial to the desired cooking time to turn on the oven and begin Air Fry. The top heating elements and fan will turn on.The oven power light will illuminate. The TIMER will ring once when the cycle is complete and the oven will power off when the time expires. To stop Air Frying, turn the Dial to TIMER the OFF position.

Cleaning And Maintenance

CLEANING AND MAINTENANCE

1. Unplug your Air Fryer Oven and allow it to completely cool before cleaning. Do not use abrasive cleaners, as they will damage the finish. Simply wipe the exterior with a clean, damp cloth and dry thoroughly. Apply the cleaning agent to a cloth, not directly onto the Air Fryer Oven. Do not use excess pressure when cleaning the area of the control panel as it could cause the best to be removed over time.
2. To clean the interior walls and bottom of the oven (remove the Crumb Tray first) use a damp soapy cloth or sponge. Never use hardy abrasives or corrosive products including oven cleaner sprays. These will permanently damage the surface. Never use steel wool pads on the Air Fryer Oven or accessories.
3. The Oven Rack, Baking/Drip Pan, Air Fryer Basket and Crumb Tray should be hand-washed in hot, sudsy water or use a nylon scouring pad or nylon brush. These parts are not dishwasher safe.
4. Always clean the Crumb Tray after each use. Excess food particles could cause smoking and will be hard to remove from tray. To remove food particles, fill the Crumb Tray with hot water and let it soak for 15 min in hot, sudsy water or use nondabrasive cleaners. Never operate the oven without the Crumb Tray in place.
5. The top interior of the Air Fryer Oven should be cleaned to remove excess grease that may accumulate after cooking greasy foods. Doing so will prevent smoking in the oven during subsequent uses.

Troubleshooting

TROUBLESHOOTING

PROBLEM		PROBABLE CAUSE
The oven will not turn on	1	Make sure the oven is plugged in.
	2	Turn on the TIMER DIAL.
Foods are not completely cooked.	1	Decrease cooking TEMP ⅴ or time.
Foods are over cooked or burned.	1	Decrease cooking TEMP ⅴ or time.
	2	Make sure foods are not too large to touch the heating elements.
Foods are cooked unevenly.	1	Preheat the oven
	2	Make sure foods are not too closely placed on a tray, rack or other container.
White smoke is coming out from the oven.	1	The oven may cause a little white smoke when it be first used. This is normal.
	2	When the oven is cooking, excess oil or fatty foods may cause white smoke. Make sure the inside of the oven is cleaned properly and not greasy
Black smoke is coming out from the oven.	1	Immediately turn off the oven and then unplug it. Cool down the oven to room TEMP ⅴ. Then remove the food by opening the oven door or pulling out the tray, basket or rack.

Limited Warranty

LIMITED WARRANTY

HOME EASY LTD warrants to the original consumer or purchaser that the Air Fryer Countertop Oven is free from defects in material or workmanship for a period of One (1) year from the date of purchase. If any such defect is discovered within the warranty period, HOME EASY LTD, at its discretion, will repair or replace the Product at no cost. This limited warranty is good only to the original purchaser of the product and effective only when used in United States.

For warranty or repair service: Call 1-844-801-8880 and choose the appropriate prompt, or email info@homeasy.net. Please have your Product's model number, your name, address, city, state, zip code and phone number ready.

NO OTHER WARRANTY IS APPLICABLE TO THIS PRODUCT. THIS WARRANTY IS IN LIEU OF ANY OTHER WARRANTY, EXPERSS OR IMPLIED. INCLUDING WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT ANY IMPLIED WARRANTY IS REQUIRED BY LAW, IT IS LIMITED IN DURATION TO THE WARRANTY PERIOD SET FORTH ABOVE. NEITHER THE MANUFACTURER NOR ITS U.S.DISTRIBUTOR SHALL BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY NATURE. INCLUDING WITHOUT LIMITATION: LOST REVENUES OR PROFITS, OR ANY OTHER LOSS OR DAMAGE ARISING OUT OF USE OR INABILITY TO EMPLOY. SOME STATES AND/OR TERRITORIES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS. SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU, THE ORIGINAL PURCHASER, SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE OR TERRITORY TO TERRITORY.

Limited Warranty

1. Failure of product to perform during power failures and interruptions or inadequate electrical service .
2. Damage caused by transportation or handling.
3. Damage caused to the product by accident, vermin, lightning, winds, fire, floods, or acts of God.
4. Damage caused by improper handling, alteration, misuse, abuse, or improper installation, repair, or maintenance. Improper use includes using an external device that alters or converts the voltage or frequency of electricity.
5. Any unauthorized product modification, repair by unauthorized repair center, or use of non-approved replacement parts.
6. Abnormal cleaning and maintenance as described in the user's manual.
7. Use of accessories or components that are not compatible with this product.

The cost of repair or replacement under these excluded circumstances shall be borne by the consumer.

GeekChef®
Kool Solutions For Life

Home Easy Ltd
1275 Bloomfield Ave
Fairfield, NJ 07004
1-844-801-8880

左右不可侵入区域8mm