BISSELL®

BigGreen Commercial™

Sweeper BG25™
Sweeper BG23™
Sweeper BG21™

Quick and easy assembly

1. **A** - Locate 4 handle sections and top plastic handle grip.



B – 1 of the 4 handle sections has a plastic nut in one end. This is the bottom of the handle



2. Twist all handle sections together with the 1 piece of handle with plastic nut on bottom. Twist sections until they fit tightly into one another. When handles no longer turn they are in place. add plastic hand grip to the top of handle by inserting firmly.





3. Lift the bail (threaded metal bar on the top of the sweeper) to a vertical position. Screw sweeper handle all the way down the "shoulder" of the threaded metal bail. Failure to do this could cause the bail to break.



To empty dustpan

Hold sweeper over wastebasket. Press gently on rear of dustpan. Pan will open and debris will fall out.



Proper care and cleaning

Models BG25 & BG23

Clean strings, hair and other debris from the brush, paying special attention to the brush ends. Cleaning can be performed while the brush is in or out of the sweeper.



Model BG21 only

Paddles can be removed and washed with warm soapy water or washed in a dishwasher. Thoroughly dry before reinserting the brush.