Innovaze®
Innovation for quality and design

User Manual

MGCS-2001B Trash Can



1. Please find the assembly guidelines on Page 2.
2. We are committed to providing excellent after-sales support, and we offer a 1-year warranty for this product, covering damage that occurs during shipping and parts damaged during normal use. If you have any issues, our dedicated customer service team is always ready to assist you, ensuring complete satisfaction with your purchase.
3. Dents may occur due to violent impacts during the shipping process. If you find any defects, dents, or missing parts, please send an email to cs@innovaze.com. Please tell us your order number, shipping address, and which part is needed. We will respond within 24 hours and provide free replacement parts or other services you need.
4. Please wipe the stainless steel surface regularly with a soft, damp cloth and mild detergent. Avoid abrasive cleaners, bleach, steel wool, and harsh chemicals. Wipe dry after cleaning to help prevent water spots and maintain the finish.

MEGA CASA INC. dba Innovaze USA

18003 Cortney Court, City of Industry, CA 91748
Phone Number: 1-888-810-6342
E-mail: cs@innovaze.com

INSTRUCTIONS

1. Install the Removable Drip Pan

Place the removable drip pan at the bottom of the trash can.





2. Use the Foot Pedal

Step on the foot pedal to open the lid hands-free.

3. Soft-Close Lid

The built-in damper system controls the lid closing speed for a soft and quiet close.

4. Stay-Open Position

For longer tasks, lift the liner rim and lid together by hand to the fully upright position (90°) to keep them open.

⚠ATTENTION: Do not step on the foot pedal while lifting the liner rim and lid to the upright position, as this may damage the opening mechanism.

5. Insert and Secure the Trash Bag

Step 1: Lift the liner rim and lid together to the stay-open position.

Step 2: Place the trash bag inside the can and fold the top edge of the bag over the rim of the trash can body.

Step 3: Push the liner rim and lid down together to close.

Step 4: The trash bag is securely held in place and concealed for a neat appearance.