

SW-7032 Shower Wall Kit

HIGH-GLOSS SHOWER WALL KITS

Manufactured from Swan High-Gloss (see page 2 for detailed information)

4"

WARRANTY

Limited Lifetime – Residential

Limited 5-year – Commercial

FEATURES

- Ultra-bright, glossy surface comes from durable, baked-on finish
- Includes all materials needed for installation
- The SW-7032 is a glue-up 3-piece shower wall panel system
- · Compression molded

SW-7032

Designed to fit base areas 32" wide x 32" deep or smaller x 70" high (813 mm x 813 mm x 1778 mm)

SPECIFICATIONS

SW-7032 High-Gloss Shower Wall Kit

Model	Part	Base Area Designed To Fit	Ship Wt. Lb.	Ship UPS	Carton Dims. In.	Cu. Ft.
SW-7032	SW07032	32" W x 32" D* x 70" H (*or smaller) (813 mm x 813 mm x 1778 mm)	48	-	74 x 34 x 6	8.74

Kit Includes: One back panel with molded-in soap dish and shampoo shelf, two end panels, one roll of pressure sensitive tape, three tubes of adhesive, one tube of caulk and complete installation instructions.

Packaging: Each kit is packed in a flat, rectangular carton.

ACCESSORIES

See page 55 for complete listing of all shower wall accessories.

STANDARDS AND RATINGS

Class B fire rating American Society for Testing and Materials National Electrical Manufacturers Association

SUPPORT DOCUMENTS

Installation instructions available on line at www.swanstone.com

COLORS (See pg. 139 for color sample.)

- White (010)
- Bone (037)
- Bisque (018)

MAINTENANCE AND CLEANING INFORMATION

Warning: Do not use abrasives as it will dull the glossy finish! This product is made of Swanstone with a gloss finish. While it is stain resistant, it requires regular and reasonable care. Wash regularly with warm water and a non-abrasive cleaner such as Soft Scrub Liquid Gel with bleach (without abrasives), Clorox Clean-up with bleach, Top Job or Mr. Clean. Remove hard water stains or mineral build up with scale removers such as Lime-Away.

Do not use harsh cleansers or abrasives such as scouring powders, abrasive cleansers or scouring pads. Abrasives will dull the finish. Protect the finish with fiberglass wax or automotive paste wax.