

How to Apply Aluminum Roof Coatings



STEP 1: PREPARE THE SURFACE

1. **Clear roof surface** of loose debris including dirt, gravel, sticks, etc. using a push broom or blower
2. **Clean surfaces** with brooms or blowers, and pressure wash to remove dirt, dust, and loose material.
3. **Inspect the surface** for cracks, blisters, and other problem areas.
4. **Patch and repair** using **Black Jack or Leak Stopper roof cements** and reinforcing fabrics. See label directions for application, and allow proper cure time before topcoating.

Recommended Surfaces

- Metal
- Modified Bitumen
- Rolled roofing
- Built-up Roof (BUR)
- Existing Aluminum Coating

Recommended Applicators

- Roof brush
- ¾ inch nap roller

STEP 2: APPLY BLACK JACK ALUMINUM COATING

- Apply at 60°F and rising, not exceeding 100°F.
- All products except **Leak Stopper black roof patch** and **All-Weather Roof Cement** should be applied on a clear sunny day with no rain for at least 24 hours.

Coverage Rates: Two coats recommended
Approximately 50 square feet / gallon (most surfaces);
75 square feet / gallon over metal roofing



ALL BLACK JACK PRODUCT LABELS INCLUDE APPLICATION INSTRUCTIONS.
WHEN IN DOUBT, CHECK THE LABEL, AND SHOW THE CUSTOMER THE LABEL DIRECTIONS.