





76 Whitetail Dr. Rexford, MT 59930 888.889.3728
www.montanawoodworks.com cs@montanawoodworks.com

"From The Mountains of Montana to Your Home"

Assembly Instructions for Glider and Single Seat Glider

Thank you very much for purchasing your heirloom quality glider from Montana Woodworks®. Should you have any questions or need to contact sales or support, please do not hesitate to contact our corporate offices at 888.889.3728 or via E-Mail at:
cs@montanawoodworks.com

Tools Needed: 9/16" & 7/16" Wrench or Socket, Rubber Mallet

Before beginning assembly please take a few moments to read the instructions carefully, understanding each step. Likewise, please also ensure that the hardware package contains the items as described here.

Parts List: (1) Back, (1) Seat, (1) Right and Left Arm, (1) Lower Glide Assembly

Hardware List: (6) 3" Lag Screws, (4) 4" Hex Bolts, (4) Hex Lock Nuts, (14) Washers (4) Levelers (4) 4" Screws

Assembly Directions:

Step 1. Remove components from boxes. You may lay the cardboard on floor to prevent marring of finish.

Step 2. Place arms "A" onto tenons of seat assembly "B" and back assembly "C".

Step 3. Tap with rubber mallet if needed.

Step 4. Insert lag screws "F" with washers into the pre-drilled side holes and TIGHTEN FULLY.

Step 5. Place completed seat/back assembly over lower glide assembly "D" making certain that the front of glide assembly is forward.

Step 6. Insert one bolt through each hole in the four pre-attached glide swivels "E".

Step 7. Place one washer on each bolt so there is a washer between the steel glide assembly and the wood surface.

Step 8. Insert one bolt through each of the four predrilled holes in the lower glide assembly. Place one washer on each bolt and hand tighten a nut onto each bolt.

Step 9. Gently glide unit back and forth by hand. *Do not sit on the assembly at this time.*

Step 10. Using socket and wrench(s), tighten until snug. Glide assembly must move freely. Do not over-tighten.

Step 11. Insert 4" screws into the predrilled back holes and tighten fully. This secures the back to the side arms.

Step 12. Insert a leveler into each of the four, pre-installed receptacles on the bottom logs of the lower glide assembly. Adjust each in turn until the glider is level.

Your new glider is now fully assembled. Enjoy!

- Please Note" If you purchased your glider "ready to finish" special care must be taken to properly apply a high grade final finish in a timely manner. Doing so will help protect your purchase from discoloration and damage caused by exposure to ultra-violet light and/or weather. If the intended use is outside, please use an exterior finish to also protect the item from weather damage. See use and care instructions for further information. Failure to adequately protect item by the applications of a final finish may void warranty. Failure to annually re-inspect final finish and re-apply as necessary may void warranty.