

# KOHLER® Roughing-In

## K-T10581, K-T10582, K-T10583, K-T10584 BANCROFT® BATH AND SHOWER FAUCET TRIM

### Product Information

Applicable product:	
Bath and shower trim, metal lever handle, NPT spout (shown)	K-T10581-4
Bath and shower trim, ceramic lever handle, NPT spout (shown)	K-T10581-4P
Bath and shower trim, metal lever handle, slip-fit spout	K-T10582-4
Bath and shower trim, ceramic lever handle, slip-fit spout	K-T10582-4P
Shower only trim, metal lever handle	K-T10583-4
Shower only trim, ceramic lever handle	K-T10583-4P
Valve only trim, metal lever handle	K-T10584-4
Valve only trim, ceramic lever handle	K-T10584-4P
NPT diverter bath spout	K-10588
Slip-fit diverter bath spout	K-10589

Required accessories:	
Rite-Temp valve <b>OR</b>	K-304-*
HiFlow Rite-Temp valve with stops	K-2971-KS
* For a complete listing of all the Rite-Temp valves, refer to the K-304-* Specification Sheet or Roughing-In sheet.	

#### Optional accessories:

HiFlow Rite-Temp® thin wall installation kit	88526
--	-------

### Installation Notes

Install this product according to the installation guide.

**NOTICE: Risk of product damage.** Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Avoid cross-flow conditions. Do not install shut-off device on either valve outlet.

Install straight pipe or tube drop of 7" (17.8 cm) to 18" (45.7 cm) with single elbow between valve and wall-mount spout.

