



PREMIUM STEEL MOBILE HOME SKIRTING

Product Installation Guide



Installation Tools Needed

- Electric Saw (for framework only)
- Cordless Drill or Hammer
- Tin Snips
- Shed-resistant Paint Roller
- Level

Recommended Hardware

- 2" X 4" Lumber for framework (treated recommended for bottom edge)
- Galvanized roofing nails with rubber washers OR 1" Stainless Steel screws
- Galvanized J-Channel or corner protectors (deck screws recommended for J-Channel installation)
- Pipe grip ties and 24" rebar sections to secure frame at ground level



Using the spaces between the block pattern as a guide, you may fasten skirting to framework with either a hammer and galvanized roofing nails (with rubber washers) or with stainless steel screws as seen in the



Corners can be made by bending skirting around or into the corner or can be trimmed and J-channel used along the top, bottom and end edges of

***The versatile,
affordable, durable,
easy to install
alternative to other
skirting options***

330 Industrial Park Drive SW
P.O. Box 206
Carrollton, OH 44615
Phone: (800) 452-0484
Fax: (330) 627-7090
Email: dma@sevenranges.com
www.dmaskirting.com

Framework consists of 2" X 4" boards placed 5' apart or 30" on center. Pipe grips secure rebar sections that have been anchored into the ground.



Primer and paint can be applied to your skirting immediately, or you may allow the skirting to "weather" for several months and then apply paint without primer. Check your local home improvement store to find the paint suitable for your location.

QUICK TIP: *Shed-resistant paint rollers will cover your skirting quickly and beautifully.*

**FOR MORE INFORMATION
VISIT US AT
www.dmaskirting.com**