

POHLIG BROS. LLC	
DATE: 10/14/2011 CUSTOMER: Delta Circle DESC: Wall RX small Kit SPEC#: 28832 CAD#: KD6182_Small ORDER#: xxxxx FILE NAME: kd6182_small.ap	COLORS IN JOB: Cyan Magenta Yellow Black Dieiline
CLIENT APPROVAL REQUIRED	
NOTICE: It is necessary to examine this proof for color & copy. Please note all corrections directly on this proof. If you are also running match, demand or PMS inks along with process inks, those colors are simulated on this proof. You must refer to your ink color draw downs for actual color. This proof should be returned as quickly as possible, since a prompt response is essential to maintaining your press schedule date. Should you have any questions, please call your CSR or Salesperson at 804-275-9000	
<input type="radio"/> OK as submitted	<input type="radio"/> changes made, new proof not required
Signature _____ Date _____	

Anyone can do it! Affordable, portable and **FAST!**

SMALL KIT

PRESCRIPTION FOR YOUR WALL



Satisfaction Guaranteed

SMALL KIT



BEFORE



AFTER

No Tools

No Skills

No Mess

The *fastest* and *simplest* way to repair any drywall hole!

This **SMALL KIT** contains repairs for:
2 inch hole
1 inch hole



Made with *Pride* in the **USA**



WALL+RX

Complete Wall Repair Kit

SMAL KIT

SMALL KIT

Complete Wall Repair Kit

No skills or tools required!

No Tools
No Skills
No Mess

WALL+RX™

Anyone can do it! Affordable, portable and **FAST!**

Cualquiera puede hacerlo! Asequible, portátil y **RÁPIDO!**

1



PLACE

Coloque WallRx disc (disc must be 1" larger than hole)

Remove WallRx disc from the package, peel off the back cover and place disc with adhesive side over the drywall hole.
Retire el disco WallRx del paquete, retire la cubierta posterior y Coloque el disco con el lado adhesivo sobre el agujero de paneles de yeso.

2



PEEL

Pela WallRx frame

Remove WallRx frame from package and peel off back cover.
Quite el marco WallRx del paquete y retire la cubierta posterior.

3



PRESS

Presione

With palm of hand, firmly press WallRx frame with compound over disc.
Con la palma de la mano, presione firmemente el marco WallRx con el compuesto sobre el disco.

4



ROLL

Alise

Gently roll fingers over WallRx membrane and spread compound evenly around hole. Smooth out edges with fingertips for best results. Compound typically dries in 48 hours. Once compound is dry and hard, remove frame from wall and gently sand to desired smoothness.
Nota: Drying time and finished surface results may vary.

DONE

Disfrutar de

Cuidadosamente mueva los dedos sobre la membrana WallRx y el compuesto difusión uniformemente alrededor del agujero. Suavizar los bordes con los dedos lo mejor para resultados. Compuesto por lo general se seca en 48 horas. Una vez compuesto esté seco y duro, sacar el marco de pared y con cuidado de arena a la suavidad deseada.
Nota: El tiempo de secado y acabado de superficie resultados pueden variar.

✓



GUARANTEE

If you are not completely satisfied with your purchase return to The Wall Doctorx, LLC for a full refund!
Si usted no está completamente satisfecho con su declaración de compra para el Doctorx Wall, LLC para un reembolso completo!

101-2-12-SR



8 56497 00302 0

The Wall Doctorx, LLC
Wilmington, DE
www.walldoctor.com
Made in U.S.A. Patent Pending
© 2011 The Wall Doctorx, LLC

Warning

Keep out of reach of children. Do not ingest.

Advertencia

Mantener fuera del alcance de los niños. No ingerir.