

CedarSafe® Natural ClosetLiner™ 100% Aromatic Cedar

CedarSafe® Cedar Closet Liners available in:

Consumer Pak – 15sq. ft. 3-3/4 in. x 1/4 in. x random length planks.

Project Planning

Calculating Boxes Needed: Measure width and height of each surface to be covered. Calculate and total square footage and add to that the square footage of the floor and ceiling. Include the door area to completely protect the closet. Use the chart below to determine how many boxes are needed. After calculating the depth and width, read across the chart for the suggested number of boxes.

		Closet width in inches Largeur du placard en centimètres (pouces)							
		24"	36"	48"	60"	72"	84"	96"	108"
Closet depth in inches PProfondeur du placard en centimètres (pouces)	16"	4	6	7	8	9	11	12	13
	18"	5	6	7	8	10	11	12	13
	20"	5	6	7	9	10	11	13	14
	24"	5	7	8	9	11	12	13	15
	30"	6	7	9	10	12	13	14	16
	36"	7	8	10	11	12	14	15	17
	48"	8	10	11	13	14	16	18	19
	60"	9	11	13	14	16	18	20	21

Chart assumes an 8' wall height
Dans le tableau, la hauteur par défaut est de 2,44 m (8 pi)

CedarSafe Cedar Closet Liner Plank Preparation:

- Store in area being lined for 48 hours, so cedar can adjust to moisture content
- Do not install too tightly; allow room for natural expansion of wood
- Walls need to be as smooth as possible - clear all nails, hooks, shelf brackets, etc.

Tools Required:

A medium weight claw hammer, a tri-square, and a hand saw with fine teeth. A miter box is helpful but not essential.

Nails Required:

Colored paneling nails for nailing over wallboard. With plaster and lathe, nails may need to be longer. If splitting occurs, pre-drill holes.

Adhesive needed:

Use a subfloor approved adhesive, such as Loctite® PowerGrab® All-purpose (#185445) Heavy Duty Construction Adhesive and PowerGrab® Panel and Drywall (#241406), in conjunction with nails or mechanical fasteners.

Installation:

(Complete installation instructions accompany each box of CedarSafe Cedar Closet Liners)

1. Locate studs by tapping wall with hammer or using an electric stud finder. Using a yard stick and pencil, mark center line at all studs.
2. Starting at the back wall, apply Cedar Planks horizontally. Select a piece shorter than width of back wall. Place the grooved edge down against floor; slip to left until end fits into corner. Nail at stud mark through the plank face.
3. To finish first run, place and nail additional lengths. Make sure that run is level as it is being completed. Cut last piece so it will fit the remaining opening. Use other end to start second run. Repeat this procedure until you reach the ceiling. At ceiling, rip pieces to fill remaining gaps or, for a more professional finish, use cove moulding to cover any gap.
4. Follow same procedure to cover side walls. Line the front wall last.
5. For door trim, run each course up to the trim, same as fitting in a corner. When top of door is reached, cutting and fitting is usually required. Moulding gives a professional finish.
6. Line the back of door as in Step 2 and 3 using an adhesive.
7. Cover the ceiling and floor as in Step 2 and 3.
8. Install cove moulding in corners to cover any gaps.
9. No further finishing is required.
10. Maintenance: Over time, cedar oils will crystallize on the surface of the planks, sealing in the aroma. This can easily be regenerated with light sanding every few years.

Giles & Kendall, CedarSafe and the Environment:

Giles & Kendall uses only Aromatic Eastern Redcedar in the manufacture of our products, as only Aromatic Eastern Redcedar provides natural protection against insect pest infestation and mildew. This unique Cedar wood is not an endangered species. NaturalClosetLiner™ is a trademark of Giles & Kendall, Inc.