

## Assembly Instruction Sheet #IS-VVCS9360 For Style VVCS93600I AND VVCS9360PK

Tools Required: None.

Bulb Recommended: (3) Medium Base 75W Maximum, Alternate bulb (3) 19W CFL

Estimated Assembly Time: 20-30 minutes

**Preparation:** Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.

## **△** Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.

## **INSTALLATION**

- A. Attach Socket Assembly, Column, Rod, Rod with Connecter and Base together. Hand tighten until snug. Pull the cord from the Base as you assemble the parts together to remove the excess cord between parts.
- B. Place Shade over the Nipple on the top of Socket Assembly, secure by threading Finial onto the Nipple, hand tighten until sung.
- C. This fixture uses standard bulb with medium base . Maximum 75 watts. Insert bulb and screw snugly into place.

Your fixture is now assembled and ready to use. Enjoy!

Note: Light the bulbs by rotating the switch on the column at the bottom of the socket assembly as shown.



