

Montana Woodworks, Inc.  
Assembly Instructions for Log Daybed w/ Pop Up Trundle

Thank you very much for purchasing our heirloom quality log daybed with pop up trundle. Should you have any questions or need to contact sales or support, please do not hesitate to contact our corporate offices at 888.889.3728 or via E-Mail at: [cs@montanawoodworks.com](mailto:cs@montanawoodworks.com)

Before beginning assembly please take a few moments to read the instructions carefully, understanding each step. Likewise please also ensure that the hardware package contains the items as described here.

Tools Needed: 9/16" Wrench or Socket

Parts List: (1) Log Back Support, (2) Log Arm Supports, (1) Top Spring, (1) Pop Up Trundle

Hardware List: (4) 3" Lag Bolts & Washers, (8) Lag Shields, (8) 2 ½ " Lag Bolts and Washers

Step 1. Bolt Log Back support to Log Arm supports by inserting back supports into pre-drilled holes in arm supports. Note; it may be necessary to cut the black banding around Log Back Support at this time. If Back Supports fits easily into Arm Support holes, leave banding intact until step 5.

Step 2. Secure Back Support/Arm Support assembly with the (4) 3" lag screws. DO NOT FULLY TIGHTEN THESE BOLTS UNTIL AFTER THE TOP SPRING HAS BEEN SECURED.

Step 3. Attach the Top Spring into the pre-drilled holes on Arm Supports. Insert lag shields into pre-drilled holes and line up frame. Secure with (8) 2 ½ " lag bolts and washers.

Step 4. FULLY TIGHTEN ALL BOLTS/FASTENERS AT THIS TIME.

Step 5. Cut black banding around Back Support at this time if not done earlier.

Step 6. Pop Up Trundle slides under Top Spring. To open read printed instructions on Pop Up Trundle.

PROUDLY MADE IN THE U.S.A.

Pine requires a good sealant. We recommend two coats of varnish being applied per manufacturer's directions. The item may be stained prior to the application of the varnish.