

Vanity Installation Guide

Bow Front Vanity / Reeded Front Vanity

Models - 605-10-V300, 307-44-V2400, Item # 368496, 368497

Package Contents Included:

- Wood Vanity Case
- Cultured Marble/Granite Top
- Natural Pure Solid Copper Sink
- Oil-Rubbed Bronze Grid Drain

Before You Begin

NOTICE: This installation is best with two people.

- Observe all local plumbing and building codes.
 - The appearance of your vanity may differ from the illustrations in this guide. The instructions still apply.
 - Prior to installation, unpack the new product and inspect it for damage. Return the product to its protective carton until you are ready to install it.
 - Make sure the finished wall is straight and plumb, and the floor is flat and perpendicular to the finished wall.
 - Remove any molding that may inhibit the vanity from being flush against the finished wall.
-

Keeping Your Vanity & Sink Beautiful

Wood Vanity Cleaning – We recommend dusting frequently with a clean, soft, dry, lint-free cloth. Clean surface by rubbing in the direction of the wood grain to reduce scratching. Try to avoid placing your Vanity in direct sunlight which could cause fading.

Pure Solid Copper Sink Cleaning & Maintenance – Gently wash your copper sink with soap, water, and a soft cloth or sponge. Occasionally wipe dry to remove any standing water. Rinse sink thoroughly after use to reduce spotting. NEVER use anything abrasive, soft scrub, Clorox or Drano type products. Copper has natural anti-microbial properties that promotes healthy living.

Aged Copper Sink – Maintenance Tips

- Aged Copper finish will change very little with time.
 - It is recommended that you wax your sink with fixture wax occasionally or high-end automotive or furniture wax
 - NEVER use copper polish or anything abrasive, it will remove the aged patina finish.
 - If your sink finish begins to lighten, the finish will naturally darken through coppers natural patina process. Ages much like the finish of a penny.
-

Installation

Unpack

- Gently open box and remove top packaging contents (box knife not recommended)
 - Lift top and sink out of box and place upside down on clean towel or carpet.
 - Locate and remove Drain box and place aside
 - Gently tip box backwards while lifting wood vanity case out of box.
 - Carefully inspect vanity for damages while unwrapping vanity packing. If damages are found please stop and repackage as originally received.
-

Installing Sink and Drain

**** NOTE ** In order to maintain proper under-mount sink location, please trace front/back and side edges prior to removing under mount brackets and foam.**

- With sink and top upside down remove 4 under-mount brackets and set aside.
 - Remove sink from top and discard protective foam. Place sink in safe area.
 - Locate and open the grid drain included. Using drain assembly instructions securely attach drain to sink. Use plumbers putty on the inside lip of the drain hole to prevent leakage.
 - Apply a small continuous bead of 100% clear silicone to the bottom of the counter top. Measure 1/2” back from sink hole opening for ideal silicone placement.
 - Once silicone application is complete, using the 4 trace markings slowly position sink back into its original under-mount location.
 - With sink in proper under-mount location gently place metal clips into place. Once all 4 clips are in place slowly tighten screws into anchors. While holding the sink in place carefully tighten and secure the wing nuts to bracket.
 - Gently turnover top to inspect proper sink placement. Use a clean damp cloth or towel to remove any silicone excess.
 - Optional use clear silicone to fill in any gaps from inside of bowl and remove any excess silicone.
-

Securing Top to Vanity with Silicone (Optional)

- With opened Topless vanity in its designated location you can begin installing the marble top to the vanity.
- Carefully apply a thin continuous bead of 100% silicone to the entire top edge of the vanity.
- Slowly position top onto the vanity and ensure top is faced in the proper direction (faucet holes to the back)
- Adjust vanity top as needed and wipe off any excess silicone.
- Let silicone dry for 4 to 6 hours minimum. Overnight is preferred.
- After silicone dries – finish water and drain attachments.