



Making Quality Roofing Felt Since 1984

United Roofing Mfg. PRODUCTS

Installation Guide

15 Lb. Felt Quality Roof Deck Protection

Lowe's Item 10306

Do not walk on any felt that is not securely fastened to the roof. Always use proper safety equipment during installation. Roofing felt should be installed from the bottom of the roof in horizontal layers to increase the ability of the rain water to shed off the felt. The initial layer of the felt should be installed to cover the bottom edge of the decking, from edge to edge. Overhang is not required. Position the felt and anchor the top corner, then roll the felt out across the roof. Be sure to roll the felt smoothly to avoid wrinkles. The top edge of the felt should be fastened approximately every eight inches, as well as, the middle and bottom edge. The second layer should overlap the first layer to the 2" lap line. If the roll of felt should run out before you reach the edge of the roof, then overlap the previous felt 4" with the new roll (end lap). The fastening pattern used on the first layer should be used on all subsequent layers. If you do have wrinkles, slice the wrinkles with a utility knife and fasten them flat to the deck. If the primary roof is not installed immediately, seal the cuts with waterproofing cement.

NOTE: Local building codes may dictate an alternative application pattern to the information stated above. Always consult and comply with your local building code prior to application.