



PATIO STONES | KEYSTONE EMPIRE PATIO

EMPIRE Stone™

INSTALLATION



1. Mark & Dig

Excavate the installation area to approximately 6 in. larger on all sides than the actual finished size.




4. Lay Stones

Lay patio stones in the desired pattern. If the desired pattern requires cutting, the patio stones can be cut with a wet saw.



2. Base & Compact

Install patio base to a compacted finished thickness of 4 in. for patios and walkways.



5. Sand & Finish

Spread polymeric sand on the installation and sweep into joints, according to manufacturer's instructions. Sweep off any loose sand from project surface.



3. Base Preparation

Lay a 1 in. outside diameter pipe on base. Spread 1 in. of sand over compacted base. Level the sand by dragging a 2 in. x 4 in. board over pipe.



6. Edge Restraint

Install patio restraint edging and spikes around the entire project, according to the manufacturer's instruction.



Keystone Retaining Wall Systems LLC • A Contech Company
4444 West 78th Street • Minneapolis, MN 55435
(952) 897-1040 • www.keystonewalls.com

©2017 Keystone Retaining Wall Systems LLC

