



EDGERS | INSIGNIA® EDGER



INSTALLATION



Mark & Dig

Mark an outline of your project. Then dig a shallow trench 3" deep by 6" wide to receive the edging unit.



Adjust & Finish

Adjust unit alignment by hand or by using a rubber mallet to tap the units in place. Finalize your installation with the landscape rock, mulch, sod or materials of your choosing.



Place & Level

Place units in the trench, in either a straight line or a curved alignment. Interlock the overlap edge detail of the A & B units in an alternating manner.

Use this chart to estimate the number of units you will need.

	Linear Project Length									
	5'	10'	15'	20'	25'	30'	35'	40'	45'	50'
Units (each)	4	8	12	16	20	24	28	32	36	40

