

# 4x8 HOLLAND PAVER

A timeless classic, the Holland Paver is a versatile product ideal for walkways, patios and garden paths. The traditional brick shape gives a classic look that can be used in a variety of patterns, including herringbone, basketweave and running bond.



## INSTALLATION INSTRUCTIONS



Refer to [www.call811.com](http://www.call811.com) before digging or excavation begins. Dig entire area where pavers are planned approximately 6" deep and 6" longer and wider than desired final dimensions. Remove any grass, sod, roots, large rocks and/or organic material.



Use a vibratory plate compactor or hand tamper to compact the new excavated area. Add approximately 2" of paver base material, spraying with water to keep moist while compacting. Repeat this process until desired thickness of base is reached. (typically approx. 6") Keep in mind that any elevation inconsistencies on the compacted base will be evident on finished paver surface.



Place two pieces of 1" outside diameter pvc or steel pipe on compacted aggregate base with a comfortable workable space between the two pipes. (approx. 3'). Place paver sand between pipes and use a wood 2x4 or aluminum screed to evenly screed fine paver sand on top of compacted base material. Keep repeating this process for entire base area being careful not to disturb screeded sand. Once pipes are removed, fill in area with loose paver sand and smooth over with straight edge.



Install PVC edge restraint (recommended) per the manufacturer's instructions. Lay pavers in loose, uncompacted paver sand, using a rubber mallet to make minor adjust pavers if necessary. Do not pound pavers into place with mallet. Vibratory plate in next step will compress pavers into sand. Keep paver joints tight to each other laying in the pattern of your choice. Use of string lines is suggested to ensure that vertical and horizontal joints maintain alignment during installation for the most even appearance.



Run vibratory plate or use hand tamper to compress pavers into loose sand setting bed. Care should be taken in this step not to scuff or excessively scratch paver surface. Use of cardboard sheets or rubber mats under tamper plate are suggested.



Sweep dry polymeric sand into joints between pavers after initial compaction, being sure to follow manufacturer's recommended installation instructions. You are now ready to enjoy your 4x8 Holland Paver project