



MAIDAN FLOATING VANITY SUPPORTS INSTALLATION INSTRUCTIONS

Installation Considerations

Every successful vanity installation begins with good planning and action. Do not wait until the last minute to order your vanity support, fasteners or adhesives for installation. Make sure that all aspects of the support substructure are considered and discussed to insure that your vanity installation will be smooth and that your vanity support will be sufficient.

Note that this installation document should not be considered a specific recommendation for your particular application. Federal Brace cannot provide installation guidelines to meet the particulars of every application. This document should be considered a help sheet that provides considerations about the general characteristics of a particular type of support and installation.

Characteristics of the Maidan Floating Vanity Support Bracket

Our Maidan Vanity Bracket is designed to provide the support strength necessary to wall mount a standard vanity in a bathroom setting. The material thickness of the Maidan Floating Vanity Support Bracket is $\frac{1}{4}$ ". The Maidan Support comes in both brushed stainless steel and black powder coat painted steel materials. Slots are providing for mounting to allow positioning always to be in a stud. The Maidan Vanity Support has a 200 pound carrying capacity.

Considerations when Installing Maidan Floating Vanity Support Brackets

Whenever installing the Maidan Brackets make sure that you provide the thickest possible substructure (at least 1.75") on which to fasten the bracket. You will want the fasteners to have as much "biting" material as possible. This will provide a secure fastening of the brackets. Remember, a weak substructure makes for a weak installation. The Maidan should be spaced no more than 16" apart for the length of the counter if more than 4" overhangs on each side.

Note: The Maidan Floating Vanity Support should be tied into studs. Determine the position of the bracket. Hold the bracket in the selected location and mark your holes for drilling and attachment of bracket to the substructure. Make sure that when you fasten the bracket that you check for level in all directions. The bracket should be straight up and down and be level across the top flange as well as down the top flange. This will give the best possible support result to your vanity.

You should position the Maidan Vanity Support Bracket at such a height that it places your vanity at the desired height. Standard

counter height is approximately 35". Once the bracket(s) are in place, you will want to wipe them down to get rid of any hand prints or other debris. Just before installation of your vanity you will want to apply adhesive or silicone to the top of the bracket to adhere it to the vanity.

Final step is to enjoy your work and your new bathroom vanity! We are thankful that you chose to support your beautiful vanity with Federal Brace brackets. We would be thankful if you would send us images of your new bathroom and our brackets under your vanity. We enjoy seeing Federal Brace supports at work.

Also, know that the highest compliment Federal Brace can be given is a reference from our customers to friends and family. If you have enjoyed your buying experience with Federal Brace please let someone know.

For any questions or comments please to contact us by email at customer.service@federalbrace.com or by phone at (877) 353-8899. If you are a visual learner, check out our installation videos on our YouTube channel Don't forget to share your projects with your new Federal Brace brackets on Twitter and Instagram, just tag us @FederalBrace. Like us on Facebook, and check out our boards on Pinterest for more home improvement/decor and DIY project ideas.

