



Federal Brace
BEAUTIFULLY CRAFTED CONFIDENT SUPPORT

FURNITURE FEET | *Corinthian*



FURNITURE FEET CORINTHIAN INSTALLATION GUIDELINES

Every successful furniture foot installation begins with good planning and action. Be sure to plan for the proper amount of parts required for your project and the correct fastening components. Make sure that all aspects of the furniture or cabinet you are supporting are considered and discussed to insure that your furniture foot installation will be smooth and that your support products will be sufficient.

Note that this installation document should not be considered a specific recommendation for your particular application. Federal Brace cannot provide installation guidelines to meet the particulars of every application. This document should be considered a help sheet that provides considerations about the general characteristics of a particular type of support and installation

Characteristics of the Corinthian Cabinet Foot

Our Corinthian Cabinet Foot is designed to be mounted to the bottom of a cabinet, island or a piece of furniture. The thick stainless steel material is designed to support all types of applications and the weight that might accompany the cabinet or furniture.

Preparations for the Corinthian Cabinet Foot

The installation of our Corinthian Cabinet Foot will require a hanger bolt or a dowel and threaded insert. This will be deter-

mined by what you are installing the Corinthian on and how the receiving end is made. If mounting directly into wood with a pilot hole then a hanger bolt is required. If a threaded hole is in place on the furniture then it will receive a dowel to install.

Considerations when Installing the Corinthian Cabinet Foot

The Corinthian should be installed on all four corners of cabinets and furniture where applicable. You will want to make sure your furniture or cabinet base is prepped for the furniture foot. This may mean drilling a pilot hole if you are using a hanger bolt or a larger hole if a threaded insert is the desired install method. Insert the hanger bolt (fine thread end) or dowel into the tapped hole on the Corinthian till you meet the coarse threads on the hanger bolt or half the length of the dowel. If using the hanger bolt, drill a pilot hole into the wood bottom of the cabinet or furniture piece. Insert the hanger bolt and tighten until the foot